ALE BUILDING LAWS PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://alebuildinglaws.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. **How many seats are necessary for PWD in an assembly area that can hold 500 or more individuals?**

   A. 6

   B. 8

   C. 10

   D. 12

2. **What is the raised rim at the edge of a street or sidewalk called?**

   A. Curb

   B. Bump

   C. Edge

   D. Sidewalk barrier

3. **According to PD 1096, what is the minimum width of an exit door?**

   A. 750 mm

   B. 900 mm

   C. 1 m

   D. 1.2 m

4. **In assembly areas, what is the maximum slope for exit ramps according to RA 9514?**

   A. 1:10

   B. 1:12

   C. 1:14

   D. 1:16

5. **What is the key characteristic of an 'interior lot'?**

   A. Located at a street intersection

   B. Not adjacent to any right-of-way

   C. Surrounded by other lots

   D. Accessed from two roads

SAMPLE

6. What is the minimum height for wall or door signage?

A. 1 m

B. 1.4 m

C. 1.6 m

D. 1.8 m

7. What is the minimum area for parks and playgrounds according to BP 220?

A. 50 sqm

B. 100 sqm

C. 150 sqm

D. 200 sqm

8. What type of permits do Architectural Permits, Civil/Structural Permits, and Electrical Permits fall under?

A. Main permits

B. Ancillary permits

C. Special permits

D. Temporary permits

9. For places of assembly serving 60 seats or more, what is the minimum aisle width on one side only?

A. 760 mm

B. 900 mm

C. 912 mm

D. 1200 mm

10. What is the minimum distance of horizontal firewall projection according to BP 220?

A. 200 mm

B. 300 mm

C. 400 mm

D. 500 mm

SAMPLE

Answers

SAMPLE

1. D
2. A
3. B
4. B
5. C
6. B
7. B
8. B
9. C
10. B

SAMPLE

Explanations

SAMPLE

1. How many seats are necessary for PWD in an assembly area that can hold 500 or more individuals?

A. 6

B. 8

C. 10

D. 12

In assembly areas designed to accommodate 500 or more individuals, regulations stipulate that a specific number of seats must be reserved for persons with disabilities (PWD). This is mandated to ensure accessibility and compliance with disability rights laws and building codes. According to common guidelines, for every 100 seats in assembly areas, one must be designated for wheelchair use, beginning with a minimum standard for larger capacities. In an assembly area that holds 500 individuals, the required number of designated seats for PWD aligns with the regulatory framework that sets this minimum at 12 seats. This approach ensures adequate provision for accessibility and is a reflection of the commitment to inclusivity in public spaces. Each of the other options falls short of this requirement, as they do not meet the stipulated guidelines designed to accommodate persons with disabilities effectively and appropriately.

2. What is the raised rim at the edge of a street or sidewalk called?

A. Curb

B. Bump

C. Edge

D. Sidewalk barrier

The raised rim at the edge of a street or sidewalk is referred to as a curb. A curb serves multiple important functions, including defining the boundary between the roadway and the pedestrian walkway, providing a physical barrier that helps to manage drainage by directing water away from the street, and enhancing safety by preventing vehicles from encroaching on pedestrian spaces. A curb is typically made of concrete and has a defined height, creating a noticeable distinction between the street and sidewalk. This structure is crucial for urban planning and design, as it enhances the safety and usability of public spaces for both vehicles and pedestrians. The other options do not accurately define this structure. A bump might refer to any raised surface but does not specifically indicate a boundary; edge is a general term that lacks the specificity of its use related to streets or sidewalks; and a sidewalk barrier typically implies a more elaborate physical obstruction than a standard curb, often used for safety or separation but does not describe the common raised edge.

3. According to PD 1096, what is the minimum width of an exit door?

A. 750 mm

B. 900 mm

C. 1 m

D. 1.2 m

The minimum width of an exit door, as established by PD 1096, is specified to be 900 mm (or 0.9 meters). This requirement is designed to ensure that occupants can safely and swiftly exit a building in the event of an emergency, minimizing the risk of crowding and allowing for efficient evacuation. A width of 900 mm strikes a balance between providing ample space for individuals to pass through, including those who may be using mobility aids, and accommodating the structural limitations and design considerations of various buildings. This regulation reflects the importance of safety in building design and aims to facilitate a quick exit from potentially hazardous situations. Other options, such as 750 mm, 1 m, and 1.2 m, do not conform to the established minimum, as 750 mm is narrower than required for emergency egress, while 1 m and 1.2 m exceed the minimum width established in the code and are likely not required unless specified by additional regulations for particular types of buildings or circumstances.

SAMPLE

4. In assembly areas, what is the maximum slope for exit ramps according to RA 9514?

A. 1:10

B. 1:12

C. 1:14

D. 1:16

The maximum slope for exit ramps in assembly areas as stated in RA 9514 is 1:12. This designation indicates that for every 12 units of horizontal distance, the ramp should rise no more than 1 unit. This specific slope is crucial in ensuring that ramps are accessible and safe for individuals using mobility aids, such as wheelchairs, as well as for general use by the public during an evacuation process. A slope of 1:12 provides a balance between safety and functionality, ensuring that the ramp is not too steep to navigate. Ramps with steeper slopes, like 1:10, would pose challenges for individuals with limited mobility or those carrying heavy objects, increasing the risk of accidents during evacuation. Conversely, a slope of 1:14 or 1:16 would not meet the requirements for emergency escape routes, as they might be too gentle, affecting the efficiency of the exit during an emergency. Hence, the adherence to a 1:12 slope ensures compliance with safety regulations while promoting universal accessibility.

5. What is the key characteristic of an 'interior lot'?

A. Located at a street intersection

B. Not adjacent to any right-of-way

C. Surrounded by other lots

D. Accessed from two roads

An interior lot is defined primarily by its positioning in relation to surrounding properties and access points. The key characteristic of an interior lot is that it is surrounded by other lots and does not have frontage on a public right-of-way. This means an interior lot is encased by neighboring lots on all sides, making it distinct from corner lots or through lots which have openings to public streets. The other options reflect characteristics that do not align with the definition of an interior lot. A lot located at a street intersection typically refers to a corner lot; being not adjacent to any right-of-way suggests a situation that depicts a landlocked scenario, which also does not conform to the standard definition of an interior lot; and a lot accessed from two roads usually indicates a through lot that runs between two streets. Therefore, the defining feature of an interior lot remains that it is designed as a property bordered by other lots, without direct access to a public road, reinforcing its classification within zoning and real estate practices.

6. What is the minimum height for wall or door signage?

A. 1 m

B. 1.4 m

C. 1.6 m

D. 1.8 m

The minimum height for wall or door signage is typically set at 1.4 meters. This height is generally established to ensure that signs are easily visible and accessible to a wide range of individuals, including those who may be seated, such as in public spaces, or shorter individuals. It allows for sign visibility without obstruction from objects or furniture that may be present in the vicinity of the sign. Using this height also aligns with accessibility standards, ensuring that signage is compliant with regulations that aim to accommodate individuals with disabilities. Proper signage height is crucial for effective wayfinding and safety within buildings, helping all occupants navigate spaces confidently and efficiently.

SAMPLE

7. What is the minimum area for parks and playgrounds according to BP 220?

A. 50 sqm

B. 100 sqm

C. 150 sqm

D. 200 sqm

According to BP 220, which outlines standards for socialized housing, the minimum area designated for parks and playgrounds is set at 100 square meters. This requirement is significant as it highlights the importance of recreational spaces in residential areas, promoting community well-being and providing essential areas for children and families to engage in outdoor activities. Sufficient space for parks and playgrounds is crucial in densely populated areas to compensate for limited open spaces. This standard ensures that developers allocate a reasonable portion of land for public use, facilitating social interaction and physical activities among residents. The other options do not meet the established minimum requirements mandated by BP 220.

8. What type of permits do Architectural Permits, Civil/Structural Permits, and Electrical Permits fall under?

A. Main permits

B. Ancillary permits

C. Special permits

D. Temporary permits

Architectural Permits, Civil/Structural Permits, and Electrical Permits are categorized as ancillary permits because they are supplementary to the main building permit. An ancillary permit supports the overall construction process by addressing specific elements of a project, ensuring compliance with local codes and regulations. These permits focus on specialized aspects of a building's infrastructure. For example, the architectural permit ensures that the design meets local zoning and building codes, while the civil/structural permit focuses on the engineering and structural integrity of the project. The electrical permit regulates the safe installation and operation of electrical systems. In contrast, main permits would typically refer to the overarching permit needed to initiate a building project, while special permits are often required for cases that don't fit standard building criteria, such as zoning variances. Temporary permits are usually granted for short-term projects or activities, distinct from the ongoing requirements established by ancillary permits. Therefore, recognizing Architectural, Civil/Structural, and Electrical Permits as ancillary helps delineate their specific roles in the broader context of building regulations.

SAMPLE

9. For places of assembly serving 60 seats or more, what is the minimum aisle width on one side only?

A. 760 mm

B. 900 mm

C. 912 mm

D. 1200 mm

In spaces designed for assembly, such as theaters or auditoriums, there are specific requirements regarding aisle widths to ensure safe and efficient movement of people, particularly during emergencies. The minimum aisle width must accommodate the expected occupancy comfortably and allow for expedited evacuation. For places of assembly with 60 seats or more, a minimum aisle width of 912 mm is established as sufficient to facilitate smooth movement. This specified width allows individuals sufficient space to navigate through aisles, reducing the risk of congestion and enhancing safety during events with larger crowds. This requirement aligns with building safety codes and standards aimed at protecting public safety, particularly in emergency situations where quick evacuation may be necessary. Aisle widths less than this threshold could result in dangerous conditions, such as bottlenecks, especially under stress or panic.

10. What is the minimum distance of horizontal firewall projection according to BP 220?

A. 200 mm

B. 300 mm

C. 400 mm

D. 500 mm

The minimum distance of horizontal firewall projection according to BP 220, which pertains to the building regulations in the Philippines, set the requirement at 300 mm. This distance is specified to ensure that firewalls adequately protect adjoining properties from potential fire hazards by extending beyond the exterior wall of a building. The projection serves to minimize the risk of flames or heat from a fire reaching adjacent structures. In the context of fire safety protocols, a horizontal firewall projection is critical for creating a barrier that can withstand fire exposure and prevent the spread of fire laterally. This requirement is especially relevant for buildings that are constructed close to property lines or in densely populated areas, where the danger of fire spreading to other buildings is increased. Understanding the significance of this requirement not only helps in adhering to safety laws but also contributes to effective fire prevention strategies in urban planning and building design.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://alebuildinglaws.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE