AMATEUR TECHNICIAN LICENSE PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://amateurtechnician.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Who must designate the station control operator?

A. The station licensee

B. The FCC

C. The frequency coordinator

D. Any licensed operator

2. What is the approximate bandwidth of AM fast-scan TV transmissions?

A. More than 10 MHz

B. About 6 MHz

C. About 3 MHz

D. About 1 MHz

3. Why do most solid-state transmitters reduce output power as SWR increases beyond a certain level?

A. To protect the output amplifier transistors

B. To comply with FCC rules on spectral purity

C. Because power supplies cannot supply enough current at high SWR

D. To lower the SWR on the transmission line

4. What is the approximate bandwidth required to transmit a CW signal?

A. 2.4 kHz

B. 150 Hz

C. 1000 Hz

D. 15 kHz

5. What should you do before calling CQ?

A. Listen first to be sure that no one else is using the frequency

B. Ask if the frequency is in use

C. Make sure you are authorized to use that frequency

D. All these choices are correct

6. What is the approximate bandwidth of a VHF repeater FM voice signal?

A. Less than 500 Hz

B. About 150 kHz

C. Between 10 and 15 kHz

D. Between 50 and 125 kHz

SAMPLE

7. What is meant by "repeater offset"?

A. The difference between a repeater's transmit and receive frequencies

B. The repeater has a time delay to prevent interference

C. The repeater station identification is done on a separate frequency

D. The number of simultaneous transmit frequencies used by a repeater

8. How can you safely measure high voltage with a multimeter?

A. Use standard probes

B. Ensure proper insulation and lead ratings

C. Measure in a wet environment

D. Use it without safety gloves

9. Which term describes the ability of a receiver to discriminate between multiple signals?

A. Discrimination ratio

B. Sensitivity

C. Selectivity

D. Harmonic distortion

10. What formula is used to calculate resistance in a circuit?

A. R = E X I

B. R = E / I

C. R = E + I

D. R = E - I

SAMPLE

Answers

SAMPLE

1. A
2. B
3. A
4. B
5. D
6. C
7. A
8. B
9. C
10. B

SAMPLE

Explanations

SAMPLE

1. Who must designate the station control operator?

A. The station licensee

B. The FCC

C. The frequency coordinator

D. Any licensed operator

The station control operator is designated by the station licensee. This role is critical as the control operator is responsible for ensuring that the station operates in compliance with the regulations set forth by the Federal Communications Commission (FCC). The licensee, who holds the legal authority for the station, must ensure that someone is in charge of its operation, particularly regarding adherence to operational rules, frequency use, and overall station management. The licensee is typically the individual or entity that holds the station license and is responsible for the station's compliance with all relevant laws and regulations. This designation is necessary to ensure accountability and proper management of the station's activities, particularly in terms of technical operation and content broadcasting. Other roles, such as a frequency coordinator, do not have the authority to designate control operators, as their job typically involves coordinating frequency use among multiple stations to prevent interference. Similarly, the FCC has regulatory oversight but does not appoint control operators for individual stations. Any licensed operator may be capable of acting as a control operator, but ultimately, it is the licensee's responsibility to designate the individual fulfilling that role.

2. What is the approximate bandwidth of AM fast-scan TV transmissions?

A. More than 10 MHz

B. About 6 MHz

C. About 3 MHz

D. About 1 MHz

The approximate bandwidth of AM fast-scan TV transmissions is about 6 MHz. This bandwidth is necessary to accommodate the video signal, which requires a certain amount of frequency range to accurately reproduce the quality of the images being transmitted. In fast-scan television, which includes standard formats like NTSC in the United States, there are specific requirements for bandwidth to ensure that the image and sound are transmitted clearly without significant loss of quality. This 6 MHz bandwidth allows for adequate transmission of the video information, including the luminance and chrominance signals, while also providing space for the audio component. Using less bandwidth could result in poor image quality, such as graininess or lack of detail, which is critical for effective television transmission. Thus, understanding this bandwidth's role is essential for anyone involved in amateur radio and television transmission practices.

SAMPLE

3. Why do most solid-state transmitters reduce output power as SWR increases beyond a certain level?

A. To protect the output amplifier transistors

B. To comply with FCC rules on spectral purity

C. Because power supplies cannot supply enough current at high SWR

D. To lower the SWR on the transmission line

Most solid-state transmitters reduce output power when the Standing Wave Ratio (SWR) increases beyond a certain level primarily to protect the output amplifier transistors. When the SWR is high, it indicates that there is a significant mismatch between the transmitter's output and the antenna system. This mismatch can lead to increased voltage standing waves, which can result in excessive reflected power. The output amplifier transistors are designed to operate within specific voltage and current limits. High SWR conditions can cause the transistors to overheat or become damaged if too much reflected power is delivered back to them. By automatically reducing the output power in response to rising SWR, the transmitter helps ensure that the transistors remain within safe operational parameters, thereby extending their lifespan and maintaining the reliability of the transmitter itself. This protective measure is vital in solid-state designs, as they are often more sensitive to such conditions compared to older vacuum tube designs. It is also worth noting that while there are reasons related to compliance and performance, the primary concern with increased SWR is often about protecting the hardware.

4. What is the approximate bandwidth required to transmit a CW signal?

A. 2.4 kHz

B. 150 Hz

C. 1000 Hz

D. 15 kHz

The correct choice reflects that Continuous Wave (CW) signals require a relatively narrow bandwidth. Typically, the approximate bandwidth needed to transmit a CW signal is around 150 Hz. This is because a CW signal produces keying tones that are generally not wide, allowing them to be efficiently transmitted over radio frequencies with minimal interference and distortion. CW signals are used primarily in Morse code communications, which is a form of digital communication, and their frequency characteristics are well-suited to amateur radio practices. Given the limited frequency variation in a CW signal, the bandwidth remains low, typically around 150 Hz, which is optimal for clear transmission over long distances while maintaining the integrity of the signal. The other options suggest much wider bandwidth requirements, which are unnecessary for CW signals, making them less accurate in representing the actual bandwidth requirements for this type of transmission.

SAMPLE

5. What should you do before calling CQ?

A. Listen first to be sure that no one else is using the frequency

B. Ask if the frequency is in use

C. Make sure you are authorized to use that frequency

D. All these choices are correct

Before calling CQ, it is essential to follow proper protocol to ensure that you are operating correctly and considerately within the amateur radio community. Listening first to the frequency allows you to determine if someone else is already using the channel, thereby avoiding interference and maintaining good operating practices. It's also important to ask if the frequency is in use, particularly if you suspect that someone might be using it, as this can encourage courteous interactions among operators. Additionally, verifying that you are authorized to use a specific frequency is crucial, as each amateur radio operator must adhere to regulations governing their license class, including the bands they may operate on. By confirming your authorization, you ensure compliance with laws and regulations that govern amateur radio operation. Together, these precautions foster a respectful environment on the airwaves and help uphold the integrity of amateur radio as a service. Hence, all choices presented encompass essential steps to take before making a CQ call, solidifying that they are collectively the correct response.

6. What is the approximate bandwidth of a VHF repeater FM voice signal?

A. Less than 500 Hz

B. About 150 kHz

C. Between 10 and 15 kHz

D. Between 50 and 125 kHz

The approximate bandwidth of a VHF repeater FM voice signal is typically between 10 and 15 kHz. This bandwidth is determined by the modulation characteristics of frequency modulation (FM) used for voice communications. In FM, the bandwidth is primarily influenced by the modulation index, which is determined by the frequency deviation and the highest frequency of the audio signal being transmitted. For standard FM voice communications, the typical frequency deviation is about ±5 kHz, and considering the audio signal's frequency range (which generally extends to about 3 kHz for voice), this results in an overall bandwidth of around 10 to 15 kHz. This bandwidth allows for clear voice transmission while minimizing interference with adjacent channels. Therefore, the value given correctly aligns with the practical requirements for FM voice communications in the VHF band, enabling reliable and efficient communication.

7. What is meant by "repeater offset"?

A. The difference between a repeater's transmit and receive frequencies

B. The repeater has a time delay to prevent interference

C. The repeater station identification is done on a separate frequency

D. The number of simultaneous transmit frequencies used by a repeater

"Repeater offset" refers to the difference between a repeater's transmit frequency and its receive frequency. In amateur radio, repeaters are used to extend the range of communication by receiving a signal on one frequency and then retransmitting it on another. The offset is typically necessary because it allows for the simultaneous transmission and reception of signals without causing interference to the users of the repeater. For example, a common offset might be set at 600 kHz, meaning if the repeater is set to receive a signal on a frequency of 144.390 MHz, it would retransmit that signal on 144.990 MHz. This specific frequency separation is crucial in avoiding overlap with the incoming signal and allows multiple users to utilize the same repeater without disruptions in communication. The concept of a repeater offset is fundamental to understanding how repeaters operate in the amateur radio frequency spectrum.

EXAMPLE

8. How can you safely measure high voltage with a multimeter?

A. Use standard probes

B. Ensure proper insulation and lead ratings

C. Measure in a wet environment

D. Use it without safety gloves

Using a multimeter to measure high voltage requires special care to ensure safety and accuracy, which is why ensuring proper insulation and lead ratings is the best practice in this scenario. High voltage can pose significant risks, including electric shock and damage to the measuring instrument if the probes and leads are not rated for the voltage being measured. Proper insulation helps to prevent accidental contact with live parts, while using leads that meet the appropriate voltage rating ensures they can handle the electrical stress without breaking down or causing a short circuit. Multimeters often come with different types of probes, some of which are specifically designed for high voltage use, and using those appropriate for the task is critical for safety. In contrast, standard probes may not be equipped to safely handle high voltage, which could lead to hazardous situations. Measuring in a wet environment increases the risk of conductive pathways that can lead to electric shock, and manipulating high voltage without safety gloves greatly increases the danger of accidental contact. Therefore, precautionary measures must always be taken when working with high voltage to maintain safety and accuracy during measurements.

9. Which term describes the ability of a receiver to discriminate between multiple signals?

A. Discrimination ratio

B. Sensitivity

C. Selectivity

D. Harmonic distortion

The term that describes the ability of a receiver to discriminate between multiple signals is selectivity. Selectivity refers to a receiver's ability to isolate and process a specific signal of interest from other signals that are operating at the same or similar frequencies. High selectivity allows a receiver to effectively differentiate between closely spaced channels or signals, ensuring that it can receive the intended transmission without interference from neighboring transmissions. In contrast, sensitivity relates to the minimum signal strength that a receiver can detect; this does not directly imply discrimination between signals. The discrimination ratio, while important in evaluating the quality of a receiver, typically refers to the ability to differentiate between the desired signal and unwanted noise or interference rather than between multiple signals directly. Harmonic distortion generally pertains to the distortion of a signal caused by the nonlinearities in the system and is not associated with the receiver's ability to discriminate between signals.

10. What formula is used to calculate resistance in a circuit?

A. R = E X I

B. R = E / I

C. R = E + I

D. R = E - I

The formula used to calculate resistance in a circuit is derived from Ohm's Law, which states that the voltage (E) across a conductor is equal to the current (I) flowing through it multiplied by the resistance (R) of the conductor. This relationship can be expressed mathematically as: $$E = I \times R$$ To isolate resistance (R), you can rearrange the equation by dividing both sides by the current (I). This gives: $$R = \frac{E}{I}$$ This formula indicates that resistance is equal to the voltage across a component divided by the current flowing through it. It highlights how voltage and current interact in a circuit to define resistance. Understanding this fundamental relationship is essential for analyzing and designing electrical circuits.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://amateurtechnician.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE