AVIATION INSTITUTE OF MAINTENANCE (AIM) BLOCK 2 PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://aimblock2.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which of the following statements about the AN8-12 bolt is true?

A. It is a metric bolt

B. It has a length of 2 inches

C. It uses metric threads

D. It has a diameter of 1/2 inch and length of 1 1/4 inch

2. What safety steps should be taken before performing electrical work on an aircraft to prevent shock or damage?

A. Wear insulated gloves.

B. Turn off the battery and resume work.

C. Work energized with precautions.

D. Disconnect power, lockout/tagout if available, verify de-energized with a tester, and ground the work area.

3. What is the purpose of a circuit breaker in an aircraft electrical system?

A. To regulate voltage to a constant level.

B. To filter electrical noise.

C. To protect electrical circuits from overload by interrupting current when it exceeds the rating.

D. To convert AC to DC.

4. What is the primary purpose of normalizing a part after welding?

A. To relieve internal stresses developed with the base metal

B. To increase hardness

C. To improve surface finish

D. To reduce weight

5. What is the diameter and length of an AN8-12 bolt?

A. 1/2 inch in diameter, 1 1/4 inch in length

B. 1/2 inch in diameter, 1 inch in length

C. 5/16 inch in diameter, 1 1/4 inch in length

D. 3/4 inch in diameter, 1 1/2 inch in length

SAMPLE

6. Which action is the most effective safety measure to prevent accidental energizing of a circuit during maintenance?

A. Ground the work area.

B. Lockout/tagout if available.

C. Disable the main battery only.

D. Work with the circuit energized but insulated.

7. What is the purpose of a water break test?

A. To make certain that the bare metal surface is thoroughly clean

B. To determine coating thickness

C. To assess corrosion resistance of paint

D. To locate pinhole leaks

8. What is the term for the lifting or flaking of metal surfaces due to delamination of grain boundaries from corrosion products?

A. Exfoliation

B. Pitting

C. Spalling

D. Erosion

9. After sealant application on an aluminum wing skin, which aspects should be inspected?

A. Only cracks

B. Only corrosion

C. Cracks, corrosion, and bonding integrity

D. Only bonding integrity

10. What does ESD stand for, and what measures are used during maintenance to prevent it?

A. Electrostatic discharge; use anti-static wrist straps, mats, grounding before handling components.

B. Electrical surge disposal; use insulated gloves.

C. Electrostatic device shielding; use rubber mats only.

D. Emergency static detection; use grounding clamp only.

SAMPLE

Answers

SAMPLE

1. D
2. D
3. C
4. A
5. A
6. B
7. A
8. A
9. C
10. A

SAMPLE

Explanations

SAMPLE

1. Which of the following statements about the AN8-12 bolt is true?

A. It is a metric bolt

B. It has a length of 2 inches

C. It uses metric threads

D. It has a diameter of 1/2 inch and length of 1 1/4 inch

In aviation hardware, AN bolts are specified in imperial measurements. The designation AN8 denotes a bolt with a 1/2 inch diameter, and the size listed for this particular bolt corresponds to a length of 1-1/4 inches. It uses standard imperial threads, not metric. So the statement describing a 1/2 inch diameter and 1-1/4 inch length matches the actual AN8-12 size, while the others imply metric sizing or a different length.

2. What safety steps should be taken before performing electrical work on an aircraft to prevent shock or damage?

A. Wear insulated gloves.

B. Turn off the battery and resume work.

C. Work energized with precautions.

D. Disconnect power, lockout/tagout if available, verify de-energized with a tester, and ground the work area.

Before electrical work, the key safety concept is to completely remove energy and prevent any re-energization, while giving any stored energy a safe path to discharge. Disconnecting power and applying lockout/tagout if available stops current flow and prevents someone from re-energizing the system while you work. Verifying de-energized with a tester confirms there's zero voltage present and no stored energy to contend with. Grounding the work area provides a safe path for any residual charge to dissipate, reducing the risk of shock and protecting components from static or stray currents. This combination addresses both the immediate shock hazard and the danger from stored or capacitive energy. Wearing insulated gloves helps personal protection but does not guarantee that all energy sources are isolated; turning off just one power source might leave other sources or stored energy active; and working energized with precautions still carries significant risk.

3. What is the purpose of a circuit breaker in an aircraft electrical system?

A. To regulate voltage to a constant level.

B. To filter electrical noise.

C. To protect electrical circuits from overload by interrupting current when it exceeds the rating.

D. To convert AC to DC.

Circuit breakers protect aircraft electrical circuits by interrupting current when the load tries to draw more than the circuit is designed to carry. This high-current condition can result from faults or short circuits, causing overheating and potential damage or fire. By opening the circuit, the breaker stops the excess current and helps prevent insulation damage and further faults, and it can be reset after the fault is cleared so the system can be re-energized safely. This function is different from regulating voltage, which is done by voltage regulators; from filtering electrical noise, which is handled by filters; and from converting AC to DC, which is done by rectifiers. So the best description is that a circuit breaker interrupts current to protect circuits from overload.

SAMPLE

4. What is the primary purpose of normalizing a part after welding?

A. To relieve internal stresses developed with the base metal

B. To increase hardness

C. To improve surface finish

D. To reduce weight

Normalizing after welding is about managing the stresses introduced by welding and refining the metal's structure. When you weld, the weld metal and surrounding base metal heat and cool at different rates, leaving residual internal stresses and a coarser grain in the heat-affected zone. Heating the part above the transformation temperature and letting it cool in air produces a finer, more uniform grain structure and relieves these stresses. The result is improved toughness, reduced distortion, and lower risk of cracking in service. This isn't primarily about increasing hardness, improving surface finish, or reducing weight, which are not the main goals of normalizing.

5. What is the diameter and length of an AN8-12 bolt?

A. 1/2 inch in diameter, 1 1/4 inch in length

B. 1/2 inch in diameter, 1 inch in length

C. 5/16 inch in diameter, 1 1/4 inch in length

D. 3/4 inch in diameter, 1 1/2 inch in length

In aviation fasteners, the designation after AN tells you the diameter, and the trailing number refers to the length from a standard chart. The diameter part, AN8, means 8 sixteenths of an inch, which is 1/2 inch. The dash-number corresponds to the length listed in the standard AN bolt tables; for AN8-12, that length is 1 1/4 inches. So an AN8-12 bolt is 1/2 inch in diameter and 1 1/4 inches long. The other options don't match the established AN bolt sizing: they would imply a different diameter or a different length for an AN8-12 bolt.

6. Which action is the most effective safety measure to prevent accidental energizing of a circuit during maintenance?

A. Ground the work area.

B. Lockout/tagout if available.

C. Disable the main battery only.

D. Work with the circuit energized but insulated.

Preventing accidental energizing during maintenance hinges on isolating the circuit from all energy sources and preventing removal of that isolation while work is done. Lockout/tagout uses a physical lock and a tag to clearly indicate a system is de-energized and to stop anyone from energizing it until the lock is removed by the person who applied it. This approach covers all energy sources—electrical, hydraulic, pneumatic, mechanical, and stored energy—so no part of the system can unexpectedly come back to life and cause harm. Grounding the area helps with shock protection but doesn't guarantee the circuit is isolated or free from stored energy. Merely disabling the main battery leaves other power sources and stored energy able to energize the circuit, and it doesn't provide a reliable lock to prevent re-energizing. Working with the circuit energized but insulated is unsafe because insulation can fail and you're exposed to unexpected energization or faults. Lockout/tagout is the most reliable method to ensure a safe maintenance environment.

SAMPLE

7. What is the purpose of a water break test?

A. To make certain that the bare metal surface is thoroughly clean

B. To determine coating thickness

C. To assess corrosion resistance of paint

D. To locate pinhole leaks

The water break test checks how clean the metal surface is before applying coating by seeing how water wets it. When the surface is free of oils, greases, and other contaminants, water spreads evenly in a smooth film. If residues remain, water beads up or breaks into droplets, signaling that cleaning is still needed. This ensures proper adhesion of the primer and coating. It isn't used to measure coating thickness, evaluate the paint's corrosion resistance, or locate leaks.

8. What is the term for the lifting or flaking of metal surfaces due to delamination of grain boundaries from corrosion products?

A. Exfoliation

B. Pitting

C. Spalling

D. Erosion

Exfoliation describes a corrosion process where corrosion products build up between the grains of a metal, pushing the grain boundaries apart and causing entire layers to lift off or peel away in sheet-like flakes. This creates a flaky, laminated surface as the outer layers delaminate from the underlying metal. It's most noted in certain alloys, like some aluminum alloys, where the swelling of corrosion products between grains drives the peeling action. Pitting is localized tiny holes from focused attack, so it doesn't involve lifting whole layers. Spalling refers to the shedding of surface chunks due to mechanical or thermal stresses, not specifically grain-boundary delamination from corrosion products. Erosion is material loss from abrasive or fluid flow impacts rather than corrosion-driven delamination.

9. After sealant application on an aluminum wing skin, which aspects should be inspected?

A. Only cracks

B. Only corrosion

C. Cracks, corrosion, and bonding integrity

D. Only bonding integrity

After sealant work on an aluminum wing skin, you must check for three interrelated failure modes: cracks, corrosion, and bonding integrity. Cracks in the skin or adjacent structures can propagate under load and send moisture behind the skin if the sealant isn't fully protecting the joint. Corrosion can develop underneath or at the edges where moisture may become trapped by imperfect sealant coverage, especially in areas near fasteners or joints. Bonding integrity is crucial because the sealant must adhere well to both surfaces; if it delaminates, voids form, or there are wrinkles or lumps, moisture can penetrate and the joint can fail. Sealant is intended to seal joints against moisture and environmental exposure, so neglecting any of these aspects can allow hidden problems to grow. While a crack alone or corrosion alone might seem manageable, they often coexist with bonding issues or indicate a broader problem with the sealant's performance. Therefore, a thorough inspection should assess cracks, any signs of corrosion, and the bond between the sealant and the surfaces to ensure the joint remains moisture-tight and structurally sound.

SAMPLE

10. What does ESD stand for, and what measures are used during maintenance to prevent it?

A. Electrostatic discharge; use anti-static wrist straps, mats, grounding before handling components.

B. Electrical surge disposal; use insulated gloves.

C. Electrostatic device shielding; use rubber mats only.

D. Emergency static detection; use grounding clamp only.

Electrostatic discharge is the sudden flow of electricity between two objects at different electrical potentials. In maintenance, a tiny static charge on you or your workstation can zap a sensitive electronic component, causing damage that isn't always visible. The best way to prevent this is to create a controlled path for any charge to ground and keep components on a safe, conductive surface. That means using an anti-static wrist strap plugged into a grounded point, placing components and tools on an anti-static mat, and ensuring everything you touch or handle is grounded before you start work. These measures work together: the wrist strap gives your body a direct discharge path, the mat provides a grounded surface for parts, and grounding before handling eliminates potential differences before contact. Other options miss key elements. They don't address grounding and protective measures together, or they use terms that don't reflect standard ESD practices, so they wouldn't reliably prevent static damage.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://aimblock2.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE