BIOENVIRONMENTAL ENGINEERING (BEE) BLOCK 9 PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://beeblock9.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which description best captures the risk factors for natural bathing areas?

A. Only water temperature

B. Depth and bottom type

C. Proximity to pollution sources, level of bathing area use, historical water quality data, and occurrence of sewage spills or other pollution events

D. Water color alone

2. Which action is performed on all new components before assembling the main during disinfection?

A. Swab the interior of all new components with a one-percent hypochlorite solution

B. Rinse with clean water only

C. Apply paint to components

D. Expose to sunlight for 24 hours

3. Which statement describes the use of high-test calcium hypochlorite in field water treatment?

A. It is never used in field water treatment.

B. It is 100% chlorine and used in pools.

C. It is used only for disinfection of wastewater.

D. It is a chlorination method containing 65-70% chlorine used for field water treatment.

4. Which of the following is a Tier 2 violation?

A. Monitoring and testing procedure violations

B. Waterborne disease outbreak

C. Fecal coliform MCL violation

D. Excessive turbidity

5. Exposing water to intense UV will kill pathogenic bacteria and viruses; this is an example of which disinfect method?

A. Bleach

B. Heat

C. Ozone

D. Radiation

SAMPLE

6. What is important in preservation of samples with volatile organic compounds (VOCs), and is done by collecting sample in a completely filled container?

A. Temperature control

B. Nitrogen flushing

C. Light exposure

D. Zero headspace

7. Which chlorination method is the most effective for field water treatment and preferred for large-scale systems, with 65-70% chlorine?

A. Chlorine Gas

B. Bleach

C. Ozone

D. High-test calcium hypochlorite

8. Which ESAM Plan component involves identifying the laboratory used for analyses and the required certification?

A. A Current Map

B. Identification of Support Laboratory and the Appropriate Certification

C. Locally Developed Procedures for Drinking Water Surveillance Program

D. Annual sampling schedule

9. BE will sample aircraft watering points for bacteriological analysis at what frequency?

A. Weekly

B. Monthly

C. Quarterly

D. Annually

10. What are two zones associated with ground water?

A. Zone of Water Table, Zone of Capillary Rise

B. Zone of Saturation, Zone of Infiltration

C. Zone of Aeration (Vadose) [unsaturated], Zone of Water Table

D. Zone of Aeration (Vadose) [unsaturated], Zone of Saturation

SAMPLE

Answers

SAMPLE

1. C
2. A
3. D
4. A
5. D
6. D
7. D
8. B
9. B
10. D

SAMPLE

Explanations

SAMPLE

1. Which description best captures the risk factors for natural bathing areas?

A. Only water temperature

B. Depth and bottom type

C. Proximity to pollution sources, level of bathing area use, historical water quality data, and occurrence of sewage spills or other pollution events

D. Water color alone

Assessing risk in natural bathing areas requires looking at multiple factors that influence how likely contaminants are to reach and affect swimmers, and how exposure might occur. Proximity to pollution sources matters because contaminants can enter the water from nearby sewage outfalls, agricultural runoff, or urban drainage. The level of bathing area use matters because more people can mean more opportunities for contamination and more exposure to any contaminants present, as well as the need for ongoing monitoring. Historical water quality data provide a baseline to recognize typical conditions and detect anomalies, helping distinguish normal variation from problems that warrant caution. The occurrence of sewage spills or other pollution events is a direct indicator of elevated risk, signaling that recent samples may not reflect typical conditions and that advisories or closures may be necessary. Relying on a single factor like water temperature doesn't capture where contaminants come from or how they might affect exposure. Depth and bottom type influence physical safety and habitat, not the contamination risk itself. Water color can be misleading, since natural coloration or sediment can mimic pollution or mask it. Together, the four factors give a practical, comprehensive view of risk that supports better decisions about when and where bathing is safe.

2. Which action is performed on all new components before assembling the main during disinfection?

A. Swab the interior of all new components with a one-percent hypochlorite solution

B. Rinse with clean water only

C. Apply paint to components

D. Expose to sunlight for 24 hours

Disinfection before assembling system components depends on directly treating interior surfaces so any potential contaminants are eliminated before they come together. Swabbing the inside with a one-percent hypochlorite solution targets microbes that may be present on those surfaces, providing broad spectrum effectiveness and a practical, quick-action disinfection step. This helps prevent introducing bacteria, viruses, or spores into the main unit when assembly occurs. Rinsing with clean water alone wouldn't reliably kill microbes. Painting would introduce contaminants rather than disinfect, and exposing components to sunlight for 24 hours isn't a dependable or sufficient disinfection method due to variable UV exposure and inadequate contact with all surfaces.

SAMPLE

3. Which statement describes the use of high-test calcium hypochlorite in field water treatment?

A. It is never used in field water treatment.

B. It is 100% chlorine and used in pools.

C. It is used only for disinfection of wastewater.

D. It is a chlorination method containing 65-70% chlorine used for field water treatment.

High-test calcium hypochlorite is a solid form of chlorine with a high available chlorine content, typically around 65–70%. In field water treatment, it acts as a chlorination method by releasing hypochlorous acid when dissolved, providing rapid and effective disinfection of water in remote or on-site settings. It's not 100% chlorine, and it's not limited to pools or wastewater only; its high chlorine content and solid, portable form make it well-suited for field disinfection where quick dosing and storage stability are important. That combination is why the description of a chlorination method containing 65–70% chlorine used for field water treatment is the best fit.

4. Which of the following is a Tier 2 violation?

A. Monitoring and testing procedure violations

B. Waterborne disease outbreak

C. Fecal coliform MCL violation

D. Excessive turbidity

Tiered public notification is used to categorize drinking water violations by urgency. Tier 2 violations are nonserious noncompliance issues that don't pose an immediate health risk but still require public notice within a set timeframe. Monitoring and testing procedure violations fit this category because failing to perform required monitoring or testing undermines compliance, yet by itself does not create an immediate health hazard for consumers. In contrast, a waterborne disease outbreak is an actual health event caused by the water supply, which is an immediate risk and would be Tier 1. A fecal coliform MCL violation signals contamination above the allowed limit and is taken seriously, typically treated as a Tier 2 public notice issue unless additional risk factors change the category. Excessive turbidity indicates process failures in filtration and can be serious, but the clear, established example of a Tier 2 violation here is the monitoring/testing procedure lapse.

5. Exposing water to intense UV will kill pathogenic bacteria and viruses; this is an example of which disinfect method?

A. Bleach

B. Heat

C. Ozone

D. Radiation

The main idea here is that UV exposure is a disinfection method that relies on radiation. Ultraviolet light, especially UV-C, penetrates microbial cells and damages their DNA or RNA, producing changes that prevent replication. Because the microorganisms can no longer reproduce, they are effectively inactivated, which is why water treated with UV is considered disinfected. This is a physical form of disinfection and does not introduce chemicals into the water, unlike bleach or ozone, and it is not based on heating. It's important to note UV works best with clear water, since turbidity can block the light, and it doesn't leave a residual disinfectant in the water.

SAMPLE

6. What is important in preservation of samples with volatile organic compounds (VOCs), and is done by collecting sample in a completely filled container?

A. Temperature control

B. Nitrogen flushing

C. Light exposure

D. Zero headspace

VOCs are highly volatile, so preserving them means preventing loss to the surrounding air. Collecting the sample in a completely filled container removes any air gap, leaving no headspace for VOCs to evaporate into. This directly minimizes volatilization losses during collection, transport, and storage, keeping the sample's composition intact until analysis. While temperature control or flushing with inert gas can further aid preservation, the act of having zero headspace is the most direct way to prevent VOC loss at the moment of collection.

7. Which chlorination method is the most effective for field water treatment and preferred for large-scale systems, with 65-70% chlorine?

A. Chlorine Gas

B. Bleach

C. Ozone

D. High-test calcium hypochlorite

In field water treatment and large-scale systems, you want a disinfectant form that combines high available chlorine with practical handling, storage, and dosing. High-test calcium hypochlorite fits that need because it contains about 65–70% available chlorine in a dry solid. That high concentration lets you dose effectively with relatively small, simple feeders and ships and stores more safely and easily than gases or dilute liquids. Chlorine gas, while very effective, requires specialized equipment, gas handling safety, and robust leak control, which is impractical for widespread field operations. Household bleach is convenient but usually only around 5–8% chlorine, so you'd need huge volumes to reach the same disinfection dose, plus it can degrade with storage. Ozone isn't a chlorine-based disinfectant at all and needs an expensive, complex generator with its own set of operating demands. So, the solid high-test calcium hypochlorite provides the best balance for large-scale field use with the specified chlorine content.

SAMPLE

8. Which ESAM Plan component involves identifying the laboratory used for analyses and the required certification?

A. A Current Map

B. Identification of Support Laboratory and the Appropriate Certification

C. Locally Developed Procedures for Drinking Water Surveillance Program

D. Annual sampling schedule

The main concept is ensuring the ESAM Plan specifies which laboratory will perform analyses and what certifications that lab must hold. In environmental analysis, data quality hinges on using a properly credentialed lab, so the plan must clearly identify the support laboratory and document the required certifications (such as accreditation, proficiency testing, and staff qualifications). This guarantees that analyses are performed to accepted standards, results are defensible, and regulatory or programmatic requirements are met. This focus is distinct from other plan components. A current map relates to locations or infrastructure, not who does the lab work. Locally developed procedures for drinking water surveillance define methods and procedures, not the identity or credentials of the lab. An annual sampling schedule concerns timing of sampling, not laboratory capability or certification.

9. BE will sample aircraft watering points for bacteriological analysis at what frequency?

A. Weekly

B. Monthly

C. Quarterly

D. Annually

Regular monitoring of aircraft potable water systems for bacterial contamination is used to ensure safety by detecting microbes before they can reach passengers or crew. The frequency needs to be enough to catch changes in water quality without overburdening operations. Monthly sampling provides ongoing surveillance to identify any contamination trends promptly and to trigger corrective actions in a timely manner. Weekly sampling would be unnecessarily frequent for routine systems and can strain resources, while quarterly or annual sampling risks missing intermittent contamination and delaying response. Monthly testing thus offers a practical balance, maintaining safety and compliance with standard potable water surveillance practices.

10. What are two zones associated with ground water?

A. Zone of Water Table, Zone of Capillary Rise

B. Zone of Saturation, Zone of Infiltration

C. Zone of Aeration (Vadose) [unsaturated], Zone of Water Table

D. Zone of Aeration (Vadose) [unsaturated], Zone of Saturation

Groundwater resides in the portion of the subsurface that is fully saturated with water—the zone of saturation. Above this is the vadose or unsaturated zone, where the pores contain air plus some water. The water table marks the upper boundary of the saturated zone. So the two zones associated with groundwater are the unsaturated vadose zone and the saturated zone. Other terms like the water table describe the boundary, while capillary rise and infiltration describe processes within those zones rather than distinct groundwater zones.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://beeblock9.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE