CERTIFICATION BOARD FOR STERILE PROCESSING AND DISTRIBUTION (CBSPD) STERILE PROCESSING TECHNICIAN PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://cbspd-technician.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. How should loads that include implantable devices be treated regarding biological indicators?

A. They do not need monitoring

B. Only monitored if they have been modified

C. Monitored with a biological indicator

D. Monitored with a chemical indicator

2. Which method of sterilization is commonly used for sterilizing liquids?

A. Ethylene oxide

B. Hydrogen peroxide gas plasma

C. Gravity steam

D. Dry heat

3. Which of the following is a wet sterilization system for unwrapped items?

A. Hydrogen peroxide

B. Peracetic acid

C. Ethylene oxide

D. Superheated steam

4. Which option is NOT considered a specialty cart?

A. Exchange

B. Procedure cart

C. IV cart

D. Surgical cart

5. The efficacy of a disinfectant is dependent on what key factor?

A. Concentration

B. Temperature

C. Whether it remains wet for the stated amount of time

D. Type of microorganisms present

6. Which option BEST describes a prion?

A. A Virus

B. An Abnormal Protein

C. A Bacterial Spore

D. A Living Cell

SAMPLE

7. Which item does NOT need to be checked before releasing an item for a sterile supply order?

A. Expiration date

B. Cost effectiveness data

C. Item integrity

D. Quantity on hand

8. A small cut is noted in the cord of an IV Pump that has been disinfected. Which of the following steps should the CS/SPD technician take?

A. Send to the biomedical engineering department

B. Dispose of immediately

C. Re-disinfect the pump

D. Use for patient care

9. Which sterilization method works with tyvek pouches and certain rigid sterilization containers?

A. Steam

B. Ethylene Oxide

C. Low-Temperature Gas Plasma (LTGP)

D. Dry heat

10. What color do Gram-Negative microorganisms stain?

A. Blue or Purple

B. Red or Pink

C. Yellow or Orange

D. Green or Brown

SAMPLE

Answers

SAMPLE

1. C
2. C
3. B
4. A
5. C
6. B
7. B
8. A
9. C
10. B

SAMPLE

Explanations

SAMPLE

1. How should loads that include implantable devices be treated regarding biological indicators?

A. They do not need monitoring

B. Only monitored if they have been modified

C. Monitored with a biological indicator

D. Monitored with a chemical indicator

Implantable devices require careful consideration during the sterilization process because their safety and efficacy depend on effective sterilization. The use of a biological indicator is crucial when processing loads that contain these devices. Biological indicators specifically assess the effectiveness of the sterilization process by using living microorganisms that are more resistant to sterilization methods than the organisms typically found on surgical instruments and devices. By incorporating a biological indicator into the load, the sterilization process's ability to destroy these resistant microorganisms can be verified. This is essential for implantable devices, as they are introduced into sterile tissue and can pose a significant risk of infection if not adequately sterilized. The monitoring ensures that the sterilization cycle was sufficient to eliminate any potential microbial contamination, providing confidence in the safety of the implantable devices. In this context, other monitoring methods, such as chemical indicators or the notion that no monitoring is needed, do not provide the same level of assurance regarding the actual microbial load reduction. Chemical indicators may indicate that a sterilization cycle occurred but do not confirm whether the sterilization was effective against more resistant organisms. Therefore, monitoring loads including implantable devices with a biological indicator is a critical practice to ensure their safety before use in medical procedures.

2. Which method of sterilization is commonly used for sterilizing liquids?

A. Ethylene oxide

B. Hydrogen peroxide gas plasma

C. Gravity steam

D. Dry heat

The method of sterilization commonly used for sterilizing liquids is gravity steam. Steam sterilization is particularly effective for items that can withstand high temperatures and moisture, making it suitable for sterilizing many types of liquid solutions, such as culture media and intravenous fluids. The steam's ability to penetrate the liquid ensures that all microorganisms are effectively eradicated, achieving a high level of sterility. When using gravity steam sterilization, the process relies on the natural flow of steam, which displaces air in the sterilization chamber. As the steam condenses on the surfaces of the liquid and container, it maintains a temperature and pressure that is sufficient to kill bacteria, viruses, and spores. Furthermore, steam sterilization doesn't leave any residues that could be harmful, which is crucial when considering the purity of liquid solutions. The other methods mentioned may not be suitable for liquids, especially in scenarios where moisture can be detrimental or where the concern is to avoid chemical residues. Ethylene oxide is a gas typically used for heat-sensitive items and is not ideal for liquids. Hydrogen peroxide gas plasma is also primarily used for items that cannot withstand traditional steam or moisture but does not effectively deliver sterilization into a liquid medium. Dry heat requires prolonged exposure times and is better suited for solid instruments

SAMPLE

3. Which of the following is a wet sterilization system for unwrapped items?

A. Hydrogen peroxide

B. Peracetic acid

C. Ethylene oxide

D. Superheated steam

Peracetic acid is a wet sterilization system that is particularly effective for unwrapped items. It works through a combination of peracetic acid and water, providing both an antimicrobial effect and the ability to penetrate surfaces effectively. This system is valued for its rapid action and ability to sterilize in a short amount of time, typically at lower temperatures than traditional steam sterilization, making it suitable for heat-sensitive materials. Hydrogen peroxide, while effective for sterilizing certain materials, is typically used in vapor form and doesn't function well as a wet sterilization system for unwrapped items. Ethylene oxide is a gas that is used for sterilizing heat-sensitive items but requires a more complex process that involves sealing items in a chamber rather than applying wet conditions. Superheated steam, while a form of sterilization, is not used for unwrapped items as it requires containment and specific conditions to achieve sterilization. Thus, peracetic acid stands out as the correct answer in this context for wet sterilization of unwrapped items.

4. Which option is NOT considered a specialty cart?

A. Exchange

B. Procedure cart

C. IV cart

D. Surgical cart

The option that is not considered a specialty cart is the exchange cart. An exchange cart is primarily used for the purpose of exchanging used items for clean, sterile ones and does not represent a specialized function like the other carts listed. Specialty carts are designed for specific procedures or functions, enhancing efficiency and organization within a sterile processing environment. Procedure carts are equipped with instruments and supplies tailored for particular surgical procedures, making them essential for maintaining workflow in the operating room. IV carts are specifically designed to hold intravenous supplies and medications, ensuring that healthcare providers have the necessary tools readily available for IV administration. Surgical carts contain instruments and supplies specifically for surgical procedures, facilitating quicker access for surgical teams. In contrast, the exchange cart serves a more generalized role in inventory management rather than specialization in a particular area of sterile processing, marking it as the option that does not fit the definition of a specialty cart.

SAMPLE

5. The efficacy of a disinfectant is dependent on what key factor?

A. Concentration

B. Temperature

C. Whether it remains wet for the stated amount of time

D. Type of microorganisms present

The correct answer highlights the critical role of contact time in the effectiveness of a disinfectant. The duration for which a disinfectant remains in contact with a surface or item is crucial to ensure that it effectively kills or inactivates the microorganisms present. If a disinfectant does not stay wet for the required amount of time specified by the manufacturer, it is likely that it will not achieve the desired level of disinfection, regardless of the concentration or type of microorganisms. While concentration, temperature, and the type of microorganisms are important factors, they all depend on the contact time to achieve effective disinfection. For example, even a highly concentrated disinfectant may fail if it evaporates quickly and does not stay wet long enough to exert its full antimicrobial activity. Similarly, higher temperatures can enhance the efficacy of certain disinfectants, but again, if the disinfectant dries too quickly, it won't be effective. Therefore, ensuring that a disinfectant remains wet for the recommended amount of time is fundamental to achieving successful disinfection outcomes.

6. Which option BEST describes a prion?

A. A Virus

B. An Abnormal Protein

C. A Bacterial Spore

D. A Living Cell

A prion is best described as an abnormal protein. Prions are unique pathogens that differ from viruses, bacteria, or living cells, as they do not contain nucleic acids (DNA or RNA). Instead, they are misfolded forms of normal cellular proteins that can induce other proteins to also misfold, leading to the aggregation of proteins in neural tissues. This misfolding process results in neurodegenerative diseases, such as Creutzfeldt-Jakob disease and mad cow disease. Understanding prions is essential in sterile processing and infection control, as they are remarkably resistant to conventional methods of sterilization, which complicates their control within healthcare settings. Their existence challenges traditional concepts of infectious agents, emphasizing the need for awareness of various types of pathogens and their properties.

7. Which item does NOT need to be checked before releasing an item for a sterile supply order?

A. Expiration date

B. Cost effectiveness data

C. Item integrity

D. Quantity on hand

When releasing an item for a sterile supply order, it's essential to ensure that the item is suitable for use in a sterile environment. This includes checking the expiration date, which confirms that the item is still safe and effective for use, ensuring the integrity of the item to guarantee that it has not been damaged, and verifying the quantity on hand to ensure that sufficient stock is available for the order. Cost effectiveness data, however, is not a practical consideration that directly impacts the safety or functionality of the item itself. While understanding cost is valuable for inventory management and budgeting purposes, it does not affect the immediate decision about whether a sterile item can be released for use. Therefore, it is not a requirement in the same way as the other factors, making it the correct choice for what does not need to be checked before releasing a sterile supply item.

SAMPLE

8. A small cut is noted in the cord of an IV Pump that has been disinfected. Which of the following steps should the CS/SPD technician take?

A. Send to the biomedical engineering department

B. Dispose of immediately

C. Re-disinfect the pump

D. Use for patient care

In the case of a small cut noted in the cord of an IV Pump that has already been disinfected, the appropriate action is to send the device to the biomedical engineering department. This course of action is critical because any damage to the electrical cord can pose a safety hazard, including the risk of electrical shock to both patients and healthcare staff. Biomedical engineering departments are equipped to evaluate, repair, or properly dispose of medical equipment. Disposing of the pump immediately can seem like a safe option, but it does not allow for the assessment of whether the pump can be repaired. Re-disinfecting the pump would not address the underlying safety issue posed by the damaged cord, and using the pump for patient care could endanger patient safety due to the potential for equipment malfunction. Thus, notifying biomedical engineering is the most responsible step, ensuring that the IV Pump is addressed by professionals who can either repair it or deem it unfit for use without compromising safety.

9. Which sterilization method works with tyvek pouches and certain rigid sterilization containers?

A. Steam

B. Ethylene Oxide

C. Low-Temperature Gas Plasma (LTGP)

D. Dry heat

Low-Temperature Gas Plasma (LTGP) is the correct method for sterilizing items packed in Tyvek pouches and some rigid sterilization containers. This method uses low-temperature hydrogen peroxide gas plasma to effectively sterilize heat- and moisture-sensitive medical instruments, making it suitable for materials that cannot withstand the higher temperatures of steam sterilization or dry heat. Tyvek pouches are designed specifically for use with LTGP, as the material allows the gas to penetrate effectively while maintaining the sterility of the contents. This permeability is essential for achieving a successful sterilization cycle. Other sterilization methods, while effective for various applications, do not share this compatibility. For instance, steam sterilization operates at high temperatures and may lead to the degradation of sensitive materials. Similarly, dry heat sterilization also requires elevated temperatures that can adversely affect the integrity of specific packaging materials. Ethylene oxide, while it can be used for sterilizing complex devices, may not be suitable for all types of containers or packaging, such as those made from Tyvek, without additional considerations. Thus, LTGP stands out as the ideal choice for the circumstances described in the question.

SAMPLE

10. What color do Gram-Negative microorganisms stain?

A. Blue or Purple

B. Red or Pink

C. Yellow or Orange

D. Green or Brown

Gram-negative microorganisms stain red or pink due to the structure of their cell walls. In the Gram staining process, these bacteria have a thin peptidoglycan layer surrounded by an outer membrane containing lipopolysaccharides. During the staining process, after applying the crystal violet stain, a mordant (iodine) is used to form a complex that gets trapped in the cell wall of Gram-positive bacteria, which have a thick peptidoglycan layer. When the staining process continues with alcohol or acetone, Gram-negative bacteria are unable to retain the crystal violet-iodine complex due to their thin peptidoglycan layer and the presence of the outer membrane. As a result, they are decolorized and subsequently take up the counterstain, typically safranin, which gives them the characteristic red or pink appearance. Understanding this principle helps in identifying and classifying bacteria in clinical specimens, which is crucial in the fields of microbiology and sterile processing.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://cbspd-technician.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE