CHAMPIONS RESIDENTIAL INSPECTIONS SAE PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://champresidentialinspsae.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which of the following is considered a safer alternative to Chlordane for termite treatment?

A. Termidor

B. Krypton

C. Carbaryl

D. Naled

2. What constitutes the skeleton of a house?

A. The roof

B. The foundation

C. The frame

D. The walls

3. What is the most common sign of a shower leak?

A. Mold

B. Mildew

C. Water stains

D. Cracked tiles

4. What is one potential consequence of not having errors and omissions insurance as an inspector?

A. Loss of License

B. Legal Liability

C. Increased Fees

D. Decreased Client Trust

5. In lumber terminology, what is a "board" typically classified by?

A. Thickness and width

B. Weight and structural integrity

C. Color and finish

D. Grain patterns

SAMPLE

6. Which setting should electric stove tops be energized from?

A. High to low

B. Medium to high

C. Low to medium to high

D. Low to high

7. What condition can lead to the greatest risks for termite invasion?

A. Well ventilated basements

B. Excess moisture in wood

C. Exposure to sunlight

D. Cool air currents

8. What is the required pouring method for a concrete slab across its depth?

A. In layers

B. Uniform depth

C. On a slope

D. With reinforcement

9. What is a naturally occurring radioactive gas that is undetectable by smell, sight, or taste?

A. Radon

B. Carbon monoxide

C. Uranium

D. Radium

10. What is the primary treatment for drywood termite infestation?

A. Spot treatment

B. Fumigation

C. Soil treatment

D. Direct wood injection

SAMPLE

Answers

SAMPLE

1. A
2. C
3. B
4. B
5. A
6. C
7. B
8. B
9. A
10. B

SAMPLE

Explanations

SAMPLE

1. Which of the following is considered a safer alternative to Chlordane for termite treatment?

A. Termidor

B. Krypton

C. Carbaryl

D. Naled

Termidor is recognized as a safer alternative to Chlordane for termite treatment due to its active ingredient, Fipronil, which is a more modern and targeted pesticide. Fipronil works by disrupting the central nervous system of insects, leading to their death, but it poses significantly lower risks to human health and non-target organisms compared to Chlordane, which is a persistent organochlorine compound that can accumulate in the environment and is linked to various health concerns. Termidor's effectiveness against termites combined with its reduced environmental impact makes it a preferred choice in the pest control industry. Moreover, unlike Chlordane, which has been banned in many areas due to its toxicity, Termidor is regulated and meets current safety standards, providing a balance between efficacy and safety. This makes it a reliable and responsible option for homeowners and professionals dealing with termite infestations.

2. What constitutes the skeleton of a house?

A. The roof

B. The foundation

C. The frame

D. The walls

The frame of a house is considered the skeleton because it provides the structural support necessary to hold the building together. It includes the beams, studs, and rafters that create the shape and structure of a house. Just as a skeleton supports the body and determines its shape, the frame supports the weight of the roof, floors, and walls. It also allows for the installation of plumbing, electrical systems, and insulation within the structure. The roof, foundation, and walls are indeed vital components of a house, but they do not serve the same foundational role in terms of providing the basic skeletal structure. The foundation supports the entire building and anchors it to the ground, the walls provide enclosure and separation of spaces, and the roof protects the structure from the elements. However, without a frame, the house could not maintain its structural integrity or shape, establishing why the frame is viewed as the essential skeleton.

3. What is the most common sign of a shower leak?

A. Mold

B. Mildew

C. Water stains

D. Cracked tiles

The most common sign of a shower leak is often associated with mildew. Mildew, which thrives in damp, warm environments like showers, can indicate prolonged moisture presence due to a leak. When water seeps from the plumbing or between tiles, it creates a perfect breeding ground for mildew, resulting in visible growth. While moisture can also lead to mold growth, both are manifestations of excess humidity usually stemming from leaks. However, mildew is typically more indicative of the immediate effects of water exposure, making it a frequent first sign of a leak in a shower area. Other signs, like water stains and cracked tiles, also indicate moisture issues. Water stains suggest that water has been present on a surface long enough to leave a mark, while cracked tiles may result from underlying water damage causing structural integrity loss. These signs, while important, often appear later in the sequence of effects caused by leaks, as opposed to mildew, which emerges more swiftly in response to humidity.

SAMPLE

4. What is one potential consequence of not having errors and omissions insurance as an inspector?

A. Loss of License

B. Legal Liability

C. Increased Fees

D. Decreased Client Trust

Not having errors and omissions insurance can lead to legal liability for an inspector, which is a significant risk in the real estate inspection industry. This type of insurance is designed to protect professionals from claims of negligence, errors, or omissions during their services. If an inspector makes a mistake, such as failing to identify a serious issue in a property, they could be sued by clients seeking damages. Without insurance coverage, the inspector would be personally liable for any legal fees, settlements, or judgments, potentially resulting in substantial financial hardship. While loss of license, increased fees, and decreased client trust are all valid concerns for an inspector, they primarily relate to the broader implications of professional practice rather than the direct legal ramifications that stem from not having errors and omissions insurance. Legal liability directly addresses the financial consequences and legal ramifications that arise specifically from the shortcomings in the inspector's work, making it the most relevant consequence to highlight in relation to the absence of such insurance.

5. In lumber terminology, what is a "board" typically classified by?

A. Thickness and width

B. Weight and structural integrity

C. Color and finish

D. Grain patterns

A "board" in lumber terminology is classified primarily by its thickness and width. This classification is crucial because it helps determine the board's dimensions, which directly influence its application in construction and other woodworking projects. Lumber is often specified in terms of nominal dimensions, which refers to its rough-cut size before drying and planing. For example, when a board is referred to as a "1x6," it indicates a nominal thickness of 1 inch and a width of 6 inches. Understanding the thickness and width of a board is essential for builders and woodworkers when selecting materials for specific purposes, as these dimensions affect both structural performance and aesthetic considerations. The other options involve factors that, while important in the broader context of wood use, do not define a board's basic classification. Weight and structural integrity relate to the type of wood and its treatment but are not standard parameters for classifying lumber as a board. Similarly, color, finish, and grain patterns may influence the choice of lumber for particular projects, but they are not fundamental characteristics used to categorize a board in lumber terminology.

SAMPLE

6. Which setting should electric stove tops be energized from?

A. High to low

B. Medium to high

C. Low to medium to high

D. Low to high

The correct answer is that electric stove tops should be energized from low to medium to high. This approach is necessary because it allows for better control over the cooking process, facilitating a gradual increase in temperature. Starting at a low setting gives users the flexibility to heat the stove top without risking damage to the cookware or causing food to burn. As the cooking progresses, users can adjust the temperature to medium and then high as needed, ensuring even cooking and efficiency. In contrast, beginning at a high setting could result in immediate, intense heat that can scorch food or lead to uneven cooking. The other options do not provide the same range of control or safety that starting from low to medium to high does, which is crucial for proper cooking techniques. Ultimately, this method ensures optimal performance and safety while using electric stove tops.

7. What condition can lead to the greatest risks for termite invasion?

A. Well ventilated basements

B. Excess moisture in wood

C. Exposure to sunlight

D. Cool air currents

Excess moisture in wood creates an ideal environment for termites, as these pests are attracted to damp and decaying wood. Moisture not only weakens the structural integrity of wooden materials but also promotes the growth of mold and fungi, which can further attract termites seeking out soft, deteriorating wood for nourishment. In situations where wood is consistently exposed to high humidity or water intrusion, the risk of termite infestation increases significantly. Termites thrive in such conditions, making it crucial to address any sources of excess moisture in and around a home to prevent potential damage. Other options such as well-ventilated basements, exposure to sunlight, and cool air currents typically contribute to a less favorable environment for termites. Adequate ventilation can help reduce moisture build-up, sunlight can dry out damp wood, and cool air currents can discourage the moist conditions that termites favor. This context highlights why excessive moisture in wood stands out as the primary condition that elevates the risk for termite invasion.

8. What is the required pouring method for a concrete slab across its depth?

A. In layers

B. Uniform depth

C. On a slope

D. With reinforcement

The correct answer is uniform depth. When pouring a concrete slab, it is essential to maintain a uniform depth throughout the entire area to ensure structural integrity and promote even curing. This consistency prevents weak spots that can occur if the concrete is poured in varying thicknesses, which can lead to cracking, settling, or other structural issues over time. Maintaining a uniform depth helps in achieving a consistent strength across the slab and simplifies the finishing process. It allows for better weight distribution and load-bearing capacity, which is crucial for any structures that will be supported by the slab, such as buildings or driveways. While other pouring methods may be valid in certain contexts, such as using layers for thicker sections or adding reinforcement for added strength, those approaches do not address the primary requirement for a standard concrete slab, which is a uniform thickness.

SAMPLE

9. What is a naturally occurring radioactive gas that is undetectable by smell, sight, or taste?

A. Radon

B. Carbon monoxide

C. Uranium

D. Radium

Radon is a naturally occurring radioactive gas that is produced by the decay of uranium found in soil, rock, and water. One of its critical characteristics is that it is colorless, odorless, and tasteless, making it undetectable to human senses. This invisibility is particularly concerning in residential environments where radon can accumulate, especially in enclosed spaces like basements or poorly ventilated areas. Long-term exposure to radon is linked to serious health risks, including lung cancer, making awareness and testing for radon levels essential in home inspections. The other options, while related to radioactive materials, do not share the same properties as radon. Carbon monoxide is a toxic gas produced by incomplete combustion, uranium is a heavy metal used in nuclear applications, and radium is a radioactive element but not a gas. Understanding radon's nature and health risks is vital for homeowners and inspectors alike.

10. What is the primary treatment for drywood termite infestation?

A. Spot treatment

B. Fumigation

C. Soil treatment

D. Direct wood injection

Fumigation is the primary treatment for drywood termite infestations because it involves enclosing the entire structure in a tent and then introducing a gas (usually sulfuryl fluoride) that penetrates all areas of the wood where termites may be present. This method is effective because drywood termites can exist within the wood itself and do not require contact with the soil for their lifecycles. Fumigation ensures that even termites hidden deep inside the wood can be eradicated thoroughly, making it a comprehensive solution for severe infestations. Unlike other treatments, fumigation addresses the problem by effectively killing all life stages of the termites. While spot treatment, soil treatment, and direct wood injection can be effective in certain cases, such as for localized infestations or different types of termites, they are not as effective for the structural integrity and widespread nature of drywood termite infestations, which often require the extensive reach that fumigation provides.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://champresidentialinspsae.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE