
ECE 29401 EE SCAVENGER HUNT PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://ece29401eescavengerhunt.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1
Table of Contents 2
Introduction 3
How to Use This Guide 4
Questions 5
Answers 9
Explanations 11
Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which of the following is the correct phone number for the ECE Undergraduate Office?

A. 812-555-0000

B. 494-3390

C. 317-555-5555

D. 765-123-4567

2. Explain impedance matching in transmission lines and how a termination resistor achieves it.

A. Match the load to the line's characteristic impedance Z0 to minimize reflections; a resistor equal to Z0 at the load end accomplishes this.

B. Increase the line's bandwidth by adding a resistor in series.

C. Use a capacitor to ground to damp reflections.

D. Termination has no effect on reflections.

3. Kirchhoff's Current Law states that at any node the algebraic sum of currents is zero; which statement best expresses this law?

A. Currents entering equal currents leaving.

B. Net currents around a loop are zero.

C. Voltage around a node sums to zero.

D. Total resistance at a node is zero.

4. For a series RLC circuit, resonance occurs when which condition holds?

A. $\omega L = 1/(\omega C)$

B. $R = 0$

C. $\omega = 0$

D. $X_L = 0$

5. What are the three categories of the Academic Progress Initiative?

A. Good Standing, Warning, Dismissal

B. At Risk, Probation, Recovery

C. On Track, At Risk, Recovery

D. Probation, Suspension, Dismissal

SAMPLE

6. What is aliasing and how can it be avoided in a digital sampling system?

A. Aliasing is the misinterpretation of high-frequency components as lower frequencies due to an insufficient sampling rate. It can be avoided by sampling at $f_s \geq 2B$ and/or using anti-alias filters before sampling.

B. Aliasing occurs when the sampling rate is too high, which actually preserves all frequencies.

C. Aliasing is distortion caused by quantization in ADCs.

D. Aliasing occurs only in analog systems and cannot be avoided.

7. For a load with impedance Z, if the RMS voltage is $V_{rms} = 120$ V and the RMS current is $I_{rms} = 2$ A, which expression gives the real power P in terms of the phase angle φ?

A. $P = 240 \sin\varphi$

B. $P = 240 \cos\varphi$

C. $P = 240 \tan\varphi$

D. $P = 240$

8. Nyquist sampling theorem in your own words.

A. The sampling rate must be greater than any frequency component in the signal.

B. Sampling below twice the highest frequency can still reconstruct perfectly.

C. Aliasing is avoided if you sample at exactly the bandwidth of the signal.

D. Nyquist criterion states sampling at least twice the highest frequency component.

9. In a summing amplifier using an op-amp with three input resistors R1, R2, R3 and a feedback resistor Rf, what is Vout in terms of Vin1, Vin2, Vin3?

A. Vout = -Rf (Vin1/R1 + Vin2/R2 + Vin3/R3)

B. Vout = - (Vin1 + Vin2 + Vin3) / Rf

C. Vout = Rf (Vin1/R1 + Vin2/R2 + Vin3/R3)

D. Vout = Vin1/R1 + Vin2/R2 + Vin3/R3

SAMPLE

10. Under the passive sign convention, which statement is correct about power P?

A. Power absorbed is positive when current enters the negative terminal.

B. Power absorbed is positive regardless of current direction.

C. Current entering the positive terminal means the element absorbs power; if it enters the negative terminal, power is negative.

D. Power sign is determined solely by the element's resistance.

SAMPLE

Answers

SAMPLE

1. B
2. A
3. A
4. A
5. B
6. A
7. B
8. D
9. A
10. C

SAMPLE

Explanations

SAMPLE

1. Which of the following is the correct phone number for the ECE Undergraduate Office?

A. 812-555-0000

B. 494-3390

C. 317-555-5555

D. 765-123-4567

This question tests recognizing the real campus contact number and dialing conventions. The ECE Undergraduate Office is listed with the seven-digit campus extension 494-3390, which is how you'd dial it locally on campus (outside campus you'd add the area code 765). The other options mimic plausible-looking numbers but are not the office's real line: they include an invalid or reserved exchange (555) or area codes that point to other cities, or a nonstandard full number. So 494-3390 is the number that matches the actual campus listing. If ever unsure, confirm with the department's official contact page.

2. Explain impedance matching in transmission lines and how a termination resistor achieves it.

A. Match the load to the line's characteristic impedance Z0 to minimize reflections; a resistor equal to Z0 at the load end accomplishes this.

B. Increase the line's bandwidth by adding a resistor in series.

C. Use a capacitor to ground to damp reflections.

D. Termination has no effect on reflections.

Impedance matching means making the end of the line look like the same impedance the line has along its length, called the characteristic impedance Z0. A traveling wave on the line carries energy, and when it hits the boundary at the load, if the load impedance ZL differs from Z0, part of that energy reflects back toward the source. The amount of reflection is described by the reflection coefficient Γ = (ZL − Z0)/(ZL + Z0). If the load is terminated with a resistor equal to Z0, then ZL = Z0 and Γ becomes zero, so there are no reflected waves. The energy is absorbed by the load as the wave travels, which means the signal continues cleanly toward the end without bouncing back and causing interference. This is why using a termination resistor that matches the line's Z0 is the standard way to prevent reflections, especially on high-frequency lines where even small mismatches can create standing waves and distort the signal. A simple series resistor or a capacitor to ground doesn't provide a proper boundary that matches Z0 across the signal bandwidth, so they don't achieve the same effect as a true Z0 termination. Termination does affect reflections; without a proper match, reflected waves travel back and forth and degrade the signal.

SAMPLE

3. Kirchhoff's Current Law states that at any node the algebraic sum of currents is zero; which statement best expresses this law?

A. Currents entering equal currents leaving.

B. Net currents around a loop are zero.

C. Voltage around a node sums to zero.

D. Total resistance at a node is zero.

At a junction, charge cannot accumulate in steady state, so the currents must balance. Kirchhoff's Current Law says the algebraic sum of currents at a node is zero. If you take currents entering as positive and currents leaving as negative, the only way the sum can be zero is that the amount entering equals the amount leaving in magnitude. This captures the idea that what flows in must flow out, even though currents can split and recombine along the way. This matches the statement that currents entering equal currents leaving. The other ideas refer to different concepts: summing voltages around a loop is Kirchhoff's Voltage Law, the notion of voltage around a node isn't a defined quantity here, and total resistance at a node isn't the principle behind current balance.

4. For a series RLC circuit, resonance occurs when which condition holds?

A. $\omega L = 1/(\omega C)$

B. $R = 0$

C. $\omega = 0$

D. $X_L = 0$

Resonance in a series RLC circuit happens when the energy exchanged between the inductor and capacitor creates no net reactive effect in the loop. The total impedance is $Z = R + j(\omega L - 1/(\omega C))$. To have no imaginary part, the reactive term must cancel: $\omega L - 1/(\omega C) = 0$, which gives $\omega L = 1/(\omega C)$. This makes the impedance purely real ($Z = R$), so the current for a given voltage is maximum. At this frequency, the voltages across the inductor and capacitor can be large and opposite, but they cancel in the circuit's loop. The other options don't produce that zero net reactance. Setting R to zero lowers losses but doesn't enforce that the reactive parts cancel. If $\omega = 0$, the capacitor's reactance is infinite and nothing cancels. If $X_L = 0$, that also doesn't satisfy the condition needed for cancellation.

5. What are the three categories of the Academic Progress Initiative?

A. Good Standing, Warning, Dismissal

B. At Risk, Probation, Recovery

C. On Track, At Risk, Recovery

D. Probation, Suspension, Dismissal

The Academic Progress Initiative uses three statuses to guide student progress: At Risk, Probation, and Recovery. At Risk signals that a student isn't meeting academic standards and needs targeted intervention to prevent slipping further. Probation is a formal status that triggers specific requirements and a plan of action to demonstrate improvement and return to satisfactory standing. Recovery means the student has shown improvement and is moving back toward or sustaining acceptable progress, with ongoing monitoring to maintain gains. Other options mix terms that describe actual standing or consequences rather than the active three-category pathway this initiative uses.

SAMPLE

6. What is aliasing and how can it be avoided in a digital sampling system?

A. Aliasing is the misinterpretation of high-frequency components as lower frequencies due to an insufficient sampling rate. It can be avoided by sampling at $f_s \geq 2B$ and/or using anti-alias filters before sampling.

B. Aliasing occurs when the sampling rate is too high, which actually preserves all frequencies.

C. Aliasing is distortion caused by quantization in ADCs.

D. Aliasing occurs only in analog systems and cannot be avoided.

Aliasing happens when the sampling rate isn't high enough to capture the signal's highest frequencies, causing those high-frequency components to fold back into lower frequencies in the digitized spectrum. The safe fix is to ensure the sampling rate is at least twice the signal's bandwidth ($f_s \geq 2B$) and, before sampling, filter the signal with a low-pass (anti-aliasing) filter that attenuates frequencies above half the sampling rate. This keeps any energy that could alias out of the baseband, so the discrete representation accurately reflects the original signal. The other ideas don't fit because aliasing isn't caused by sampling too aggressively, and it isn't a result of quantization noise. It also isn't limited to analog behavior—aliasing arises during the sampling process itself, and using a sufficiently high sampling rate along with an anti-alias filter prevents it.

7. For a load with impedance Z, if the RMS voltage is $V_{rms} = 120$ V and the RMS current is $I_{rms} = 2$ A, which expression gives the real power P in terms of the phase angle φ?

A. $P = 240 \sin\varphi$

B. $P = 240 \cos\varphi$

C. $P = 240 \tan\varphi$

D. $P = 240$

Real power is the part of the electrical power that actually does work, and it equals the product of the RMS voltage, RMS current, and the cosine of the phase angle between them: $P = V_{rms} I_{rms} \cos\varphi$. With $V_{rms} = 120$ V and $I_{rms} = 2$ A, the apparent power is $S = V_{rms} I_{rms} = 120 \times 2 = 240$ VA. The real power then becomes $P = 240 \cos\varphi$. So the expression that gives P in terms of φ is $240 \cos\varphi$. Think of it this way: when the voltage and current are perfectly aligned ($\varphi = 0$), all the apparent power contributes to real power, giving $P = 240$ W. As the phase angle grows, $\cos\varphi$ decreases, reducing the real power accordingly. The other forms would either capture the reactive component ($\sin\varphi$), a ratio that isn't the real power, or ignore the phase altogether.

8. Nyquist sampling theorem in your own words.

A. The sampling rate must be greater than any frequency component in the signal.

B. Sampling below twice the highest frequency can still reconstruct perfectly.

C. Aliasing is avoided if you sample at exactly the bandwidth of the signal.

D. Nyquist criterion states sampling at least twice the highest frequency component.

When you turn a continuous signal into samples, you must prevent the spectral copies created by sampling from overlapping. The condition that ensures this is: sample at least twice the highest frequency present in the signal. This threshold, known as the Nyquist criterion, lets the original signal be reconstructed from its samples under ideal conditions. So the choice that matches this idea says you need a sampling rate at least twice the highest frequency component. That's the essential rule. The other statements either suggest a too-low requirement, claim perfect reconstruction below the 2×Nyquist rate, or imply that sampling exactly at the bandwidth guarantees alias-free reconstruction—each of which conflicts with how spectral replicas align in the frequency domain and how real-world filtering works.

SAMPLE

9. In a summing amplifier using an op-amp with three input resistors R1, R2, R3 and a feedback resistor Rf, what is Vout in terms of Vin1, Vin2, Vin3?

A. Vout = -Rf (Vin1/R1 + Vin2/R2 + Vin3/R3)

B. Vout = - (Vin1 + Vin2 + Vin3) / Rf

C. Vout = Rf (Vin1/R1 + Vin2/R2 + Vin3/R3)

D. Vout = Vin1/R1 + Vin2/R2 + Vin3/R3

An inverting summing amplifier combines multiple input voltages as a negative, scaled sum, with the scaling set by the input resistors and the feedback resistor. The non-inverting input is grounded, so the inverting input sits at a virtual ground (nearly 0 V) due to negative feedback. Each input current is Vin1/R1, Vin2/R2, and Vin3/R3, flowing into the summing node. Since the op-amp input draws no current, all those currents must pass through the feedback resistor, and the current through that resistor is (Vout − 0)/Rf = Vout/Rf. Applying Kirchhoff's current law at the summing node gives Vin1/R1 + Vin2/R2 + Vin3/R3 + Vout/Rf = 0, which leads to Vout = −Rf (Vin1/R1 + Vin2/R2 + Vin3/R3). The negative sign reflects inversion, and the output scales with Rf relative to each input path. If only one input is present, you recover the familiar single-input inverting gain of −Rf/R1.

10. Under the passive sign convention, which statement is correct about power P?

A. Power absorbed is positive when current enters the negative terminal.

B. Power absorbed is positive regardless of current direction.

C. Current entering the positive terminal means the element absorbs power; if it enters the negative terminal, power is negative.

D. Power sign is determined solely by the element's resistance.

Under the passive sign convention, the terminal where current enters is defined as the positive terminal, and the power is positive when the element absorbs energy. If current enters the positive terminal, the power P is positive, meaning the element is absorbing or dissipating energy. If the current instead enters the negative terminal, the power is negative, indicating the element is delivering energy back to the circuit. So the statement that current entering the positive terminal means the element absorbs power, and if it enters the negative terminal, the power is negative, is the correct way to describe how power is signed under this convention. A resistor with current entering the positive side will have positive P and heat dissipated; a source delivering power would have current entering the negative side, resulting in negative P under the chosen polarity. The sign does not depend on resistance alone; it depends on the direction of current relative to the defined voltage polarity.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://ece29401eescavengerhunt.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE