MARYLAND EROSION AND SEDIMENT (E&S) CONTROL CERTIFICATION PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://marylanderosionsedimentcontrol.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which of the following materials is NOT typically used in inlet protection?

A. Stone

B. Woven slit film geotextile

C. Sand

D. Nonwoven geotextile

2. What is the maximum allowable slope for a Type A temporary swale?

A. 5 percent

B. 10 percent

C. 15 percent

D. 20 percent

3. Most filtering practices should receive what type of flow?

A. Sheet flow only

B. Point source flow

C. Runoff flow

D. Subsurface flow

4. How many types of standard inlet protection are there?

A. A and B

B. 1 and 2

C. There is only one type

D. None of the above

5. Which year is associated with the current Maryland Standards and Specifications for Soil Erosion and Sediment Control?

A. 1994

B. 2000

C. 2011

D. 2013

SAMPLE

6. Who is responsible for reviewing and approving erosion and sediment control plans in Maryland?

A. All local governments

B. The Maryland Department of the Environment

C. Only federal agencies

D. Private contractors

7. What design consideration is crucial for rock outlet protection?

A. Cost efficiency

B. Geological formation

C. Soil stability

D. Hydraulic capacity

8. Can a storm drain diversion discharge to silt fence?

A. True

B. False

9. What material is used to filter sediment-laden water in standard inlet protection?

A. Woven slit film geotextile

B. Woven monofilament geotextile

C. Nonwoven geotextile

D. 2" - 3" stone

10. Is a waterway construction permit required if a streamflow is diverted using a clear water diversion pipe?

A. Yes

B. No

SAMPLE

Answers

SAMPLE

1. C
2. B
3. A
4. A
5. C
6. B
7. D
8. B
9. A
10. B

SAMPLE

Explanations

SAMPLE

1. Which of the following materials is NOT typically used in inlet protection?

A. Stone

B. Woven slit film geotextile

C. Sand

D. Nonwoven geotextile

Inlet protection is a critical aspect of erosion and sediment control practices, particularly to prevent sediment-laden runoff from entering stormwater inlets during construction activities. The materials used for inlet protection are specifically chosen for their effectiveness in filtering sediment while allowing water to pass through. Stone is commonly used due to its durability and capacity to create a structural barrier that can accommodate the flow of water while trapping sediment. Woven slit film geotextiles are also frequently utilized because they offer a good balance between filtration and hydraulic conductivity, enabling them to filter sediment effectively. Nonwoven geotextiles are often employed as well, as they provide a high level of sediment retention and are known for their effectiveness in sediment control applications. On the other hand, sand is not typically used for inlet protection. While sand can serve as a filtering material, it does not provide the same level of structural integrity or sediment retention as the other options. Sand may easily wash away or become displaced during storm events, reducing its efficiency in controlling sediment at inlets. Therefore, the inclusion of sand as a material for inlet protection is not standard practice, making it the correct choice for this question.

2. What is the maximum allowable slope for a Type A temporary swale?

A. 5 percent

B. 10 percent

C. 15 percent

D. 20 percent

The maximum allowable slope for a Type A temporary swale is indeed 10 percent. This standard is established to ensure proper function and effectiveness of the swale in managing water runoff and erosion control. The moderate slope allows for adequate flow without causing excessive water velocity, which could lead to erosion of the swale itself or surrounding areas. A slope of 10 percent strikes a balance between ensuring effective drainage and reducing the risk of erosion. If the slope were to exceed this percentage, the increased water velocity could compromise the swale's ability to temporarily hold and manage runoff safely. Therefore, adhering to the 10 percent maximum is crucial for maintaining the performance and integrity of Type A temporary swales in erosion and sediment control practices.

SAMPLE

3. Most filtering practices should receive what type of flow?

A. Sheet flow only

B. Point source flow

C. Runoff flow

D. Subsurface flow

The correct answer focuses on the concept of sheet flow, which refers to the thin layer of runoff flowing evenly across the surface of the ground. This type of flow is ideal for many filtering practices because it allows for a broad distribution of water over a larger area, facilitating effective sediment capture and pollutant removal. Filtering practices, such as vegetated swales, filter strips, and bioretention areas, are designed to manage runoff by providing the opportunity for water to infiltrate the soil and to allow for natural processes to take place. When runoff is spread out in a thin layer, it reduces potential erosion and enhances the ability of the filtering media to treat the water before it enters waterways. In contrast, point source flow represents concentrated water flow from a single source, which can lead to increased erosion and ineffective filtration as it may overwhelm the filtration practice. Runoff flow can vary and may come from multiple sources, potentially complicating management efforts. Subsurface flow occurs below the surface, which would not utilize the filtering practices effectively since these practices are designed to interact directly with surface water. Thus, it is the nature of sheet flow that aligns most closely with the operational principles of effective filtering practices, ensuring efficient treatment and management of water runoff.

4. How many types of standard inlet protection are there?

A. A and B

B. 1 and 2

C. There is only one type

D. None of the above

The correct choice indicates that there are two types of standard inlet protection measures available. Inlet protection is crucial in managing sediment and preventing debris from entering storm drain systems during construction activities. The two types typically include options like silt fences or gravel bags placed around the drains to filter out sediment and prevent it from clogging the system. Understanding the two types allows for flexibility in implementation based on site-specific conditions, such as the volume of runoff and the type of soil present. Each type of protection has its own application methods and materials that cater to different scenarios, ensuring effective erosion and sediment control. Recognizing the distinction between the types is essential for compliance with Maryland's Erosion and Sediment Control regulations, which emphasize effective methods for minimizing sedimentation during construction projects. Knowing that there are two options encourages practitioners to select appropriate measures that fit the specific site requirements, thereby enhancing the control of sediment movement to protect water quality during construction activities.

SAMPLE

5. Which year is associated with the current Maryland Standards and Specifications for Soil Erosion and Sediment Control?

A. 1994

B. 2000

C. 2011

D. 2013

The current Maryland Standards and Specifications for Soil Erosion and Sediment Control were established in 2011. This set of standards provides guidelines for managing soil erosion and sedimentation during land-disturbing activities to protect water quality and prevent land degradation. These specifications were updated to reflect advancements in erosion and sediment control technologies and practices, ensuring that they are effective and relevant in addressing current environmental challenges. The 2011 update is crucial for professionals in the field, as adopting these standards helps ensure compliance with state regulations and promotes sustainable land management practices. Understanding the historical context and the evolution of these standards can help practitioners implement better strategies for erosion control and maintain compliance with legal requirements.

6. Who is responsible for reviewing and approving erosion and sediment control plans in Maryland?

A. All local governments

B. The Maryland Department of the Environment

C. Only federal agencies

D. Private contractors

The Maryland Department of the Environment is responsible for the review and approval of erosion and sediment control plans within the state. This agency has been designated to ensure that development projects comply with state regulations aimed at preventing soil erosion and sedimentation, which can have detrimental effects on waterways and the environment. Erosion and sediment control plans must adhere to specific guidelines established by the Department to effectively minimize the impact of construction activities. The Department's role includes providing oversight, technical assistance, and enforcement to maintain the integrity of Maryland's natural resources. This centralization of responsibility helps ensure consistency and adherence to best management practices throughout the state. While local governments play a role in implementing these plans at a community level and ensuring compliance with local codes, the ultimate authority and responsibility for these reviews lie with the Maryland Department of the Environment. Other entities, such as federal agencies and private contractors, do not have the primary legal responsibility for the assessment and approval of these plans in the state.

SAMPLE

7. What design consideration is crucial for rock outlet protection?

A. Cost efficiency

B. Geological formation

C. Soil stability

D. Hydraulic capacity

In the context of rock outlet protection, hydraulic capacity is a crucial design consideration because it ensures that the outlet can effectively handle the flow of water without causing erosion or other forms of damage. Proper design must account for the expected flow rates and velocities, as well as the size and type of rock used in the protection measure. If the hydraulic capacity is not adequate, the energy of the flowing water can lead to the displacement of the rock, undermining the structural integrity of the outlet protection. Therefore, understanding the hydraulic conditions is essential for effectively designing rock outlet protection to manage water flow safely and efficiently. This consideration helps in preventing erosion and maintaining the stability of surrounding areas.

8. Can a storm drain diversion discharge to silt fence?

A. True

B. False

Discharging a storm drain diversion to a silt fence is typically not advisable because silt fences are designed primarily to capture sediment from sheet flow across a site, rather than from concentrated flows such as those that would come from a storm drain. When water flows through a storm drain, it can carry sediments and pollutants in higher concentrations and at greater velocities compared to sheet flow. Silt fences have limitations in terms of their capacity to handle concentrated discharges, as they can become overwhelmed, leading to potential failure. The proper function of a silt fence relies on the even filtering of sediment-laden water, which is not achievable with the direct discharge from a storm drain. Instead, it's essential to divert this type of water to a more suitable sediment control practice, like a sediment basin or a trap, which can effectively handle and manage the runoff before it leaves the construction site. This approach helps prevent the transport of sediment into water bodies and maintains the integrity of the erosion and sediment control plan.

9. What material is used to filter sediment-laden water in standard inlet protection?

A. Woven slit film geotextile

B. Woven monofilament geotextile

C. Nonwoven geotextile

D. 2" - 3" stone

The correct material used to filter sediment-laden water in standard inlet protection is woven slit film geotextile. This type of geotextile is designed specifically for applications involving erosion and sediment control due to its effective filtration properties. Woven slit film geotextiles are made from slit film fibers, which provide a robust structure that allows for efficient water flow while effectively trapping sediment particles. In the context of erosion and sediment control, standard inlet protection is used to help prevent sediment from entering stormwater inlets during construction or land-disturbing activities. The woven slit film geotextile allows water to percolate through while capturing sediment, thereby helping to maintain water quality and prevent clogging of stormwater systems. The other materials listed, while they have their uses in different contexts, do not provide the same level of filtration efficiency and structural integrity required for inlet protection. For example, woven monofilament geotextiles, while effective for other applications, do not typically offer the same filtration capabilities as slit film options. Nonwoven geotextiles may also serve as filtration solutions, but they are typically used in different contexts, such as separation or drainage, rather than directly filtering sediment-laden water in an inlet protection scenario.

SAMPLE

10. Is a waterway construction permit required if a streamflow is diverted using a clear water diversion pipe?

A. Yes

B. No

The correct choice is that a waterway construction permit is not required when a streamflow is diverted using a clear water diversion pipe. This is because clear water diversion methods are typically utilized to manage and redirect uncontaminated runoff away from construction activities, thereby minimizing erosion and sedimentation impacts. Such practices are recognized as best management practices (BMPs) aimed at protecting water quality during construction. The use of clear water diversion pipes is more aligned with maintaining site drainage and preventing stormwater from mixing with disturbed soil surfaces, which helps to maintain the integrity of the waterbody and protect aquatic life. The regulatory framework often establishes different criteria for various types of activities and the materials used in stream flow management. In many cases, clear water management systems are seen as less intrusive and do not pose the same risks associated with more extensive alterations of the stream, which would necessitate a more rigorous permitting process. Understanding the specific measures and practices allowed under Maryland's environmental regulations helps ensure that construction professionals can effectively manage water flow while complying with legal requirements.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://marylanderosionsedimentcontrol.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE