MICHIGAN JOURNEYMAN PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://mijourneyman.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. How many inches of thermal expansion occur for 100 feet of rigid nonmetallic conduit due to temperature changes between -15°F to 105°F?

A. 4.0 inches

B. 4.5 inches

C. 4.87 inches

D. 5.2 inches

2. What factor affects the ampacity of conductors when de-rating?

A. Length of the conductor

B. Type of insulation

C. Temperature and bundling conditions

D. Color of the conductor

3. How far must thermal insulation be installed from recessed lighting fixtures?

A. 2 inches

B. 3 inches

C. 4 inches

D. 5 inches

4. What type of wiring is typically used for lighting fixtures?

A. Multistrand wiring

B. Armored cable

C. Non-metallic sheathed cable

D. PVC insulated wire

5. What is the term for the maximum current that a conductor can safely carry?

A. Voltage

B. Amperage

C. Ampacity

D. Capacity

SAMPLE

6. What material should be used to install the feed to the wet niche fixture?

A. Plastic

B. Rigid brass

C. Aluminum

D. Copper

7. What standard defines the acceptable distances between electrical equipment and likely sources of water?

A. OSHA regulations

B. NEC guidelines

C. IEEE standards

D. ANSI specifications

8. What is the maximum number of conductors allowed in a conduit without derating?

A. Depends on the size of the conduit and conductors

B. Always two conductors

C. Depends on the type of connectors used

D. Five conductors for all sizes

9. What is the function of a Ground Fault Circuit Interrupter (GFCI)?

A. To regulate voltage levels

B. To prevent overload in circuits

C. To prevent electrical shock by shutting off power

D. To convert AC to DC power

10. The maximum number of number 6 AWG THW conductors allowed in a 1 inch PVC schedule 40 conduit is _____?

A. 2

B. 3

C. 4

D. 5

SAMPLE

Answers

SAMPLE

1. C
2. C
3. B
4. C
5. C
6. B
7. B
8. A
9. C
10. C

SAMPLE

Explanations

SAMPLE

1. How many inches of thermal expansion occur for 100 feet of rigid nonmetallic conduit due to temperature changes between -15°F to 105°F?

A. 4.0 inches

B. 4.5 inches

C. 4.87 inches

D. 5.2 inches

*To determine the amount of thermal expansion for 100 feet of rigid nonmetallic conduit as a result of temperature changes from -15°F to 105°F, we first calculate the total temperature change involved, which is 105°F - (-15°F) = 120°F. Nonmetallic materials typically have a coefficient of linear expansion in the range of about 0.000004 to 0.000006 per degree Fahrenheit. For the purpose of this calculation, let's use an average value of approximately 0.0000055 per degree Fahrenheit. Using the formula for thermal expansion, which is: **Expansion = Original Length x Coefficient of Expansion x Temperature Change** we can substitute the values: - Original Length = 100 feet (which is 1200 inches, since 1 foot = 12 inches) - Coefficient of Expansion = 0.0000055 - Temperature Change = 120°F Now, substituting in the values: **Expansion = 1200 inches x 0.0000055 x 120 = 0.792 inches** However, the amount given in the answer choices suggests that personal judgement or alternate parameters might have been used for material selection. If the toning is also due to*

2. What factor affects the ampacity of conductors when de-rating?

A. Length of the conductor

B. Type of insulation

C. Temperature and bundling conditions

D. Color of the conductor

The ampacity, or current-carrying capacity, of conductors is primarily influenced by several factors, including temperature and bundling conditions. When conductors are bundled together or exposed to elevated temperatures, their ability to dissipate heat diminishes, which can lead to overheating. As a result, it is necessary to apply a de-rating factor to ensure that the conductors can operate safely without exceeding their thermal limits. For instance, when multiple conductors are installed closely together, the heat generated by each conductor can accumulate, raising the overall temperature of the bundle. Similarly, higher ambient temperatures can also increase the current flowing through the conductor, necessitating a de-rating to prevent insulation damage or even fire hazards. Recognizing these conditions is crucial for maintaining electrical safety and ensuring the longevity of the installed wiring system. The length of the conductor, type of insulation, and color are important in other aspects of electrical installation, but they do not have as direct an impact on de-rating concerns related to ampacity as temperature and bundling conditions do.

SAMPLE

3. How far must thermal insulation be installed from recessed lighting fixtures?

A. 2 inches

B. 3 inches

C. 4 inches

D. 5 inches

The correct distance for thermal insulation to be installed from recessed lighting fixtures is 3 inches. This distance is primarily advised to prevent a potential fire hazard, as recessed lights can generate substantial heat. Insulation that is too close to these fixtures can cause overheating and possibly ignite the insulation material. The 3-inch allowance provides a safe buffer zone that maintains sufficient airflow around the fixtures, reducing the risk of heat buildup. It's important for both the safety of the building and compliance with local building codes concerning electrical and fire safety. Although other distances might be considered in specific contexts or jurisdictions, the 3-inch guideline is a commonly accepted standard to ensure safety in residential and commercial installations.

4. What type of wiring is typically used for lighting fixtures?

A. Multistrand wiring

B. Armored cable

C. Non-metallic sheathed cable

D. PVC insulated wire

Non-metallic sheathed cable, commonly referred to as NM cable or Romex, is typically used for lighting fixtures due to its versatility, ease of installation, and cost-effectiveness. This type of wiring consists of multiple insulated conductors held together with a non-metallic sheath, which provides protection while also allowing for flexibility in residential and light commercial environments. The advantages of non-metallic sheathed cable include its suitability for dry areas and its lightweight nature, making it easier to maneuver during installation. Additionally, NM cable is generally rated for both branch circuits and lighting applications, making it the preferred choice for residential wiring projects. This choice aligns well with the requirements and standards set forth in electrical codes, which prioritize safety and accessibility for lighting fixtures in various settings.

5. What is the term for the maximum current that a conductor can safely carry?

A. Voltage

B. Amperage

C. Ampacity

D. Capacity

The term for the maximum current that a conductor can safely carry is ampacity. This term specifically refers to the current-carrying capacity of electrical conductors, which is determined by factors such as the size of the conductor, its material, insulation type, and the surrounding environment. Ampacity ensures that the conductor operates within safe limits to prevent overheating, damage, or potential fire hazards. Understanding ampacity is essential for electricians and those involved in electrical engineering, as it guides the selection of appropriate conductors for various applications, ensuring safe and efficient electrical systems. The other terms, while related to electrical concepts, do not specifically define a conductor's safe current-carrying capability. Voltage refers to the electrical potential difference, amperage generally describes the flow of electric current, and capacity could refer to various things depending on the context but does not specifically denote the maximum current a conductor can handle.

SAMPLE

6. What material should be used to install the feed to the wet niche fixture?

A. Plastic

B. Rigid brass

C. Aluminum

D. Copper

The use of rigid brass for the feed to a wet niche fixture is essential due to its durability, corrosion resistance, and ability to handle the environmental conditions typically found in wet locations. Wet niche fixtures are installed in areas exposed to water, such as pools or spa settings, where the electrical connections need to be secure and reliable to prevent any risk of electrical hazards. Rigid brass is non-corrosive and thus performs well in wet environments, ensuring a longer lifespan and reducing maintenance needs. While plastic may seem like an option because it resists corrosion, it may not provide the same level of grounding and secure connection required in electrical systems that are often subjected to water exposure. Aluminum, though lightweight and resistant to corrosion, is not as robust as brass and may be less suitable for the high-stress environments typically present with wet niche fixtures. Copper, while an excellent conductor of electricity, can corrode over time in the presence of water and other elements, making it less suitable compared to brass for this specific application. Thus, rigid brass stands out as the most appropriate choice for ensuring safety and reliable performance for wet niche fixtures.

7. What standard defines the acceptable distances between electrical equipment and likely sources of water?

A. OSHA regulations

B. NEC guidelines

C. IEEE standards

D. ANSI specifications

The National Electrical Code (NEC) is the authoritative standard when it comes to the installation of electrical wiring and equipment in the United States, which includes specifying safety measures related to water hazards. The NEC contains specific guidelines that establish acceptable distances between electrical equipment and potential sources of water to minimize the risk of electrical shock and other hazards. These guidelines identify safe installation practices, ensuring that equipment is maintained at a safe distance from water sources, such as sinks, pools, and other areas where water may accumulate. This is especially important in residential and commercial settings, where such precautions can prevent electrical accidents and injuries. While other standards and regulations, such as those from OSHA, IEEE, and ANSI, may address safety practices and technical standards within their respective scopes, the NEC is the primary document focused on electrical installations and specifically addresses concerns related to electrical equipment in relation to water. This distinct focus makes the NEC the correct standard for this particular question about acceptable distances regarding water sources.

SAMPLE

8. What is the maximum number of conductors allowed in a conduit without derating?

A. Depends on the size of the conduit and conductors

B. Always two conductors

C. Depends on the type of connectors used

D. Five conductors for all sizes

The maximum number of conductors allowed in a conduit without derating indeed depends on the size of the conduit and the size and type of conductors being used. This is in accordance with the National Electrical Code (NEC), which provides detailed tables and guidelines for determining the maximum number of conductors that can be installed in a conduit before you need to consider derating due to heat buildup. As the number of conductors increases, especially if they are carrying current, they can generate heat. When too many conductors are packed into a conduit, their collective heat can surpass safe operating temperatures, necessitating derating to ensure safety and compliance with electrical codes. The size of the conduit dictates how many conductors can fit without overcrowding, while the type and size of the conductors affect how much current each can safely carry, further influencing the maximum allowable number of conductors. Thus, it is crucial to refer to NEC tables for your specific project to ascertain the appropriate conductor count based on both the size and material of the conduit and the conductors involved.

9. What is the function of a Ground Fault Circuit Interrupter (GFCI)?

A. To regulate voltage levels

B. To prevent overload in circuits

C. To prevent electrical shock by shutting off power

D. To convert AC to DC power

A Ground Fault Circuit Interrupter (GFCI) plays a critical role in enhancing electrical safety by monitoring the current flowing through a circuit. Its primary purpose is to quickly disconnect power when it detects an imbalance between the outgoing and incoming current, which can occur when electricity escapes the intended circuit, potentially causing electrical shock. When a ground fault occurs, the GFCI identifies the difference in current and responds almost instantaneously, cutting off the electrical supply. This prevention of electrical shock is particularly vital in areas where the risk of such occurrences is higher, like bathrooms, kitchens, and outdoor settings, where moisture and conductive materials may be present. The other options do not accurately describe the function of a GFCI. Regulating voltage levels pertains to devices like voltage regulators, preventing overload is managed by circuit breakers or fuses, and converting AC to DC power is the role of rectifiers. Thus, the focus of a GFCI is specifically on safety by preventing electrical shock.

SAMPLE

10. The maximum number of number 6 AWG THW conductors allowed in a 1 inch PVC schedule 40 conduit is _____?

A. 2

B. 3

C. 4

D. 5

The maximum number of number 6 AWG THW conductors that can be accommodated in a 1-inch PVC schedule 40 conduit is determined based on the National Electrical Code (NEC) and the fill capacity rules for conduits. According to NEC guidelines, specific tables outline the allowable fill percentages for different conduit sizes, considering conductor size and type. For a 1-inch diameter PVC conduit, the permissible fill percentage is generally 40% for conductors. By examining the NEC fill tables, we find the total cross-sectional area for a 1-inch conduit and compare it with the area occupied by each number 6 AWG THW conductor. Since the area occupied by each number 6 AWG conductor is known, the calculations confirm that four of these conductors can fit within the allowed fill space without exceeding the maximum capacity. This ensures that the conductors are not overly crowded, which could lead to overheating and other safety hazards. Therefore, the correct answer reflects the NEC's guidelines for optimal and safe installation practices, highlighting the allowance for four number 6 AWG THW conductors in a 1-inch PVC schedule 40 conduit.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://mijourneyman.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE