MINNESOTA CONTRACTORS PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://minnesotacontractors.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1
Table of Contents 2
Introduction 3
How to Use This Guide 4
Questions 5
Answers 8
Explanations 10
Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. When finishing concrete, the movement of water to the top surface is known as what?

A. Efflorescence

B. Bleeding

C. Laitance

D. Bonding

2. What is the minimum height above roof for a single radon vent pipe?

A. 8 inches

B. 10 inches

C. 12 inches

D. 16 inches

3. Chimney requirements state that the chimney must extend at least 2 feet above any portion of the building within how many feet of the chimney?

A. 2 feet

B. 5 feet

C. 8 feet

D. 10 feet

4. What is the minimum thickness of a concrete floor?

A. 2.75 inches

B. 3 inches

C. 3.25 inches

D. 3.5 inches

5. Untreated siding shall be no closer than?

A. 6 inches to the ground

B. 5 inches to the ground

C. 4 inches to the ground

D. 3 inches to the ground

SAMPLE

6. What table would you use to calculate the span for a joist that also spans cantilevers?

A. R502.3.3(2)

B. R502.3.1(1)

C. R502.3.3(1)

D. R502.5(1)

7. How do you increase the compressive strength of mortar containing lime and Portland cement?

A. Add cement

B. Add water

C. Add mortar

D. Add lime

8. When can a bedroom be accessed directly from the garage?

A. Only when the garage has a lock

B. With more than a 1.5 inch threshold

C. Only in houses built before 1980

D. Never

9. What document must a contractor submit when changing their business name?

A. Agreement for Business Name

B. Business Name Registration Form

C. Certificate of Assumed Name

D. Legal Name Change Document

10. What is the maximum tolerance between the centerline of the horizontal framing member and the vertical framing member when using steel floor framing?

A. 1/8 inch

B. 1/4 inch

C. 1/2 inch

D. 3/4 inch

SAMPLE

Answers

SAMPLE

1. B
2. C
3. D
4. D
5. A
6. C
7. A
8. D
9. C
10. D

SAMPLE

Explanations

SAMPLE

1. When finishing concrete, the movement of water to the top surface is known as what?

A. Efflorescence

B. Bleeding

C. Laitance

D. Bonding

The movement of water to the top surface of freshly poured concrete is referred to as bleeding. This phenomenon occurs as the heavier solid particles of concrete settle under the force of gravity, allowing the lighter water to rise to the surface. As water moves upward, it can create a layer on top of the concrete, which may need to be managed to ensure proper finishing and to avoid issues such as surface defects or weak layers. This process can impact the final appearance and strength of the cured concrete, making it essential for contractors to be aware of and address bleeding during the finishing process. Properly timing finishing techniques is crucial since finishing too early, when bleeding is still occurring, can trap excess water underneath the surface and lead to problems like surface scaling or dusting. Efflorescence refers to the white, powdery substance that can form on the surface of concrete due to the migration of soluble salts and moisture, but it does not describe the movement of water during the initial curing phase. Laitance is a similar phenomenon that involves the formation of a weak layer on the surface of concrete due to the upward migration of fine particles and water, but this is a different process than what bleeding describes. Bonding pertains to the adherence of materials together, which is not

2. What is the minimum height above roof for a single radon vent pipe?

A. 8 inches

B. 10 inches

C. 12 inches

D. 16 inches

The minimum height above the roof for a single radon vent pipe is 12 inches. This requirement helps ensure that the vent pipe effectively dissipates radon and any other gases below the roofline, allowing for proper ventilation and reducing the risk of radon re-entering the structure. The 12-inch height is specified to prevent potential obstructions and to promote better air flow, thus enhancing the efficacy of the ventilation system. Additionally, having the vent pipe at the proper height minimizes the possibility of wind turbulence around the pipe, which could otherwise affect the performance of the radon mitigation system. By maintaining this height, the design aligns with best practices for radon mitigation and health safety standards, ensuring that any radon gas is adequately vented away from the living spaces beneath the roof.

SAMPLE

3. Chimney requirements state that the chimney must extend at least 2 feet above any portion of the building within how many feet of the chimney?

A. 2 feet

B. 5 feet

C. 8 feet

D. 10 feet

The correct answer indicates that the chimney must extend at least 2 feet above any portion of the building within 10 feet of the chimney. This requirement is set to ensure proper ventilation and prevent the risk of smoke and harmful gases re-entering the building. By having the chimney rise higher than structures within that distance, it helps maintain efficient draft and reduces the likelihood of downdrafts that could occur if the chimney is not sufficiently elevated. The rationale behind the 10-foot measurement is primarily to mitigate the potential impact that nearby structures can have on airflow and chimney performance. Additionally, it addresses safety concerns, ensuring that the flue gases are adequately cleared away from the eaves, roofs, and adjacent buildings. This guideline promotes effective combustion and increases safety for occupants, making it an essential aspect of chimney installation and compliance with building codes.

4. What is the minimum thickness of a concrete floor?

A. 2.75 inches

B. 3 inches

C. 3.25 inches

D. 3.5 inches

The minimum thickness of a concrete floor is typically set at 3.5 inches for various structural and performance considerations. This thickness ensures adequate strength and durability for the intended use, providing sufficient load-bearing capacity to support both static and dynamic loads. A concrete floor that is 3.5 inches thick can also accommodate the contraction and expansion that happens due to temperature fluctuations, which can help prevent cracking. Additionally, this thickness allows for adequate subgrade support, which is essential in areas where soil conditions may vary. Many building codes and construction practices specify this thickness to ensure that the flooring can withstand the stresses it will encounter over time, making it a standard requirement in the industry.

5. Untreated siding shall be no closer than?

A. 6 inches to the ground

B. 5 inches to the ground

C. 4 inches to the ground

D. 3 inches to the ground

The correct answer is that untreated siding must be no closer than 6 inches to the ground to prevent damage and deterioration. This requirement is crucial because maintaining a vertical distance between the siding and the ground helps reduce the risk of moisture-related issues such as rot, mold, and pest infestations. When siding is placed too close to the ground, it becomes susceptible to water accumulation and ground contact, which can lead to structural problems over time. Additionally, this guideline aligns with best practices in building codes, emphasizing the importance of proper siding installation to ensure durability and longevity. Keeping untreated siding elevated at least 6 inches also facilitates proper airflow and drainage, further protecting the integrity of the siding material. This consideration is vital for maintaining the overall health of the building structure, hence supporting the importance of adhering to this specific distance requirement.

SAMPLE

6. What table would you use to calculate the span for a joist that also spans cantilevers?

A. R502.3.3(2)

B. R502.3.1(1)

C. R502.3.3(1)

D. R502.5(1)

To calculate the span for a joist that also spans cantilevers, the appropriate reference is R502.3.3(1). This code section specifically addresses the span requirements for floor joists, taking into account the effects of cantilevers. In this context, it provides guidance on how to determine the maximum allowable span for joists that also extend beyond their supporting walls or beams, which is essential for ensuring structural integrity and safety. The reference may include specific tables or charts that give values based on various factors such as joist size, spacing, load conditions, and the presence of cantilevered sections. Utilizing this information helps builders and contractors design safe and compliant structures by following the established standards in the Minnesota building code.

7. How do you increase the compressive strength of mortar containing lime and Portland cement?

A. Add cement

B. Add water

C. Add mortar

D. Add lime

To increase the compressive strength of mortar containing lime and Portland cement, adding cement is the best approach. Mortar is primarily composed of a binder, such as Portland cement, which gives it its strength. By increasing the amount of cement in the mixture, the overall strength of the mortar can be enhanced. The cement hydrates during the curing process, creating bonds that contribute to the structural integrity of the mortar. Lime, while beneficial for workability and flexibility, does not provide the same level of compressive strength as Portland cement. Therefore, while lime can improve other characteristics, such as adhesion and resistance to cracking, it is the increased cement content that directly improves compressive strength. Adding water does not effectively increase compressive strength; in fact, too much water can weaken the mixture if it exceeds the optimum water-to-cement ratio. Adding mortar would not alter the fundamental mix proportions favorably and could lead to inconsistencies. Similarly, adding lime does not directly increase compressive strength; rather, it plays a different role in the mortar's properties.

SAMPLE

8. When can a bedroom be accessed directly from the garage?

A. Only when the garage has a lock

B. With more than a 1.5 inch threshold

C. Only in houses built before 1980

D. Never

Access from a garage to a bedroom is typically restricted due to safety and fire code regulations. The primary concern is that garages are often considered hazardous areas because they can contain combustible materials, fumes from cars, and other potential hazards. When living spaces, such as bedrooms, are directly accessed from a garage, there is a higher risk of harmful gases entering the living area or the potential for fire to spread. In most building codes, especially those updated for safety, it is mandated that any access from a garage to a living space, like a bedroom, must be controlled and designed to minimize these risks. This can include requirements for fire-rated doors, proper ventilation, and maintaining a separation between living spaces and non-living spaces like garages. Therefore, the correct understanding is that a bedroom should never be accessed directly from a garage, ensuring the safety of occupants by maintaining a barrier between potentially hazardous conditions and living environments.

9. What document must a contractor submit when changing their business name?

A. Agreement for Business Name

B. Business Name Registration Form

C. Certificate of Assumed Name

D. Legal Name Change Document

When a contractor changes their business name, the appropriate document to submit is a Certificate of Assumed Name. This certificate is essential because it officially records the new name under which the business will operate, ensuring that it is recognized by the state. Filing this certificate provides legal protection for the new name and allows the contractor to inform the public and other businesses about the name under which they will be conducting their affairs. While other documents, such as a Business Name Registration Form or a Legal Name Change Document, might seem relevant in certain contexts, they do not specifically address the requirement for businesses operating under an assumed name. The Certificate of Assumed Name is tailored to meet the legal obligations of businesses that want to operate under a name different from their legal name.

10. What is the maximum tolerance between the centerline of the horizontal framing member and the vertical framing member when using steel floor framing?

A. 1/8 inch

B. 1/4 inch

C. 1/2 inch

D. 3/4 inch

The correct answer reflects the maximum tolerance of 3/4 inch between the centerline of the horizontal framing member and the vertical framing member when working with steel floor framing. This tolerance is established to ensure that the structural integrity and connection quality are maintained in steel construction. This allowance accommodates for slight variations during assembly and helps manage any potential misalignments that may occur due to fabrication tolerances or onsite adjustments. Steel framing requires precise alignment to ensure that loads are properly distributed and that connections between members perform as expected under load conditions. Allowing for a tolerance of up to 3/4 inch enables builders to achieve robust and reliable constructions, while still maintaining the necessary adjustability for practical installation.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://minnesotacontractors.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE