NASCLA GENERAL CONTRACTOR PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://nasclegeneralcontractor.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1
Table of Contents 2
Introduction 3
How to Use This Guide 4
Questions 5
Answers 8
Explanations 10
Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. What is the minimum width required for a wheelchair accessible door opening?

A. 30 inches

B. 32 inches

C. 34 inches

D. 36 inches

2. What is the required distance for a back wall grab bar from the center of the washer door?

A. 18 inches

B. 20 inches

C. 24 inches

D. 30 inches

3. If the intent of a contract cannot be determined, how is it interpreted?

A. It is voided

B. It goes against the party that wrote it

C. It is interpreted in favor of the party that benefits

D. It is deemed unenforceable

4. Which feature is essential for ensuring trusses perform effectively?

A. Aesthetics and color

B. Accurate measurements and proper bracing

C. Heavy materials

D. Bright markings

5. What does a payment bond guarantee?

A. Job completion for contractors

B. That subcontractors get paid

C. Securing the bid amount

D. Inspection of the project

SAMPLE

6. What is the typical relative humidity range to maintain during veneer plaster installation?

A. 10-30%

B. 40-60%

C. 20-50%

D. 30-70%

7. For a safety lanyard that can withstand great falls, what is the minimum capacity required?

A. 3000 lbs

B. 4500 lbs

C. 5400 lbs

D. 6000 lbs

8. How many revolutions should concrete undergo during delivery to ensure proper mixing?

A. 200 revolutions

B. 250 revolutions

C. 300 revolutions

D. 350 revolutions

9. What is the spacing requirement for wall ties?

A. 12" V and 24" H

B. 16" V and 32" H

C. 16" V and 24" or 32" H

D. 20" V and 28" H

10. What is the primary use of a bull float in concrete work?

A. To reinforce concrete

B. To add color

C. To level out highs and lows

D. To form edges

SAMPLE

Answers

SAMPLE

1. D
2. C
3. B
4. B
5. B
6. C
7. C
8. C
9. C
10. C

SAMPLE

Explanations

SAMPLE

1. What is the minimum width required for a wheelchair accessible door opening?

A. 30 inches

B. 32 inches

C. 34 inches

D. 36 inches

The minimum width required for a wheelchair accessible door opening is 36 inches. This standard is established to ensure that individuals using wheelchairs can easily pass through doorways without difficulty. A 36-inch opening accommodates a standard wheelchair's width and provides sufficient clearance for maneuvering. It is crucial to adhere to accessibility guidelines, such as those outlined by the Americans with Disabilities Act (ADA), which aim to provide equal access to all individuals. A wider door opening enhances accessibility, promoting independence and ease of movement for those with mobility challenges. Ensuring doors meet this minimum requirement not only complies with legal standards but also fosters inclusivity in buildings and facilities, benefiting all users.

2. What is the required distance for a back wall grab bar from the center of the washer door?

A. 18 inches

B. 20 inches

C. 24 inches

D. 30 inches

The correct distance for a back wall grab bar from the center of the washer door is 24 inches. This requirement is based on accessibility standards outlined in building guidelines and regulations, which aim to ensure safety and ease of use for individuals with disabilities. Placing the grab bar 24 inches from the center of the washer door provides enough space for the user to access the washer comfortably while maintaining support to assist with stability. This distance minimizes the risk of injury by ensuring that the grab bar can be used effectively without being too close to the potential obstruction of the washer door opening. Understanding these guidelines is essential for compliance with accessibility standards, ensuring that installations are safe and functional for all users.

3. If the intent of a contract cannot be determined, how is it interpreted?

A. It is voided

B. It goes against the party that wrote it

C. It is interpreted in favor of the party that benefits

D. It is deemed unenforceable

In contract law, when a contract's intent is unclear or ambiguous, it is often interpreted against the interests of the party that drafted it. This principle is rooted in fairness and aims to prevent one party from taking advantage of the other due to complex or unclear language that they themselves created. The rationale behind this approach, known as the doctrine of contra proferentem, is based on the idea that the drafter had the opportunity to clarify their intent but failed to do so. Therefore, if there is a dispute about the meaning of certain terms or clauses in the contract, the interpretation will favor the non-drafting party. This principle encourages drafters to be precise in their contract language, as they bear the responsibility for any ambiguities. This promotes fairness in contractual relationships and helps ensure that all parties have a clear understanding of their rights and obligations.

SAMPLE

4. Which feature is essential for ensuring trusses perform effectively?

A. Aesthetics and color

B. Accurate measurements and proper bracing

C. Heavy materials

D. Bright markings

Accurate measurements and proper bracing are crucial for ensuring that trusses perform effectively. Trusses are engineered structures made up of interconnected components that provide support and stability. When measurements are precise, it ensures that all parts fit together correctly and bear loads as intended. Any deviation in measurements can lead to misalignment, compromising the integrity of the truss. Additionally, proper bracing is vital because it adds stability and strength to the truss system, helping it withstand forces such as wind or seismic activity. Bracing distributes loads evenly and prevents the trusses from twisting or collapsing under pressure. Therefore, both accurate measurements and proper bracing work in tandem to maintain the functionality and safety of the truss design in construction.

5. What does a payment bond guarantee?

A. Job completion for contractors

B. That subcontractors get paid

C. Securing the bid amount

D. Inspection of the project

A payment bond is a type of surety bond that primarily ensures that subcontractors and suppliers involved in a construction project are paid promptly and fully for their work. When a contractor provides a payment bond, it acts as a financial guarantee that the contractor will fulfill their obligation to compensate those parties. This protects subcontractors and suppliers from non-payment, which can occur if the primary contractor faces financial difficulties or disputes arise. The purpose of the payment bond is critical in ensuring a smooth workflow on a construction site, as it alleviates concerns over payment, allowing subcontractors and suppliers to focus on their work without fear of financial loss. This is essential not only for the economic health of these smaller entities but also for maintaining good relationships among all parties involved in a construction project. In contrast, other options do not accurately reflect the nature of a payment bond. Job completion pertains more to performance bonds, securing the bid amount is related to bid bonds, and inspection of the project is not a function of bonds at all, but rather falls under regulatory or contractual obligations.

6. What is the typical relative humidity range to maintain during veneer plaster installation?

A. 10-30%

B. 40-60%

C. 20-50%

D. 30-70%

The correct choice reflects the typical relative humidity range of 20-50% that is ideal for veneer plaster installation. Maintaining this humidity level is crucial because it helps to ensure proper curing and drying of the plaster. If the relative humidity is too low, it can lead to rapid drying, which may cause cracks or poor adhesion. Conversely, if the humidity levels are too high, it can slow down the curing process significantly, which can lead to surface issues and affect the overall quality of the finish. Veneer plaster is a thin layer applied over a substrate, and achieving the right balance of moisture in the environment aids in the formation of a durable and aesthetically pleasing surface. Adhering to the recommended humidity helps contractors achieve consistent results and reduce the risk of post-installation problems. Understanding and regulating the relative humidity during application is essential to ensure the longevity and functionality of the plaster work.

SAMPLE

7. For a safety lanyard that can withstand great falls, what is the minimum capacity required?

A. 3000 lbs

B. 4500 lbs

C. 5400 lbs

D. 6000 lbs

The minimum capacity required for a safety lanyard designed to withstand significant falls is 5,400 pounds. This specification is rooted in industry safety standards, which ensure that fall protection gear can handle the forces exerted during a fall without breaking. Safety lanyards are crucial in preventing serious injuries or fatalities when workers are at height. During a fall, the force exerted can far exceed a person's body weight due to the acceleration of gravity. Therefore, the materials and construction of the lanyard must be robust enough to absorb these forces and ensure the user's safety. The choice of 5,400 pounds takes into consideration not just the weight of the individual but also the dynamic forces involved during a fall. This higher capacity provides an essential safety margin, helping to accommodate differences in individual weights and the potential for swinging or other forces that may occur during a fall. Compliance with this minimum standard helps ensure that workers are provided with effective fall protection when working at heights.

8. How many revolutions should concrete undergo during delivery to ensure proper mixing?

A. 200 revolutions

B. 250 revolutions

C. 300 revolutions

D. 350 revolutions

The requirement for the number of revolutions a concrete mixer should undergo during delivery primarily ensures that the concrete remains homogeneous and properly mixed. The correct answer is that concrete should typically undergo 300 revolutions during transit to ensure that the ingredients are well blended and maintain the desired workability. This number is significant because after a certain point, too many revolutions can lead to the breakdown of the aggregate and subsequentially affect the performance of the concrete. The standard guideline, which recommends 300 revolutions, strikes a balance that maintains the mix while preventing it from becoming too dry or over-mixed. Choosing this number helps to optimize the quality of the concrete, ensuring consistency and durability in the finished product. It reflects industry standards and protocols that are designed to maintain the integrity of the concrete mix during transportation and handling.

SAMPLE

9. What is the spacing requirement for wall ties?

A. 12" V and 24" H

B. 16" V and 32" H

C. 16" V and 24" or 32" H

D. 20" V and 28" H

The spacing requirement for wall ties is crucial for ensuring the structural integrity and stability of masonry walls. The correct answer indicates that wall ties should be placed vertically at 16 inches and horizontally at either 24 inches or 32 inches. This standard spacing helps to adequately support the weight of the wall and distribute loads evenly. Properly spaced wall ties create an effective connection between the masonry wall and the structure it supports, preventing bowing or cracking that can result from improper support. The vertical spacing of 16 inches is commonly accepted to ensure there is enough tie support along the height of the wall, which is important for maintaining not just structural integrity but also to resist lateral forces like wind. The horizontal spacing choices of either 24 inches or 32 inches allow for some flexibility while still adhering to the necessary guidelines for wall construction. This spacing helps ensure that ties are adequately placed to provide stability across the length of the wall, which is vital when considering factors like thermal expansion and contraction, as well as potential movement of the structure. In summary, the spacing of 16 inches vertically and 24 or 32 inches horizontally is based on sound engineering practices and standards, which ensure that masonry walls perform effectively under various loads and conditions.

10. What is the primary use of a bull float in concrete work?

A. To reinforce concrete

B. To add color

C. To level out highs and lows

D. To form edges

In concrete work, a bull float is primarily used to level out highs and lows in freshly poured concrete. This tool is designed to create a smooth, even surface by bridging over uneven areas. When used right after the concrete is poured and before it has set, the bull float helps to push down the aggregate materials that may have floated to the surface, while also pulling up some of the wetter, finer concrete mixture from below. This results in a more uniform surface that's crucial for subsequent finishing processes. While reinforcing concrete, adding color, and forming edges are important aspects of concrete work, they do not specifically relate to the function of a bull float. The bull float's main job is to ensure that the surface of the concrete slab is as flat and level as possible, making option C the correct answer.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://nasclegeneralcontractor.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE