
NATIONAL COUNCIL OF EXAMINERS FOR ENGINEERING AND SURVEYING (NCEES) FUNDAMENTALS OF ENGINEERING (FE) ELECTRICAL AND COMPUTER PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://ncees-fe-electricalandcomputer.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which value of s represents a damped sinusoid?

A. $s = \sigma$

B. $s = j\omega$

C. $s = \sigma + j\omega$

D. $s = 0$

2. What is typically affected by high latency in digital communication?

A. Data transfer rate

B. System redundancy

C. Responsiveness of the communication system

D. Signal strength

3. What term describes the open-circuit voltage, V(open circuit), at the terminals of interest?

A. Thevenin equivalent current

B. Thevenin equivalent voltage

C. Norton equivalent voltage

D. Voltage reference

4. What does CMRR stand for in electrical engineering?

A. Common Mode Rejection Ratio

B. Current Modulation Reduction Ratio

C. Common Mode Response Rate

D. Capacitance Modulation Ratio

5. What term describes the outflow of electrons into a vacuum from a heated conductor?

A. Thermal emission

B. Photoelectric effect

C. Electron discharge

D. Electric conduction

SAMPLE

6. What term describes a circuit that has the same voltage across all its elements?

A. Series circuit

B. Open circuit

C. Parallel circuit

D. Nodal circuit

7. What is the full name of the code represented by the acronym NESC?

A. National Electrical Safety Code

B. National Electrical Standards Code

C. National Engineering Safety Code

D. North American Electrical Safety Code

8. What is the formula for the impedance of an inductor in the s-domain?

A. s/R

B. 1/sL

C. sL

D. L/s

9. Which of the following best describes a Bode plot?

A. A visual representation of time-variant system behavior

B. A graph showing a system's frequency response including magnitude and phase

C. A chart measuring the temperature effects on electrical resistance

D. A plot outlining circuit diagram layouts

10. What distinguishes a series circuit from a parallel circuit?

A. Series circuits have multiple paths for current flow

B. Series circuits have components connected in a single path

C. Parallel circuits have higher voltage ratings than series circuits

D. Parallel circuits always consume more power than series circuits

SAMPLE

Answers

SAMPLE

1. C
2. C
3. B
4. A
5. B
6. C
7. A
8. C
9. B
10. B

SAMPLE

Explanations

SAMPLE

1. Which value of s represents a damped sinusoid?

A. $s = \sigma$

B. $s = j\omega$

C. $s = \sigma + j\omega$

D. $s = 0$

A damped sinusoid can be represented in terms of a complex frequency variable, which takes into account both the oscillatory and decaying nature of the signal. The variable s encapsulates these characteristics by incorporating both a real part and an imaginary part. In this context, $s = \sigma + j\omega$ effectively represents a damped sinusoidal signal. Here, σ (the real part) represents the damping factor. When σ is positive, it indicates that the amplitude of the sinusoidal waveform is decreasing over time, which is characteristic of damping. The term $j\omega$ (the imaginary part) represents the oscillation frequency, where ω is the angular frequency of the sinusoid. Thus, the combination $\sigma + j\omega$ allows for the representation of a waveform that not only oscillates but also gradually decreases in amplitude—qualifying it as a damped sinusoid. This formulation arises commonly in the analysis of differential equations and control systems, where damping plays a crucial role in the behavior of dynamic systems. In contrast, having solely σ denotes no oscillation, solely $j\omega$ indicates oscillation without decay, and a value of zero does not represent any signal characteristics relevant to damping.

2. What is typically affected by high latency in digital communication?

A. Data transfer rate

B. System redundancy

C. Responsiveness of the communication system

D. Signal strength

High latency in digital communication primarily impacts the responsiveness of the communication system. Latency refers to the time delay experienced in a system, particularly in transmitting signals or data from one point to another. In scenarios where quick feedback or real-time communication is essential—such as online gaming, video conferencing, or interactive applications—high latency can lead to noticeable delays in receiving and processing information, resulting in decreased responsiveness. While data transfer rate, system redundancy, and signal strength are all relevant to communication systems, they are not directly impacted by latency. Data transfer rate pertains to how fast data can be sent over a network, which operates independently of latency. System redundancy refers to the inclusion of additional components or systems for reliability and fault tolerance; this concept is not influenced by latency. Signal strength relates to the power level of the transmitted signal, which can affect the quality of the communication but does not inherently involve the time delays introduced by latency. Therefore, the correct answer is that high latency primarily affects the responsiveness of the communication system.

SAMPLE

3. What term describes the open-circuit voltage, V(open circuit), at the terminals of interest?

A. Thevenin equivalent current

B. Thevenin equivalent voltage

C. Norton equivalent voltage

D. Voltage reference

The open-circuit voltage at the terminals of interest is referred to as Thevenin equivalent voltage. This is a fundamental concept in circuit analysis based on Thevenin's theorem, which states that any linear electrical network can be represented as an equivalent circuit consisting of a single voltage source (the Thevenin equivalent voltage) in series with a resistor (the Thevenin equivalent resistance). When determining the open-circuit voltage, the load is not connected, and the voltage measured across the terminals represents the maximum potential difference available from the circuit. It is this value that is referred to as the Thevenin equivalent voltage, as it simplifies the analysis of complex circuits by allowing engineers to replace a network with a simple voltage source and resistance. Understanding Thevenin equivalent voltage is crucial for analyzing and designing circuits, as it facilitates easier calculations for various configurations without needing to delve into the details of the entire circuit each time.

4. What does CMRR stand for in electrical engineering?

A. Common Mode Rejection Ratio

B. Current Modulation Reduction Ratio

C. Common Mode Response Rate

D. Capacitance Modulation Ratio

The term CMRR stands for Common Mode Rejection Ratio. This parameter is vital in the context of differential amplifiers and operational amplifiers, as it quantifies the ability of an amplifier to reject input signals that are common to both input terminals. In other words, CMRR measures how effectively the amplifier can differentiate between the desired differential signal and any unwanted noise or interference that appears equally on both inputs, which is crucial for maintaining signal integrity in various electronic applications. The significance of a high CMRR value is that it indicates the amplifier's effectiveness in minimizing common mode signals, allowing for clearer and more accurate amplification of the intended signal. A higher CMRR implies better performance in rejecting noise and common mode interference, making it an essential specification in applications where precision and accuracy are critical, such as in audio equipment, instrumentation, and communication systems.

SAMPLE

5. What term describes the outflow of electrons into a vacuum from a heated conductor?

A. Thermal emission

B. Photoelectric effect

C. Electron discharge

D. Electric conduction

The phenomenon described in the question, where electrons are emitted from a heated conductor into a vacuum, is best labeled as thermal emission. This process occurs when the thermal energy provided to the electrons within the conductor allows them to overcome the work function of the material, enabling them to escape into the vacuum. Thermal emission specifically refers to the emission of electrons due to the heating of a material, distinguishing it from other phenomena involving electron movement or emission. For example, the photoelectric effect involves the emission of electrons as a result of light exposure, not thermal energy. Electron discharge typically refers to the flow of electrons within a medium, like from a charged object to a neutral one, rather than their emission into a vacuum. Electric conduction involves the movement of electrons through a conductive medium in response to an electric field, fundamentally differing from the emission process described in the question.

6. What term describes a circuit that has the same voltage across all its elements?

A. Series circuit

B. Open circuit

C. Parallel circuit

D. Nodal circuit

A circuit that has the same voltage across all its elements is referred to as a parallel circuit. In a parallel configuration, each component is connected across the same two nodes, which ensures that the voltage across each element is identical. This characteristic is fundamental to parallel circuits, making them widely used in various applications, such as household wiring, where devices can operate independently of each other while still receiving the same voltage from a shared source. In contrast, a series circuit is characterized by components connected in a single path, where the voltage is divided among the components, and thus, each component does not receive the same voltage. An open circuit signifies that there is a break in the path, meaning no current flows and is not a valid description of any consistent voltage across elements. A nodal circuit typically refers to the graphical representation of connections (nodes) and is not a standard term used to classify the voltage behavior across elements.

SAMPLE

7. What is the full name of the code represented by the acronym NESC?

A. National Electrical Safety Code

B. National Electrical Standards Code

C. National Engineering Safety Code

D. North American Electrical Safety Code

The acronym NESC stands for the National Electrical Safety Code. This code is crucial as it provides guidelines and regulations for the safe installation and maintenance of electric supply and communication lines and equipment. It is recognized as a standard for ensuring safety in electrical systems and addresses various aspects such as clearances, grounding, and the overall safety protocols that must be followed to protect both workers and the public. Understanding the NESC is essential for electrical engineers and practitioners, as it helps to ensure compliance with safety regulations and reduces the risk of electrical accidents. The code is updated periodically to reflect advancements in technology and industry practices, emphasizing its importance in maintaining a safe electrical infrastructure.

8. What is the formula for the impedance of an inductor in the s-domain?

A. s/R

B. 1/sL

C. sL

D. L/s

*The formula for the impedance of an inductor in the s-domain is expressed as sL. In the s-domain, which is used for analyzing systems in the Laplace transform framework, the relationship between current and voltage across inductive elements becomes more straightforward. Impedance, which combines resistance and reactance, is mainly determined by the inductive reactance in the case of an inductor. The general form of impedance for an inductor can be derived from the Laplace transform of its differential equation. For an inductor, the voltage-current relationship is defined by the equation V(s) = sL * I(s), where V(s) is the voltage across the inductor, I(s) is the current through it, and L is the inductance. Rearranged, this gives us the expression for impedance: Z(s) = V(s)/I(s) = sL. This formulation indicates that the impedance of the inductor increases linearly with frequency (indicated by 's'), highlighting that inductors resist changes in current. In analysis and design of electrical circuits involving inductive loads, this relationship is essential for understanding the behavior of circuits in response to various inputs.*

9. Which of the following best describes a Bode plot?

A. A visual representation of time-variant system behavior

B. A graph showing a system's frequency response including magnitude and phase

C. A chart measuring the temperature effects on electrical resistance

D. A plot outlining circuit diagram layouts

A Bode plot is specifically designed to represent a system's frequency response, which includes both magnitude and phase characteristics. It consists of two separate plots: one for magnitude (typically in decibels) versus frequency (usually in a logarithmic scale) and another for phase (in degrees) versus frequency. This dual representation allows engineers to analyze how a system responds to different frequencies of input signals, making it a crucial tool in control theory and signal processing. The primary utility of the Bode plot is to help engineers understand the stability and transient response of systems, particularly in feedback control systems, by providing insights into gain margins and phase margins. Given its focus on frequency response, it effectively captures the dynamic behavior of linear time-invariant systems under sinusoidal steady-state conditions. In contrast, options that refer to time-variant systems, temperature effects on resistance, or circuit layout diagrams do not align with the characteristics of a Bode plot. A Bode plot is strictly concerned with frequency response analysis rather than temporal behavior or general circuit analysis.

SAMPLE

10. What distinguishes a series circuit from a parallel circuit?

A. Series circuits have multiple paths for current flow

B. Series circuits have components connected in a single path

C. Parallel circuits have higher voltage ratings than series circuits

D. Parallel circuits always consume more power than series circuits

In a series circuit, components are connected in a single path, which means that the current flows through each component sequentially. This configuration dictates that the same current flows through all the components in the circuit, and the total resistance is simply the sum of the individual resistances. If any component in a series circuit fails or is disconnected, the entire circuit is interrupted and ceases to function. This single-path connection is what characterizes series circuits as opposed to parallel circuits, where components are connected across common points creating multiple paths for current flow. In a parallel circuit, if one branch fails, the current can still flow through the other branches, allowing the circuit to remain operational. Understanding this fundamental distinction is essential when analyzing circuits, as it affects their behavior in terms of resistance, voltage distribution, and overall operation.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://ncees-fe-electricalandcomputer.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE