
OHIO LEAD RISK ASSESSOR PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://ohleadriskassessor.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. When is it appropriate to test more than one door in the same room?

A. When the doors are differently painted/glazed

B. When the doors are made of different materials

C. When the doors are of different ages

D. When the doors are located on exterior walls

2. What calculation is made when the lab finds lead in a wipe sample?

A. Total dust weight is measured

B. Concentration is calculated in ug/ft²

C. Size of the wipe area is determined

D. Sample volume is estimated

3. What is the mandated maximum lead dust standard for window sills according to Title X?

A. 40 mcg/ft2

B. 100 mcg/ft2

C. 15 ppb

D. 10 mcg/ft2

4. Why is understanding the spatial variation of lead significant for assessors?

A. It simplifies the testing procedure

B. It ensures adequate training for assessors

C. It helps in obtaining accurate assessments

D. It makes lead management unnecessary

5. Why did the popularity of lead-based paint decline in the 1950s?

A. Due to health concerns about led exposure

B. Because of rising costs of materials

C. Latex paint became cheaper and more popular

D. Government regulations banning its use

SAMPLE

6. What was the federal limit for lead in residential paint set in 1978?

A. 0.1%

B. 0.06%

C. 1%

D. 0.5%

7. What blood lead level triggers the need for additional blood tests according to OSHA?

A. 20 ug/dL

B. 30 ug/dL

C. 40 ug/dL

D. 50 ug/dL

8. How many dust wipe samples should be taken for childcare facilities in multi-family complexes?

A. 1 floor and 1 window sill

B. 2 floors, 1 window sill, and 1 window trough

C. 3 floors and 2 window troughs

D. 5 floors and multiple window samples

9. If there is deteriorated paint known not to be lead-based paint, what action should be recommended if the lead level is above 1 mg/cm²?

A. Ignore it

B. Remove it immediately

C. Repair the paint

D. Encapsulate the paint

10. Which of the following is NOT one of the six substrates recommended by HUD?

A. Concrete

B. Glass

C. Metal

D. Drywall

SAMPLE

Answers

SAMPLE

1. A
2. B
3. B
4. C
5. C
6. B
7. C
8. B
9. C
10. B

SAMPLE

Explanations

SAMPLE

1. When is it appropriate to test more than one door in the same room?

A. When the doors are differently painted/glazed

B. When the doors are made of different materials

C. When the doors are of different ages

D. When the doors are located on exterior walls

Testing more than one door in the same room is appropriate when the doors are differently painted or glazed. The reason for this is that different finishes can significantly affect the amount of lead dust that might settle on the surface and the risk of lead exposure. Paint applied to surfaces can contain varying amounts of lead, and if the doors have been painted or glazed with different materials or colors, they may present different risks for lead exposure. The condition and composition of the paint are critical factors to understand when assessing lead hazards. Different paint types can degrade at different rates, and if one door has a lead-based paint while another does not, this creates the need for separate testing. Therefore, identifying these variations helps to ensure a thorough assessment of potential lead risks. While testing doors based on their materials, ages, or locations could offer insights into the lead hazard context, the specific focus on differences in paint or glaze is pivotal because it directly relates to lead exposure risk assessments.

2. What calculation is made when the lab finds lead in a wipe sample?

A. Total dust weight is measured

B. Concentration is calculated in ug/ft²

C. Size of the wipe area is determined

D. Sample volume is estimated

When a laboratory finds lead in a wipe sample, it performs a concentration calculation that provides the amount of lead in micrograms per square foot (ug/ft²). This measurement is crucial because it helps determine the level of lead contamination on surfaces, which is vital for assessing the potential risk of exposure in environments, especially those frequented by children or pregnant women. The concentration in micrograms per square foot gives a clear indication of the severity of contamination. Health guidelines often have specific thresholds for lead levels that dictate whether remediation is necessary. By calculating the concentration, assessors can make informed decisions about the safety of the environment and whether intervention is needed to reduce lead exposure risk. The other processes, while related to sample collection and analysis, do not directly measure the concentration of lead in the way that this calculation does. Understanding the concentration allows for effective assessment and management of lead-related health risks.

3. What is the mandated maximum lead dust standard for window sills according to Title X?

A. 40 mcg/ft2

B. 100 mcg/ft2

C. 15 ppb

D. 10 mcg/ft2

The mandated maximum lead dust standard for window sills according to Title X is 100 micrograms per square foot (mcg/ft²). This standard is significant because it sets a threshold for the allowable concentration of lead dust in residential environments, particularly where young children may be exposed. The high sensitivity of children to lead exposure necessitates strict guidelines to reduce health risks associated with lead poisoning. While there are lower standards established for other surfaces, such as floors or play areas, the window sill standard specifically focuses on areas where dust may accumulate and where children often come into contact with contaminated surfaces. Setting the standard at 100 mcg/ft² reflects a balance between practical cleaning guidelines and protective measures for public health, ensuring that property owners and lead risk assessors have clear criteria to evaluate and mitigate lead dust hazards effectively.

SAMPLE

4. Why is understanding the spatial variation of lead significant for assessors?

A. It simplifies the testing procedure

B. It ensures adequate training for assessors

C. It helps in obtaining accurate assessments

D. It makes lead management unnecessary

Understanding the spatial variation of lead is critical for assessors because it directly impacts the accuracy of lead assessments. Spatial variation refers to how lead contamination levels can differ from one location to another within a given area. Recognizing these variations allows assessors to identify specific locations that may pose a higher risk for lead exposure, which is essential for effective risk management. Accurate assessments are essential for determining the presence and concentration of lead in residential or environmental settings. Without considering spatial variation, an assessment could underestimate or overestimate lead levels, leading to inadequate responses to lead hazards. For instance, if an assessor conducts testing without accounting for known variations in lead presence, such as near older buildings or specific soil types, the results may not reflect the true risk. This can have significant public health implications, especially for vulnerable populations, such as children, who are at higher risk of lead exposure. Essentially, a thorough understanding of how lead levels can vary spatially allows assessors to create more targeted and effective testing strategies, ensuring a more comprehensive and reliable evaluation of potential lead hazards.

5. Why did the popularity of lead-based paint decline in the 1950s?

A. Due to health concerns about led exposure

B. Because of rising costs of materials

C. Latex paint became cheaper and more popular

D. Government regulations banning its use

The decline in the popularity of lead-based paint during the 1950s was significantly influenced by the rise of latex paint, which became a more favorable option for consumers due to several factors. Latex paint, being water-based, offered advantages such as easier cleanup, lower toxicity, and reduced odor compared to lead-based paints. As consumers became more aware of these benefits, they began to prefer latex paint for both interior and exterior applications. This shift was also accompanied by advancements in paint technology that made latex paints more durable and versatile, making them an increasingly attractive option for homeowners and contractors. While health concerns over lead exposure, rising material costs, and government regulations did play roles in limiting the use of lead-based paint, the immediate driver in the 1950s was the growing preference for the qualities that latex paints provided. The combination of economic factors, including the availability of affordable alternatives, contributed to the decline of lead-based paint's popularity during that era.

SAMPLE

6. What was the federal limit for lead in residential paint set in 1978?

A. 0.1%

B. 0.06%

C. 1%

D. 0.5%

The federal limit for lead in residential paint set in 1978 was established as 0.06% by weight, which was a significant regulatory step to address the dangers of lead exposure, particularly in homes where children might be at risk. This regulation aimed to reduce lead poisoning cases caused by lead-based paints, which were commonly used in homes built before the changes were enforced. Setting a specific limit was crucial, as it provided a clear guideline for manufacturers and homeowners about the allowable levels of lead in paint. By regulating the amount of lead, the federal government sought to minimize health risks associated with lead poisoning, especially in vulnerable populations such as children and pregnant women. This historical limit is an important aspect of lead safety regulations and is often referenced in discussions about lead hazard assessments and ongoing public health efforts to reduce lead exposure in the residential environment.

7. What blood lead level triggers the need for additional blood tests according to OSHA?

A. 20 ug/dL

B. 30 ug/dL

C. 40 ug/dL

D. 50 ug/dL

The threshold for triggering additional blood tests according to OSHA is a blood lead level of 40 micrograms per deciliter (ug/dL). When this level is reached, it indicates a significant level of lead exposure that requires further investigation and monitoring. This protocol is designed to ensure the safety and health of individuals, particularly in occupational settings where lead exposure is a risk. At this level, it becomes critical to assess not only the individual's health but also to implement measures to reduce future lead exposure and ensure compliance with health regulations. Continuous monitoring and follow-up tests are essential to prevent long-term health effects associated with elevated lead levels. Thus, the identification of the 40 ug/dL threshold is a key aspect of lead risk management in the workplace.

SAMPLE

8. How many dust wipe samples should be taken for childcare facilities in multi-family complexes?

A. 1 floor and 1 window sill

B. 2 floors, 1 window sill, and 1 window trough

C. 3 floors and 2 window troughs

D. 5 floors and multiple window samples

Taking dust wipe samples in childcare facilities within multi-family complexes is essential for assessing lead contamination risks. The correct approach is to collect samples from multiple locations to ensure a comprehensive evaluation of potential lead exposure. The answer specifying two floors, one window sill, and one window trough is correct because it provides a balanced assessment of lead dust in high-use areas (floors) where children may spend significant time and come into contact with lead-contaminated dust or dirt. The inclusion of a window sill is particularly important, as window sills can accumulate dust that may have lead from sources like deteriorating paint. Additionally, the window trough is an area where dust can also collect, and it is critical to assess for lead presence in these more confined spaces. In contrast, the other choices do not provide the optimal combination of sampling locations for evaluating lead hazards in a childcare setting. For instance, collecting samples from just one floor and one window sill may not adequately reflect the overall lead risk present throughout the facility. Similarly, excessively high sampling like five floors or multiple window samples could lead to unnecessary complexity and cost without significantly enhancing the assessment's efficiency or effectiveness. The goal is to balance thorough sampling with reasonable coverage for accurate risk assessment.

9. If there is deteriorated paint known not to be lead-based paint, what action should be recommended if the lead level is above 1 mg/cm²?

A. Ignore it

B. Remove it immediately

C. Repair the paint

D. Encapsulate the paint

When dealing with deteriorated paint that is confirmed not to be lead-based but still has a lead level measuring above 1 mg/cm², recommending repair is a crucial step. This is because while the paint itself is not classified as lead-based, the presence of lead at that level indicates a potential hazard that needs to be addressed. Repairing the paint involves making appropriate interventions to stabilize the surface and prevent further deterioration, which could lead to increased lead exposure. Such repairs might include patching, repainting with a lead-safe primer, and ensuring that the surrounding area is cleaned appropriately to minimize any risks associated with lead dust. Choosing to ignore the issue would pose a continued risk for exposure to lead particles for inhabitants, particularly vulnerable populations such as children, who are more susceptible to the health effects of lead. Removing the paint immediately might not be necessary if it is not lead-based and could also lead to unnecessary disruptions and costs. Encapsulation could be an option, but since the paint is not lead-based, repairing retains the integrity of the structure while adequately addressing the lead concern. Thus, recommending repair of the paint is the most balanced approach, focusing on safety while considering the actual composition of the paint in question.

SAMPLE

10. Which of the following is NOT one of the six substrates recommended by HUD?

A. Concrete

B. Glass

C. Metal

D. Drywall

The recommended substrates by HUD (the U.S. Department of Housing and Urban Development) for lead-based paint risk assessments are designed to encompass a variety of materials that may be found in residential environments. These six substrates include materials that are commonly used in housing and can have lead-based paint when the home was built before 1978, the year when the U.S. banned the use of lead in residential paint. Glass, while it can be surface-coated with paint or lead-based materials, is not typically classified as a substrate in the same way that concrete, metal, and drywall are. Concrete, metal, and drywall are structural or functional materials commonly found in homes and are often painted, making them relevant to lead assessments. Choosing glass as a non-substrate reflects its limited association with lead-based paint in the context of HUD's recommended practices, as it is generally not considered a principal surface for lead risks. This distinction emphasizes the types of materials that are more effectively checked and assessed for lead hazards within the home.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://ohleadriskassessor.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE