

PHYSIOLOGIC AND MONITORING PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR
THE FULL VERSION STUDY GUIDE

<https://physiologicmonitoring.examzify.com>



Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright	1
Table of Contents	2
Introduction	3
How to Use This Guide	4
Questions	5
Answers	8
Explanations	10
Next Steps	15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

Questions

SAMPLE

1. **CaO₂ includes the dissolved oxygen term in addition to oxygen bound to hemoglobin.**
 - A. CaO₂ is based only on SaO₂ and Hb.
 - B. CaO₂ depends only on Hb.
 - C. CaO₂ ignores PaO₂.
 - D. CaO₂ includes the dissolved oxygen term $0.003 \times \text{PaO}_2$ in addition to the oxygen bound to Hb.
2. **What is alarm fatigue and a practical strategy to mitigate it in a monitoring environment?**
 - A. Alarm fatigue is desensitization from excessive alarms; mitigate with appropriate alarm limits, prioritization, customization, routine maintenance
 - B. Alarm fatigue is a rare phenomenon; mitigate by increasing alarm volume
 - C. Alarm fatigue only occurs in the ICU; mitigate by ignoring alarms
 - D. Alarm fatigue is caused by device malfunctions; mitigate by replacing devices
3. **What is the normal serum potassium range?**
 - A. 2.5-4.5 mEq/L
 - B. 3.5-5.0 mEq/L
 - C. 4.0-6.0 mEq/L
 - D. 3.0-4.5 mEq/L
4. **Auto-PEEP is best described as?**
 - A. Air trapping due to incomplete expiration
 - B. Improved oxygenation with full exhalation
 - C. Reduced dead space ventilation
 - D. Decreased airway resistance
5. **Which change would shift the Frank-Starling curve downward?**
 - A. Administration of a beta-blocker (negative inotropic)
 - B. Administration of a positive inotropic drug
 - C. Increasing preload
 - D. Decreasing afterload

- 6. During chest compressions in CPR, how might arterial line readings be affected?**
- A. Distorted pulsatile waveform; arterial pressures influenced by CPR; rely on clinical context and correlate with ROSC.
 - B. Arterial line readings are unaffected by CPR.
 - C. CPR improves arterial waveform fidelity.
 - D. Arterial line readings are contraindicated during CPR.
- 7. What data points does a pulmonary artery catheter measure?**
- A. RA pressure, pulmonary artery pressures, SvO₂, CO by thermodilution
 - B. Central venous pressure only
 - C. Arterial blood pressure and heart rate
 - D. Airway pressures only
- 8. Which characteristic best describes two-wavelength pulse oximeters compared to bench co-oximeters?**
- A. They provide continuous, real-time data and never require daily clinician calibration.
 - B. They require arterial blood sampling for operation.
 - C. They provide only snapshot data and must be calibrated monthly.
 - D. They rely on external calibration curves that must be updated weekly.
- 9. What is the approximate normal value for VO₂?**
- A. 100 mL/min
 - B. 250 mL/min
 - C. 500 mL/min
 - D. 1000 mL/min
- 10. What happens when preload is excessive and surpasses the heart's optimal stretch point?**
- A. Stroke volume increases with preload indefinitely
 - B. Stroke volume decreases due to overdistension
 - C. Preload has no effect on stroke volume
 - D. Afterload is the only determinant of stroke volume

Answers

SAMPLE

1. D
2. A
3. B
4. A
5. A
6. A
7. A
8. A
9. B
10. B

SAMPLE

Explanations

SAMPLE

1. CaO₂ includes the dissolved oxygen term in addition to oxygen bound to hemoglobin.

- A. CaO₂ is based only on SaO₂ and Hb.
- B. CaO₂ depends only on Hb.
- C. CaO₂ ignores PaO₂.

D. CaO₂ includes the dissolved oxygen term $0.003 \times \text{PaO}_2$ in addition to the oxygen bound to Hb.

Arterial oxygen content is the sum of two parts: oxygen bound to hemoglobin and oxygen dissolved in plasma. The bound portion depends on how much hemoglobin there is and how saturated it is with oxygen, calculated as Hb concentration times 1.34 mL O₂ per gram times SaO₂. The dissolved portion, though smaller, comes from oxygen freely dissolved in plasma and is proportional to PaO₂ with a solubility of about 0.003 mL O₂ per dL of blood per mmHg. Put together, $\text{CaO}_2 = (\text{Hb} \times 1.34 \times \text{SaO}_2) + (\text{PaO}_2 \times 0.003)$. This is why including the dissolved oxygen term $0.003 \times \text{PaO}_2$ in addition to the Hb-bound oxygen correctly describes CaO₂. The dissolved term ensures PaO₂ contributes to overall oxygen content, not just saturation and Hb amount.

2. What is alarm fatigue and a practical strategy to mitigate it in a monitoring environment?

A. Alarm fatigue is desensitization from excessive alarms; mitigate with appropriate alarm limits, prioritization, customization, routine maintenance

- B. Alarm fatigue is a rare phenomenon; mitigate by increasing alarm volume
- C. Alarm fatigue only occurs in the ICU; mitigate by ignoring alarms
- D. Alarm fatigue is caused by device malfunctions; mitigate by replacing devices

Alarm fatigue is the desensitization that occurs when clinicians are exposed to a high volume of alarms, many of which are false or nonactionable. This can lead to slower responses or missed critical alerts, putting patients at risk in any monitoring environment. A practical way to mitigate it is to manage alarms effectively: set appropriate alarm limits so only clinically meaningful changes trigger alerts, prioritize and customize alarms to the specific patient and situation, and perform regular maintenance and sensor checks to reduce false or nonactionable alarms. By reducing nuisance alarms while preserving true emergencies, the monitoring system remains responsive and safer.

3. What is the normal serum potassium range?

- A. 2.5-4.5 mEq/L
- B. 3.5-5.0 mEq/L
- C. 4.0-6.0 mEq/L
- D. 3.0-4.5 mEq/L

Normal serum potassium is about 3.5 to 5.0 mEq/L. Potassium primarily sits inside cells, and extracellular levels fine tune the resting membrane potential of excitable tissues such as nerves, skeletal muscle, and the heart. Small shifts outside this range can significantly affect how easily these tissues depolarize and conduct impulses. If potassium falls below 3.5, muscles can become weak and irregularities in cardiac rhythm may occur. If it rises above 5.0, the heart and nerves can become overly excitable or conduct abnormally, leading to dangerous rhythm problems. Clinically, labs may list a range that varies slightly (some say up to 5.5), but the commonly used normal range is 3.5–5.0 mEq/L. Also be aware that improper sample handling (like hemolysis) can falsely raise potassium readings.

4. Auto-PEEP is best described as?

- A. Air trapping due to incomplete expiration
- B. Improved oxygenation with full exhalation
- C. Reduced dead space ventilation
- D. Decreased airway resistance

Auto-PEEP is air trapping that happens when expiration is incomplete before the next breath starts, so positive pressure remains in the airways at the end of expiration. This intrinsic PEEP builds up on the ventilator when the expiratory time is too short, or airway resistance is high, or the respiratory rate is rapid. The result is dynamic hyperinflation, higher end-expiratory airway pressure, and can impair venous return and hemodynamics, with a risk of barotrauma. This description fits best because it emphasizes air trapping from incomplete expiration rather than any improvement in oxygenation, reduction in dead space, or decrease in airway resistance.

5. Which change would shift the Frank-Starling curve downward?

- A. Administration of a beta-blocker (negative inotropic)
- B. Administration of a positive inotropic drug
- C. Increasing preload
- D. Decreasing afterload

The key idea is that the Frank-Starling curve shows how much the heart can pump (stroke volume) for a given amount of filling (preload). The curve's position is determined by contractility—the heart's ability to generate force. When contractility falls, the ventricle can eject less blood for the same filling, so the entire curve shifts downward. Administering a beta-blocker reduces contractility (negative inotropy), so for any level of preload the stroke volume is lower, moving the curve downward. Increasing preload or moving along the curve simply changes the operating point along the same curve. A positive inotropic drug would raise the curve, increasing stroke volume at the same preload, while decreasing afterload alters the flow at a given preload but doesn't shift the curve itself.

6. During chest compressions in CPR, how might arterial line readings be affected?

- A. Distorted pulsatile waveform; arterial pressures influenced by CPR; rely on clinical context and correlate with ROSC.
- B. Arterial line readings are unaffected by CPR.
- C. CPR improves arterial waveform fidelity.
- D. Arterial line readings are contraindicated during CPR.

During chest compressions, arterial line readings can be distorted because the mechanical force of CPR transmits pulses into the arterial system and intrathoracic pressures change with each compression. This makes the arterial pressure waveform pulsatile but often irregular or distorted, so the numbers may reflect compression quality rather than true hemodynamic status. Interpret these readings in the clinical context and correlate with return of spontaneous circulation (ROSC) when assessing improvement. A meaningful, sustained change in arterial pressure or waveform after compressions stop is more consistent with ROSC. Arterial lines are not inherently contraindicated during CPR, but their readings are not reliable on their own and require cautious interpretation.

7. What data points does a pulmonary artery catheter measure?

- A. RA pressure, pulmonary artery pressures, SvO₂, CO by thermodilution
- B. Central venous pressure only
- C. Arterial blood pressure and heart rate
- D. Airway pressures only

A pulmonary artery catheter provides a spectrum of hemodynamic data by spanning from a central vein into the right atrium, through the right ventricle, and into a branch of the pulmonary artery. This setup allows measurement of right atrial pressure via the proximal port, pulmonary artery pressures (systolic, diastolic, and mean) via the catheter in the PA, and mixed venous oxygen saturation (SvO₂) from the distal PA lumen. Cardiac output can be determined by thermodilution using injections and the catheter's thermistor. It can also estimate left atrial pressure when the balloon is wedged to obtain the wedge (PCWP) pressure, though that is an additional data point beyond the basics. Thus, data points like RA pressure, PA pressures, SvO₂, and CO by thermodilution are exactly what the catheter provides. Other options describe data from separate monitoring devices (central venous pressure alone, arterial BP and heart rate, or airway pressures), which are not the primary measurements of a pulmonary artery catheter.

8. Which characteristic best describes two-wavelength pulse oximeters compared to bench co-oximeters?

- A. They provide continuous, real-time data and never require daily clinician calibration.
- B. They require arterial blood sampling for operation.
- C. They provide only snapshot data and must be calibrated monthly.
- D. They rely on external calibration curves that must be updated weekly.

The key idea is continuous, noninvasive bedside monitoring versus lab-based, snapshot analysis. Two-wavelength pulse oximeters are designed to provide continuous, real-time data by measuring the pulsatile arterial blood at two wavelengths and converting that signal into an SpO₂ reading. They come factory-calibrated and are intended for ongoing use without daily recalibration by clinicians, making real-time trends available at the bedside. Bench co-oximeters, in contrast, analyze a blood sample with multiple wavelengths to quantify different forms of hemoglobin and related parameters. They provide results at a single point in time and require arterial blood sampling along with regular calibration and quality control. They do not deliver continuous monitoring. So the best description is that two-wavelength pulse oximeters offer continuous, real-time data and typically do not require daily clinician calibration, unlike bench co-oximeters.

9. What is the approximate normal value for VO₂?

- A. 100 mL/min
- B. 250 mL/min
- C. 500 mL/min
- D. 1000 mL/min

VO₂ is the rate at which tissues consume oxygen from the blood. At rest, metabolic demand is low, so oxygen uptake is about 250 mL per minute. This corresponds to roughly 3.5 mL O₂ per kilogram per minute for a typical adult (~70 kg), which rounds to about 250 mL/min. Values like 100 mL/min are far too low for resting metabolism, while 500 mL/min or 1000 mL/min reflect higher levels of activity rather than rest. Therefore, the approximate normal resting VO₂ is 250 mL/min.

10. What happens when preload is excessive and surpasses the heart's optimal stretch point?

- A. Stroke volume increases with preload indefinitely
- B. Stroke volume decreases due to overdistension**
- C. Preload has no effect on stroke volume
- D. Afterload is the only determinant of stroke volume

The main idea is the preload–stroke volume relationship described by the length–tension (Frank-Starling) mechanism. As the ventricle fills from diastole, muscle fibers stretch and contract more forcefully up to an optimal length. When preload becomes excessive and stretches the fibers beyond that point, contractility falls because the actin–myosin overlap is no longer ideal. The result is a weaker contraction and a smaller stroke volume. So, although increasing preload usually boosts stroke volume, pushing preload past the optimal stretch causes overdistension and a decrease in the amount ejected with each beat. This explains why simply increasing preload indefinitely isn't beneficial, and why preload does matter for stroke volume rather than being irrelevant or being determined solely by afterload.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

<https://physiologicmonitoring.examzify.com>

We wish you the very best on your exam journey. You've got this!

SAMPLE