PRINCIPLES AND PRACTICE OF ENGINEERING (PE) CIVIL: WATER RESOURCES AND ENVIRONMENTAL (WRE) PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://pe-civilwaterresource.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1
Table of Contents 2
Introduction 3
How to Use This Guide 4
Questions 5
Answers 8
Explanations 10
Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which factor generally has the least effect on evaporation rates?

A. Wind speed

B. Temperature

C. Chemical concentration in water

D. Relative humidity

2. What is a potential consequence of excessive pumping relative to recharge in aquifers?

A. The water table may rise

B. The cone of depression may form

C. Flow rate will double

D. Aquifer pressure will stabilize

3. For groundwater studies, what is the term for the elevation of the water table?

A. Hydraulic gradient

B. Potentiometric surface

C. Water surface profile

D. Groundwater recharge zone

4. Mechanical dispersion includes which of the following?

A. Adsorption

B. Advection

C. Sorption

D. Permeability

5. Which of the following statements is true about confined aquifers?

A. The well site should be in the recharge area

B. Well penetration is usually partial

C. Contamination reaches the well quickly

D. The well should fully penetrate between impervious layers

SAMPLE

6. Which of the following factors is greatly influenced by effective stress?

A. Soil compressibility

B. Soil suction

C. Soil granular size

D. Soil color

7. The degradation of biomass derived from aquatic organic matter leads to what change in dissolved oxygen levels?

A. Increased dissolved oxygen

B. No change in dissolved oxygen

C. Decreased dissolved oxygen

D. Oxygen saturation

8. Which property of soil does not depend on effective stress?

A. Soil compressibility

B. Soil shear strength

C. Index properties of soil

D. Soil saturation

9. What is one of the main purposes of a SWPPP?

A. To manage project budgets

B. To protect air quality

C. To protect water quality

D. To enhance local wildlife

10. What material can be used for channel stabilization when anticipating extremely high velocities?

A. Concrete blocks

B. Gravel

C. Riprap or rock gabions

D. Silt curtains

SAMPLE

Answers

SAMPLE

1. C
2. B
3. B
4. B
5. D
6. A
7. C
8. D
9. C
10. C

SAMPLE

Explanations

SAMPLE

1. Which factor generally has the least effect on evaporation rates?

A. Wind speed

B. Temperature

C. Chemical concentration in water

D. Relative humidity

Chemical concentration in water generally has the least effect on evaporation rates compared to other factors. This is primarily because evaporation is primarily influenced by the physical properties of water, not by the solutes dissolved in it. While the presence of certain chemicals can affect the vapor pressure of water, in most typical circumstances, such as evaporation from a body of water, the impact of temperature, wind speed, and relative humidity plays a more significant role. Temperature directly affects the kinetic energy of water molecules; higher temperatures increase evaporation rates. Wind speed enhances evaporation by removing vapor-laden air from the surface of the liquid, allowing more molecules to escape. Relative humidity affects the rate of evaporation since higher humidity levels reduce the concentration gradient between the water surface and the air, which can slow down the process. While chemical concentration can alter the physical characteristics of water—such as its boiling point or surface tension—the fundamental process of evaporation is predominantly governed by temperature, wind speed, and humidity. Therefore, while chemical concentration may have a role, it is typically much less pronounced than the other factors listed.

2. What is a potential consequence of excessive pumping relative to recharge in aquifers?

A. The water table may rise

B. The cone of depression may form

C. Flow rate will double

D. Aquifer pressure will stabilize

Excessive pumping relative to recharge in aquifers can indeed lead to the formation of a cone of depression. This phenomenon occurs when water is withdrawn from a well at a rate that exceeds the natural replenishment of the aquifer. As water is pumped out, the water level around the well decreases, resulting in a steep decline in the water table that creates a conical shape, known as the cone of depression. This condition can lead to several issues, including reduced water availability, potential land subsidence, and deteriorating water quality as shallow contaminants can more easily infiltrate the aquifer. The formation of a cone of depression reflects the fact that the aquifer is not being recharged adequately to replace the water being extracted, highlighting the imbalance between pumping rates and the natural replenishment processes. In contrast, the other options do not accurately describe the consequences of excessive pumping. The water table may not rise; instead, it typically falls in response to excessive withdrawal. Flow rates would not necessarily double as a direct consequence of excess pumping without considering specific site conditions. Lastly, aquifer pressure generally decreases with extensive pumping, contradicting the assertion that it would stabilize.

SAMPLE

3. For groundwater studies, what is the term for the elevation of the water table?

A. Hydraulic gradient

B. Potentiometric surface

C. Water surface profile

D. Groundwater recharge zone

The term for the elevation of the water table is known as the potentiometric surface. This concept represents the level to which groundwater would rise in a well or piezometer, reflecting the pressure of the groundwater within an aquifer. The potentiometric surface is especially important in understanding the behavior of groundwater flow and the relationships between different aquifers in an area. When analyzing groundwater, the potentiometric surface serves as a critical reference for groundwater management and resource development. It indicates the potential energy available to drive the flow of groundwater, which can assist in predicting how water moves through the subsurface environment. This is not the same as the water table itself, which is the upper level of the saturated zone where the pressure is equal to atmospheric pressure. Other terms listed serve different functions in groundwater studies. For example, the hydraulic gradient refers to the slope of the water table, while a water surface profile typically represents the configuration of water levels in rivers or lakes. A groundwater recharge zone is an area where surface water infiltrates down to replenish the aquifer, rather than representing the elevation of the water table itself.

4. Mechanical dispersion includes which of the following?

A. Adsorption

B. Advection

C. Sorption

D. Permeability

Mechanical dispersion refers to the process by which particles or solutes are spread or mixed in a fluid, typically due to the physical movement of the fluid itself. Advection is the primary mechanism through which this occurs, as it involves the transport of substances by the bulk motion of the fluid. In environmental contexts, such as groundwater or surface water systems, advection is crucial for understanding how contaminants move through water. In contrast, the other options involve different mechanisms related to solute behavior in water. Adsorption and sorption refer to the processes by which particles adhere to the surfaces of solids, which can impact the concentration and movement of substances but do not describe the mechanical mixing of fluids. Permeability, on the other hand, describes the ability of a material (like soil or rock) to transmit fluids, which affects the flow of water but is not a direct mechanism of dispersion itself. By understanding that mechanical dispersion, specifically in the context of fluid dynamics, primarily relates to the movement of solutes due to the flow of the fluid, it becomes evident why advection is the correct choice.

SAMPLE

5. Which of the following statements is true about confined aquifers?

A. The well site should be in the recharge area

B. Well penetration is usually partial

C. Contamination reaches the well quickly

D. The well should fully penetrate between impervious layers

Confined aquifers are characterized by being surrounded by impermeable layers, which create pressure within the aquifer and often lead to the phenomenon where water rises in a well above the level of the aquifer itself when tapped. When drilling a well into a confined aquifer, it is ideal for the well to fully penetrate between the impermeable layers above and below the aquifer. This allows for maximum water throughput and minimizes issues associated with lower hydraulic conductivity at the boundaries. By ensuring full penetration, the well can capture the entire water column available in the confined aquifer, which can provide better yield and more stable water levels. The other statements present various misconceptions about confined aquifers. For example, a well site located in a recharge area is characteristic of unconfined aquifers, where surface water can easily seep into the aquifer; this is less applicable to confined aquifers. Furthermore, well penetration is typically complete rather than partial to optimize water extraction. Lastly, contamination in confined aquifers tends to spread more slowly compared to unconfined aquifers because the impermeable layers act as barriers against rapidly moving contaminants. Thus, the statement that the well should fully penetrate between impervious layers reflects the fundamental understanding of how to effectively utilize confined aquifers.

6. Which of the following factors is greatly influenced by effective stress?

A. Soil compressibility

B. Soil suction

C. Soil granular size

D. Soil color

Effective stress is a fundamental concept in soil mechanics that refers to the inter-particle stress that contributes to the strength and deformation behavior of soil. It is defined as the total stress minus the pore water pressure. One of the key factors greatly influenced by effective stress is soil compressibility. Soil compressibility is a measure of how much a soil volume decreases under applied stress. It is critically affected by effective stress because as effective stress increases (while maintaining or reducing pore water pressure), the soil particles are brought closer together, which generally results in a reduction of void spaces and an increase in soil density. This relationship means that the compressibility of the soil is directly related to the effective stress acting on it; higher effective stresses usually lead to lower compressibility. In contrast, factors like soil suction, granular size, and soil color do not have a direct relationship with effective stress in the same way compressibility does. Soil suction relates to the moisture content and the tension forces in the pore water but is not a direct consequence of effective stress alone. Granular size can influence strength and behavior but is not influenced by effective stress in a manner that would affect compressibility. Similarly, soil color is generally a physical property that is not associated with the mechanical behavior of the

SAMPLE

7. The degradation of biomass derived from aquatic organic matter leads to what change in dissolved oxygen levels?

A. Increased dissolved oxygen

B. No change in dissolved oxygen

C. Decreased dissolved oxygen

D. Oxygen saturation

The degradation of biomass, particularly from aquatic organic matter, typically leads to a decrease in dissolved oxygen levels in the water. This process is primarily driven by microbial activity, where bacteria consume the organic matter. As they metabolize the biomass, they use oxygen for respiration, which reduces the overall concentration of dissolved oxygen in the water body. When organic matter breaks down, the demand for oxygen increases significantly due to the respiration of aerobic microorganisms. These microorganisms thrive in environments where organic matter is plentiful, but their oxygen consumption can significantly deplete the available dissolved oxygen. In aquatic ecosystems, this process can have serious implications, such as leading to hypoxic conditions (low oxygen levels) that can be detrimental to fish and other aquatic organisms. The reduction in dissolved oxygen due to this biological activity is critical in understanding the health of aquatic systems and managing water quality, as low oxygen levels can lead to fish kills and loss of biodiversity. Therefore, the correct answer indicates the direct impact of biomass degradation on dissolved oxygen levels.

8. Which property of soil does not depend on effective stress?

A. Soil compressibility

B. Soil shear strength

C. Index properties of soil

D. Soil saturation

The property of soil that does not depend on effective stress is soil saturation. Effective stress refers to the stress carried by the soil skeleton and is central to understanding soil behavior under load. It directly influences properties such as soil compressibility and shear strength, which are critical in geotechnical engineering analyses. Soil saturation, on the other hand, is a measure of how much of the pore space in the soil is filled with water. It is defined independently of the stresses acting on the soil particles. Saturation levels affect the pore water pressure and can impact effective stress, but they do not change with variations in effective stress itself. This is because saturation is concerned with the ratio of water to void spaces, not with the forces acting upon those spaces or the soil particles themselves. Thus, while effective stress clearly plays a significant role in the other properties, soil saturation remains unaffected by it.

SAMPLE

9. What is one of the main purposes of a SWPPP?

A. To manage project budgets

B. To protect air quality

C. To protect water quality

D. To enhance local wildlife

A Stormwater Pollution Prevention Plan (SWPPP) is primarily designed to protect water quality. Its main purpose is to outline strategies and control measures that minimize the discharge of pollutants from construction sites into water bodies, which can be impacted by stormwater runoff. This plan typically includes practices for managing sediment, controlling erosion, and ensuring that any chemicals or materials used on-site do not contaminate nearby water sources. The SWPPP also conforms to regulatory requirements mandated by the National Pollutant Discharge Elimination System (NPDES), which emphasizes the protection of water quality as a critical environmental concern. This ensures that both surface water and groundwater are safeguarded from the adverse effects of construction activities, thereby promoting cleaner waterways and healthier ecosystems. While managing project budgets, protecting air quality, and enhancing local wildlife are important aspects of various environmental and project management considerations, they are not the central focus of a SWPPP. The specific design and intent of the SWPPP directly address the need for water quality protection in relation to stormwater management.

10. What material can be used for channel stabilization when anticipating extremely high velocities?

A. Concrete blocks

B. Gravel

C. Riprap or rock gabions

D. Silt curtains

When anticipating extremely high velocities in channel stabilization, the use of riprap or rock gabions is particularly effective. Riprap consists of large stone or rock fragments placed along streambanks or river channels to protect against erosion. These materials have the strength and weight necessary to withstand the forces generated by high-flow waters, preventing soil erosion and maintaining the integrity of the channel. Rock gabions, which are wire mesh containers filled with rock, also provide significant resistance against rapid water flow. They can absorb and dissipate the energy of moving water and create a stable structure that retains sediment and prevents erosion, making them well-suited for areas prone to high velocities. In contrast, concrete blocks might not provide sufficient interlocking and stability under rapid flow conditions, while gravel can be easily displaced by strong currents. Silt curtains are utilized primarily for sediment control and do not serve a structural purpose for stabilization against high velocities. Therefore, riprap and rock gabions are the ideal choices for channel stabilization in conditions involving extremely high fluid velocities.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://pe-civilwaterresource.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE