PRINTREADING TRADE COMPENTENCY PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://printreadingtrade.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. Which regulation specifies the safe use of grounding conductors?

A. ART 100

B. 590.4 (J)

C. 210.8 (B) (3)

D. 250.70

2. If a branch circuit serves kitchen small appliances, how many circuits does NEC require at least?

A. One 15 A

B. Two 15 A

C. One 20 A

D. Two 20 A

3. Recessed non-Type IC lighting fixtures must maintain a clearance of at least what measurement from combustible material?

A. 1/4"

B. 1/2"

C. 1"

D. 2"

4. Are all 125V, 20A receptacles in bathrooms required to have ground-fault circuit interrupter protection?

A. True

B. False

C. Only in new constructions

D. Only in older structures

5. What is the proper method for assessing an air conditioning load for a one-family dwelling?

A. 50% of the rated load

B. 75% of the rated load

C. 100% of the rated load

D. 125% of the rated load

SAMPLE

6. When protecting NMS cable, what is the minimum height above the floor it should be protected to?

A. 4"

B. 6"

C. 8"

D. 10"

7. What is the minimum service disconnect rating for a one-family dwelling?

A. 30 A

B. 60 A

C. 100 A

D. 200 A

8. When is it acceptable to use uninsulated bonding jumpers?

A. Under no circumstances

B. In residential use

C. When using copper wire only

D. As a temporary fix

9. What is the smallest overhead service conductor permitted by the NEC for loads other than limited loads of a single branch circuit?

A. No. 6 AL

B. No. 8 Cu

C. No. 12 Cu

D. No. 10 AL

10. True or False: The NEC is a legal document intended for adoption by governmental bodies.

A. True

B. False

C. Only in certain states

D. Depends on the context

SAMPLE

Answers

SAMPLE

1. D
2. D
3. B
4. A
5. C
6. B
7. C
8. A
9. B
10. A

SAMPLE

Explanations

SAMPLE

1. Which regulation specifies the safe use of grounding conductors?

A. ART 100

B. 590.4 (J)

C. 210.8 (B) (3)

D. 250.70

The regulation that specifies the safe use of grounding conductors is found in section 250.70. This section of the National Electrical Code (NEC) provides specific requirements for ground connections, ensuring that they are made securely and effectively to protect both individuals and property from electric shock and fire hazards. Grounding conductors play a crucial role in electrical systems by providing a pathway for electrical current to safely dissipate into the ground in the event of a fault. Section 250.70 outlines the acceptable methods for connecting these conductors to a grounding electrode, ensuring that the grounding system is reliable and minimizes potential hazards. By adhering to the guidelines in 250.70, electricians can ensure that installations comply with safety standards and reduce the risk of electrical accidents that could result from improper grounding practices. This regulation helps maintain system integrity and enhances overall safety within electrical installations.

2. If a branch circuit serves kitchen small appliances, how many circuits does NEC require at least?

A. One 15 A

B. Two 15 A

C. One 20 A

D. Two 20 A

The National Electrical Code (NEC) specifies that for kitchen small appliances, at least two separate 20-amp circuits are required. This requirement is in place to ensure that there is enough power supply to accommodate the typical load from various appliances such as toasters, microwaves, coffee makers, and blenders, all of which may be used simultaneously. By mandating two circuits, the NEC aims to minimize the risk of overloading a single circuit, which could lead to tripped breakers or, in worst-case scenarios, electrical fires. Each 20-amp circuit can handle a maximum load of 2400 watts (based on 120 volts), making them well-suited for powering multiple kitchen appliances safely without exceeding the load capacity. This requirement ensures a more efficient distribution of electrical power in the kitchen, offering both safety and functionality for users who often operate several appliances at once.

3. Recessed non-Type IC lighting fixtures must maintain a clearance of at least what measurement from combustible material?

A. 1/4"

B. 1/2"

C. 1"

D. 2"

The requirement for recessed non-Type IC lighting fixtures to maintain a clearance of at least 1/2" from combustible materials is based on safety standards to prevent fire hazards. Type IC fixtures are designed for direct contact with insulation, whereas non-Type IC fixtures are not. Therefore, they must have a sufficient distance from combustible materials to ensure that heat generated by the fixture does not ignite any flammable substances that may be nearby. By requiring a minimum clearance of 1/2", this standard provides a safety buffer that helps reduce the risk of overheating and potential fires, as it allows for better airflow and cooling around the fixture. This distance aligns with recommendations from the National Electrical Code (NEC) and related safety regulations, ensuring that installation practices prioritize safety and compliance.

SAMPLE

4. Are all 125V, 20A receptacles in bathrooms required to have ground-fault circuit interrupter protection?

A. True

B. False

C. Only in new constructions

D. Only in older structures

The correct response is that all 125V, 20A receptacles in bathrooms are indeed required to have ground-fault circuit interrupter (GFCI) protection. This requirement is established by the National Electrical Code (NEC), which mandates that GFCI protection be provided for receptacles in areas of the home where water is present, such as bathrooms, kitchens, and outdoor locations. The primary purpose of GFCI protection is to safeguard against electrical shock that can occur when appliances and devices are used in proximity to water. Since bathrooms are high-risk areas for electrical accidents due to the potential for water exposure, GFCIs are designed to cut off electric power in the event of a ground fault, thereby enhancing safety. In new constructions as well as older buildings undergo renovations or updates to electrical systems, the installation of GFCI-protected receptacles is essential for compliance with current safety standards. Therefore, it's critical for both new and existing installations in bathroom areas to follow this guideline to ensure the safety of individuals using electrical devices in these environments.

5. What is the proper method for assessing an air conditioning load for a one-family dwelling?

A. 50% of the rated load

B. 75% of the rated load

C. 100% of the rated load

D. 125% of the rated load

To assess the air conditioning load for a one-family dwelling, determining 100% of the rated load is essential because it provides a baseline for the total cooling capacity required to maintain comfortable indoor temperatures during peak heat conditions. This assessment considers the full heat gain from sources such as sunlight, appliances, and occupants, ensuring that the system can handle the maximum demands placed upon it. Using 100% of the rated load is also crucial for sizing the air conditioning system accurately, helping to prevent undersizing, which could lead to insufficient cooling, or oversizing, which may cause inefficiencies and increased energy costs. Understanding the total heat load is fundamental for HVAC professionals to make informed decisions regarding equipment selection and to ensure the efficiency of the system in delivering adequate cooling throughout the dwelling.

SAMPLE

6. When protecting NMS cable, what is the minimum height above the floor it should be protected to?

A. 4"

B. 6"

C. 8"

D. 10"

The minimum height for protecting Network Multimedia System (NMS) cable is 6 inches above the floor. This standard is established to prevent damage to the cable from foot traffic, cleaning equipment, or other potential hazards found in environments like commercial buildings, schools, and industrial settings. By ensuring that the cable is at least 6 inches above the floor, it minimizes the risk of accidental disconnection or physical damage, thus helping to maintain the network's integrity and functionality. While other heights are mentioned in the options, they do not provide the same level of safety as the 6-inch minimum, which strikes a balance between accessibility and protection.

7. What is the minimum service disconnect rating for a one-family dwelling?

A. 30 A

B. 60 A

C. 100 A

D. 200 A

The minimum service disconnect rating for a one-family dwelling is set at 100 A according to the National Electrical Code (NEC). This rating is established to ensure that residential properties can handle sufficient electrical load to power essential circuits and appliances safely and reliably. Having a 100 A service disconnect rating means that the electrical system in a one-family home can accommodate the typical power demands of a modern household, which includes lighting, heating, refrigeration, and other electrical devices. This requirement also helps to prevent potential overloading issues that could lead to short circuits or electrical fires, ensuring safe operation within the home's electrical system. Other ratings, such as 30 A, 60 A, or 200 A, do not meet the standard requirements for a minimum in a one-family dwelling, either being insufficient for most residential needs or excessively high for typical single-family use. Thus, the 100 A rating is a balance that supports adequate service while maintaining safety.

8. When is it acceptable to use uninsulated bonding jumpers?

A. Under no circumstances

B. In residential use

C. When using copper wire only

D. As a temporary fix

Uninsulated bonding jumpers should never be used in any situation because they pose significant safety risks and violate electrical codes. Bonding jumpers are essential for establishing a safe, low-resistance path for electrical current in case of a fault, and they must be properly insulated to prevent accidental contact with live circuits. The use of uninsulated bonding jumpers can lead to electrical shock hazards and increase the risk of equipment damage. In scenarios such as residential use, relying on uninsulated jumpers would compromise the safety measures put in place to protect both properties and individuals. Similarly, while the use of copper wire is common in electrical work, the presence of uninsulated components in any wiring system is unacceptable. Finally, temporary fixes should adhere to the same stringent safety standards as permanent installations; therefore, using uninsulated bonding jumpers as a temporary solution is inappropriate. Proper insulation ensures that all components of the electrical system function safely and effectively.

SAMPLE

9. What is the smallest overhead service conductor permitted by the NEC for loads other than limited loads of a single branch circuit?

A. No. 6 AL

B. No. 8 Cu

C. No. 12 Cu

D. No. 10 AL

The National Electrical Code (NEC) establishes specific guidelines for the sizing of overhead service conductors to ensure safety and proper functionality. For loads other than limited loads of a single branch circuit, the NEC specifies a minimum conductor size requirement. In this context, the smallest overhead service conductor size permitted for general loads is No. 8 copper (Cu). This size is stipulated because it provides adequate carrying capacity and ensures that the system can handle the necessary load without overheating or causing other issues. Copper conductors are favored for their superior conductivity, meaning they can effectively transmit electricity with less resistance compared to aluminum conductors. Understanding this requirement is essential for compliance with code and for ensuring that electrical installations are safe and reliable. The other options, while they may represent conductor sizes that could be suitable for specific situations or limited applications, do not meet the NEC requirement for general overhead service conductors that carry loads beyond a single branch circuit.

10. True or False: The NEC is a legal document intended for adoption by governmental bodies.

A. True

B. False

C. Only in certain states

D. Depends on the context

The National Electrical Code (NEC) is indeed a legal document designed to establish minimum regulations for electrical installations to ensure safety. Its primary purpose is to provide guidelines that help reduce the likelihood of electrical hazards. When adopted by local, state, or federal governmental bodies, it becomes enforceable by law, meaning that compliance is mandated for all new electrical installations and modifications. As a comprehensive set of standards, the NEC ensures consistency and safety across the electrical industry. The code is updated regularly to reflect new innovations and safety practices, and stakeholders in the electrical trade, including contractors and inspectors, often refer to it as the authoritative source for electrical safety and regulations. In many cases, the adoption of the NEC can vary by jurisdiction; however, the foundational principle remains the same: when it is adopted, it functions as a legal requirement that must be followed. This underscores why the statement is true— it highlights the NEC's role in establishing safety standards that are legally binding when adopted by regulatory authorities.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://printreadingtrade.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE