RESIDENTIAL AIR CONDITIONING SYSTEMS MECHANIC (313D) CERTIFICATION PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://313dcert.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. **As humidity rises, what happens to the air temperature difference across an evaporator coil?**

   A. Increases

   B. Decreases

   C. Remains constant

   D. Fluctuates widely

2. **To increase superheat on a TXV system, you should turn the spring:**

   A. Counterclockwise

   B. Clockwise

   C. In any direction

   D. Gradually at random

3. **What should you check next after changing the pulley on a blower motor from 3 1/4" to 4"?**

   A. Belt size and tension

   B. Motor amperage draw

   C. Blower wheel balance

   D. Airflow direction

4. **When replacing a single pole compressor contactor with a double pole, how should you connect an off-cycle self-regulating crankcase heater?**

   A. Connect both wires to the line side

   B. One wire to the line side of one pole and the other to the load side of the same pole

   C. Connect both wires to the load side

   D. Bypass the contactor

5. **What effect does a zone damper that fails to open have in a heat pump cooling mode?**

   A. Causes high suction pressure

   B. Can cause low suction pressure

   C. Improves cooling efficiency

   D. Leads to compressor failure

SAMPLE

6. What vacuum measurement indicates a good vacuum level in a refrigeration system?

A. 30 Hg

B. 29.9 Hg

C. 28.5 Hg

D. 29 Hg

7. Which statement is accurate about conventional fan/limit controls?

A. They only have normally closed contacts

B. They are only activated by manual settings

C. They have normally open contacts on the limit side

D. They are thermally driven

8. What is the minimum required sleeve size when installing a 50 mm (2 in) nominal pipe with 38 mm (1.5 in) insulation through a concrete block wall?

A. 150 mm (6 in)

B. 200 mm (8 in)

C. 100 mm (4 in)

D. 250 mm (10 in)

9. What might cause low suction pressure in a refrigeration system?

A. A leak in the system

B. A TXV that is stuck nearly shut

C. Too high of refrigerant charge

D. Poor insulation of piping

10. When checking for continuity in a circuit, what is a crucial first step?

A. Measure the voltage first

B. Disconnect power from the circuit

C. Turn on all appliances

D. Isolate the circuit with a fuse

SAMPLE

Answers

SAMPLE

1. B
2. B
3. A
4. B
5. B
6. B
7. D
8. A
9. B
10. B

SAMPLE

Explanations

SAMPLE

1. As humidity rises, what happens to the air temperature difference across an evaporator coil?

A. Increases

B. Decreases

C. Remains constant

D. Fluctuates widely

As humidity rises, the air temperature difference across an evaporator coil decreases. This is because higher humidity levels indicate that the air has more moisture content, which affects the cooling efficiency of the evaporator coil. The evaporator coil operates by absorbing heat from the incoming air, and when the air contains more moisture, the coil must work harder to remove both heat and humidity from the air. When humidity is higher, the latent heat load, which is the energy required to remove moisture from the air, increases. This means that while the evaporator cooling capacity remains the same, a significant portion of that capacity is now directed toward dehumidification rather than cooling the air temperature. As a result, the temperature difference from the air entering the coil to the air leaving the coil is reduced, leading to decreased efficiency in cooling the air to lower temperatures. Understanding this relationship is important for optimizing air conditioning performance and ensuring comfortable indoor environments, especially in areas with high humidity.

2. To increase superheat on a TXV system, you should turn the spring:

A. Counterclockwise

B. Clockwise

C. In any direction

D. Gradually at random

In a thermal expansion valve (TXV) system, superheat is the temperature of the refrigerant vapor above its saturation temperature at a given pressure. Adjusting the spring tension in the TXV directly influences the flow of refrigerant into the evaporator and subsequently affects the superheat level. When the spring is turned clockwise, it increases the tension, which in turn raises the pressure on the diaphragm. This leads to a reduction in the flow of refrigerant entering the evaporator. As less refrigerant enters the evaporator, the refrigerant that does enter has more time to absorb heat, potentially raising the superheat. Essentially, by increasing the spring tension, you can achieve a higher superheat, ensuring that the system operates efficiently and prevents flooding of the evaporator with liquid refrigerant, which could cause compressor damage. In contrast, adjusting the spring in other directions or randomly would not provide a controlled approach to managing superheat and could lead to erratic system behavior, flooding, or inefficient performance. Thus, adjusting the spring tension in a clockwise direction is the precise method to effectively increase superheat in a TXV system.

SAMPLE

3. What should you check next after changing the pulley on a blower motor from 3 1/4" to 4"?

A. Belt size and tension

B. Motor amperage draw

C. Blower wheel balance

D. Airflow direction

After changing the pulley on a blower motor from 3 1/4" to 4", it is essential to check the belt size and tension as the first step. Changing the pulley size directly affects the speed at which the blower motor operates, and consequently alters the length and tension specifications of the belt. When the pulley size increases, it often means that the belt must accommodate this change to ensure proper engagement and function. If the belt is too loose, it may slip and lead to inefficient operation of the blower system, while too much tension can cause premature wear or even damage to both the motor and the belt itself. Hence, checking the belt size and ensuring it is properly tensioned is critical for optimal system performance and longevity. Understanding the implications of pulley changes helps in troubleshooting and maintaining effective air conditioning systems, thereby ensuring they operate within designed parameters.

4. When replacing a single pole compressor contactor with a double pole, how should you connect an off-cycle self-regulating crankcase heater?

A. Connect both wires to the line side

B. One wire to the line side of one pole and the other to the load side of the same pole

C. Connect both wires to the load side

D. Bypass the contactor

Connecting an off-cycle self-regulating crankcase heater when replacing a single pole compressor contactor with a double pole is critical for ensuring proper operation and safety of the system. The correct approach is to connect one wire to the line side of one pole and the other wire to the load side of the same pole. This configuration ensures that the crankcase heater is energized only when the compressor contactor is closed, allowing the heater to function during the off-cycle of the compressor. By connecting one wire to the line side (incoming power) and the other to the load side (outgoing to the heater), you achieve control over the heater's operation based on the contactor's state. This is essential, as it prevents the heater from running continuously when the compressor isn't operational, which can lead to unnecessary energy consumption and potential overheating. In contrast, connecting both wires to the line side would keep the heater continuously energized regardless of the contactor position, which is not ideal for off-cycle operation. Connecting both wires to the load side would create an open circuit when the contactor is off, preventing the heater from functioning at all. Bypassing the contactor entirely would eliminate control, likely leading to improper heater operation and possible system damage or inefficiency.

SAMPLE

5. What effect does a zone damper that fails to open have in a heat pump cooling mode?

A. Causes high suction pressure

B. Can cause low suction pressure

C. Improves cooling efficiency

D. Leads to compressor failure

When a zone damper fails to open in a heat pump cooling mode, it restricts airflow to a specific zone or area of the building. This limited airflow can result in a number of issues within the system's operation. A significant effect of reduced airflow is that it can lead to low suction pressure in the refrigeration circuit of the heat pump. In cooling mode, the system relies on proper airflow across the evaporator coil to efficiently transfer heat. If the zone damper stays closed, there is insufficient air to absorb the heat from the indoor environment, which reduces the amount of refrigerant vapor reaching the evaporator. Consequently, this can cause the pressure in the suction line (the line carrying refrigerant back to the compressor) to drop, leading to low suction pressure. Low suction pressure can lead to inadequate cooling performance, and if it persists, it can also contribute to further operational issues within the system. However, it is important to note that while low suction pressure is a consequence of a damper not opening, other choices do not accurately reflect the direct impact of this situation.

6. What vacuum measurement indicates a good vacuum level in a refrigeration system?

A. 30 Hg

B. 29.9 Hg

C. 28.5 Hg

D. 29 Hg

Vacuum level in refrigeration work is read in inches of mercury on a vacuum gauge. On this scale, higher numbers mean more vacuum, with about 30 inHg representing near-full vacuum. A good vacuum during evacuation is around 29.9 inHg, showing you've removed most air and moisture from the system. Reading 30 inHg is at or beyond the instrument's limit and isn't typically seen; 28.5 inHg and 29 inHg indicate less vacuum than 29.9, meaning the system hasn't reached as deep a vacuum. So, 29.9 inHg is the best indication of a good vacuum.

7. Which statement is accurate about conventional fan/limit controls?

A. They only have normally closed contacts

B. They are only activated by manual settings

C. They have normally open contacts on the limit side

D. They are thermally driven

Conventional fan/limit controls are designed to automatically regulate the operation of a heating or cooling system based on temperature. The correct response highlights that these controls are thermally driven, meaning they respond to temperature changes. When the temperature reaches a certain threshold, these controls activate the fan or limit action, promoting efficient temperature management within the system. This thermally driven mechanism allows for precise operation; for instance, when the temperature in a furnace rises to a predetermined point, the limit control turns off the burner to prevent overheating. Conversely, when the temperature drops below a certain point, the fan control activates the blower to circulate air, contributing to both comfort and safety. This understanding is fundamental for maintenance and troubleshooting in residential air conditioning systems, as it emphasizes the importance of temperature sensing in system operations. The other options do not capture this key characteristic of thermal response, making them less applicable in this context.

SAMPLE

8. What is the minimum required sleeve size when installing a 50 mm (2 in) nominal pipe with 38 mm (1.5 in) insulation through a concrete block wall?

A. 150 mm (6 in)

B. 200 mm (8 in)

C. 100 mm (4 in)

D. 250 mm (10 in)

When determining the minimum required sleeve size for installing a 50 mm (2 in) nominal pipe with 38 mm (1.5 in) insulation through a concrete block wall, it's essential to account for the diameter of the insulated pipe and the necessary clearance for installation, thermal expansion, and future maintenance. The outside diameter of the insulated pipe is the sum of the nominal pipe size and the insulation thickness. In this case, adding 50 mm (the pipe) to 76 mm (the insulation, which is twice the thickness of 38 mm) results in a total diameter of 126 mm. To ensure the sleeve accommodates the pipe's diameter while allowing some clearance, a common approach is to provide an additional margin for safe installation—this is where the chosen sleeve size becomes important. The minimum sleeve size of 150 mm (6 in) offers adequate space for the insulated pipe to fit comfortably, helps with the ease of installation, and assists in preventing damage to the insulation during the pipe's thermal expansion and contractions over time. Therefore, the choice of 150 mm as the minimum sleeve size addresses the practical aspects of installation and operation, ensuring the system functions effectively without undue stress on the insulation or the pipe itself.

9. What might cause low suction pressure in a refrigeration system?

A. A leak in the system

B. A TXV that is stuck nearly shut

C. Too high of refrigerant charge

D. Poor insulation of piping

Low suction pressure in a refrigeration system can occur for various reasons, but a TXV (Thermostatic Expansion Valve) that is stuck nearly shut can significantly impact the system's operation. When the TXV is not allowing enough refrigerant to flow into the evaporator coil, the evaporator will not be able to absorb sufficient heat from the surrounding area. This inadequate refrigerant flow leads to less evaporation within the coil, resulting in a drop in suction pressure because the evaporator is not functioning effectively. By constricting the refrigerant flow, a nearly shut TXV effectively limits the system's ability to relieve vapor pressure, resulting in low suction pressure readings. This condition can severely affect the overall performance of the refrigeration system, leading to inefficient cooling and potential compressor issues due to being starved of refrigerant. While other options can cause low suction pressure as well, they do so through different mechanisms. For instance, a leak in the system would generally lead to a loss of refrigerant and possibly lower suction pressure, but that is not the primary mechanism involved when considering the specific scenario of a stuck TXV. Understanding the role of the TXV in refrigerant flow makes it clear why this condition can lead to low suction pressure specifically.

SAMPLE

10. When checking for continuity in a circuit, what is a crucial first step?

A. Measure the voltage first

B. Disconnect power from the circuit

C. Turn on all appliances

D. Isolate the circuit with a fuse

When checking for continuity in a circuit, the crucial first step is to disconnect power from the circuit. This is essential for safety reasons, as measuring continuity while the circuit is energized can lead to inaccurate readings and poses a risk of electric shock. Ensuring that the circuit is de-energized allows the technician to safely use a multimeter or continuity tester to check for the presence of a complete electrical path without the risk of electric current flowing through the circuit. Isolating the circuit by switching off power avoids potential damage to the testing equipment and the technician. Once the power is disconnected, one can confidently ensure that the circuit components and connections are functioning correctly by checking continuity without interference from live voltage. This step acts as a foundational practice in maintaining safety standards and adhering to proper diagnostic procedures in residential air conditioning systems and electrical work in general.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://313dcert.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE