SHEET METAL JOURNEYMAN PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://sheetmetaljourneyman.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. In ductwork assembly, what does a sliding fit in a slip joint primarily facilitate?

A. Permanent, non-adjustable connection

B. High-strength welded joint

C. Insulation properties

D. Precise alignment and quick assembly

2. A health club shower room measuring 10 feet by 10 feet with four shower heads requires an intermittent exhaust capacity of how many CFM?

A. 200 CFM

B. 100 CFM

C. 300 CFM

D. 400 CFM

3. Bend allowance is used to determine what parameter in sheet metal layout?

A. The length of the flat pattern required to form a bend of a given angle with a specific radius

B. The length of the edge after bending

C. The thickness of the material

D. The finish quality of the bent edge

4. In pattern development, what does a centerline indicate?

A. The axis of symmetry or bend location.

B. The location of dim notes.

C. The seam gap width.

D. Hole center positions.

5. The purpose of a flame safeguard on a boiler is to:

A. Monitor pilot or main burner

B. Control fuel pressure

C. Regulate water temperature

D. Adjust burner tone

SAMPLE

6. What is bend allowance?

A. The length of the bent edge after forming the bend

B. The bend angle

C. The thickness of the material

D. The length of the flat pattern required to form a bend of a given angle with a specific radius

7. The return air duct to a blower type warm air furnace requires how many square inches of free air per 1,000 BTUH of rated capacity?

A. 1 in^2

B. 3 in^2

C. 2 in^2

D. 4 in^2

8. When selecting a bend radius for thin sheet metal, what must be verified to prevent cracking?

A. The color of the coating

B. Material capability

C. Bend direction

D. Ambient humidity

9. 26 inch round duct, positive pressure, un-reinforced long seam 4 inches W.G. can be made of which gauge?

A. 24 gauge

B. 22 gauge

C. 26 gauge

D. 20 gauge

10. What are the maximum flame spread and smoke-developed indices allowed for non-metallic ducts?

A. 15, 25

B. 25, 50

C. 75, 200

D. 50, 200

SAMPLE

Answers

SAMPLE

1. D
2. A
3. A
4. A
5. A
6. D
7. C
8. B
9. B
10. B

SAMPLE

Explanations

SAMPLE

1. In ductwork assembly, what does a sliding fit in a slip joint primarily facilitate?

A. Permanent, non-adjustable connection

B. High-strength welded joint

C. Insulation properties

D. Precise alignment and quick assembly

The sliding fit in a slip joint is all about letting the duct ends move relative to each other so you can position them accurately and install them quickly. Because the inner portion can slide inside the outer portion, you can cover small differences in cut length or slight out-of-square conditions without forcing parts together. This makes field installation faster and more forgiving, since you can align the joints precisely as you slide them into place and then secure and seal them. The design isn't intended to create a permanent rigid bond like welding, nor is its primary purpose insulation; those aspects come from other features or methods. So the main benefit is enabling precise alignment with quick, straightforward assembly.

2. A health club shower room measuring 10 feet by 10 feet with four shower heads requires an intermittent exhaust capacity of how many CFM?

A. 200 CFM

B. 100 CFM

C. 300 CFM

D. 400 CFM

Intermittent exhaust sizing for a shower room is typically based on the number of fixtures (shower heads) rather than just the room's area. A common guideline is about 50 CFM for each shower head when the exhaust is running only while the showers are in use. With four shower heads, that becomes 4 × 50 CFM = 200 CFM. The 10 ft by 10 ft size sets the room area, but for intermittent exhaust in a multi-head shower, the per-fixture rule is the governing factor, which is why 200 CFM is the best choice.

3. Bend allowance is used to determine what parameter in sheet metal layout?

A. The length of the flat pattern required to form a bend of a given angle with a specific radius

B. The length of the edge after bending

C. The thickness of the material

D. The finish quality of the bent edge

The main idea is that bend allowance is the portion of material length that is consumed by forming a bend, measured along the bend's neutral axis. This value tells you how much extra length the flat pattern must have so that, after bending to the specified angle and radius, the finished part reaches the correct overall dimensions. In practice, you add the bend allowance for each bend to the straight segments to determine the total flat pattern length you need to cut. This concept is what lets you translate a final bent geometry into an accurate flat layout before any bending occurs. Bend allowance is not about material thickness, edge finish, or the final edge length itself; it specifically accounts for the length used up by the bend during forming.

SAMPLE

4. In pattern development, what does a centerline indicate?

A. The axis of symmetry or bend location.

B. The location of dim notes.

C. The seam gap width.

D. Hole center positions.

Centerlines in pattern development show the line of symmetry and where bends or folds are to occur. This reference line tells you that the part is meant to be mirrored across it, so features on one side can be laid out as a mirror image on the other. When you transfer the pattern to sheet metal, bending along or around that line creates the correct, symmetric shape, with equal dimensions on both sides. It's a guide for how the piece will form, not a marker for where dim notes, seam gaps, or individual hole centers must be placed. Those details come from separate marks and measurements, while the centerline anchors the overall symmetry and bend location.

5. The purpose of a flame safeguard on a boiler is to:

A. Monitor pilot or main burner

B. Control fuel pressure

C. Regulate water temperature

D. Adjust burner tone

The flame safeguard is a safety interlock that ensures fuel is released only when a flame is actually present in the burner. It does this by continuously monitoring the flame with a sensor on the pilot or main burner. If a flame is detected, the control keeps the fuel supply on and the burner operating. If the flame goes out or fails to establish, it immediately shuts off the fuel to prevent unburned gas from accumulating, reducing the risk of explosion or hazardous conditions. This function is distinct from controlling fuel pressure, regulating water temperature, or adjusting burner tone, which are handled by other parts of the boiler system.

6. What is bend allowance?

A. The length of the bent edge after forming the bend

B. The bend angle

C. The thickness of the material

D. The length of the flat pattern required to form a bend of a given angle with a specific radius

Bend allowance is the portion of material you must include in the flat pattern to form the bend. It's the length along the neutral axis that will become the bend arc when the metal is bent, essentially the material needed to accommodate the bend for a given angle and bend radius. In practical terms, you take that arc length (roughly the bend angle times the neutral-axis radius) and add it to the straight portions of the flat pattern so the final part matches its intended dimensions. This is why the correct choice describes the flat-pattern length required to form the bend, not the length of the bent edge, the bend angle itself, or the material thickness.

SAMPLE

7. The return air duct to a blower type warm air furnace requires how many square inches of free air per 1,000 BTUH of rated capacity?

A. 1 in^2

B. 3 in^2

C. 2 in^2

D. 4 in^2

Return air must have enough free area so the blower can pull in air without creating excessive resistance. The standard rule used in practice questions is to provide 2 square inches of unobstructed free air area for every 1,000 BTUH of the furnace's rated input. This keeps the airflow steady and prevents the furnace from overheating or running inefficiently. So for a furnace rated at 60,000 BTUH, the minimum return air opening should be about 120 in^2 of free area. The other options don't fit this 2 in^2 per 1,000 BTUH ratio, which is why they're not correct.

8. When selecting a bend radius for thin sheet metal, what must be verified to prevent cracking?

A. The color of the coating

B. Material capability

C. Bend direction

D. Ambient humidity

When forming thin sheet metal, the danger of cracking at the bend comes from whether the material can tolerate the plastic deformation required by that bend. Verifying material capability means checking the metal's formability, ductility, thickness, and any coatings to ensure the bend radius is within what the material can safely bend without cracking. If the bend radius is too small for the material's capability, the outer fibers stretch and fracture can occur along the bend. This is why material capability is the best choice: it directly addresses whether the metal itself can withstand the bending without fracturing, considering its properties and any coating that might impair bendability. The other factors don't directly determine crack risk in bending: the color of the coating doesn't influence formability, bend direction isn't a primary factor in crack susceptibility, and ambient humidity isn't a controlling factor for the immediate crack resistance of the bend.

9. 26 inch round duct, positive pressure, un-reinforced long seam 4 inches W.G. can be made of which gauge?

A. 24 gauge

B. 22 gauge

C. 26 gauge

D. 20 gauge

When a duct carries positive pressure, the seam is pushed outward by the internal force, and the risk of seam failure grows with the length of the seam and how thin the metal is. For a 26-inch round duct with a four-inch long unreinforced seam, you need enough wall thickness to resist that outward thrust without additional stiffeners. Among common galvanized gauges, 22 gauge provides a solid balance: it's thick enough to handle the pressure along that short but exposed seam without reinforcement, yet not so thick and heavy as to be unnecessarily costly or hard to form. Thinner gauges like 24 or 26 would be more prone to seam bulging or failure under positive pressure, while 20 gauge would be stronger than necessary for this scenario and adds extra cost and weight. So 22 gauge is the appropriate choice for an unreinforced long seam on this duct.

SAMPLE

10. What are the maximum flame spread and smoke-developed indices allowed for non-metallic ducts?

A. 15, 25

B. 25, 50

C. 75, 200

D. 50, 200

When evaluating non-metallic ducts, safety in a fire is about how quickly flames can spread on the duct surface and how much smoke the duct material will emit. The standard sets strict limits to keep fire growth and smoke spread through the HVAC system from becoming dangerous. The allowed values are a flame-spread index of 25 or less and a smoke-developed index of 50 or less. This means the material should not facilitate rapid flame spread along its surface and should not produce excessive smoke when it burns. Any option that allows higher flame-spread or higher smoke-developed values would not meet the requirement, whereas the combination of 25 for flame spread and 50 for smoke development matches the permitted limits.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://sheetmetaljourneyman.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE