SPECIAL INSPECTOR (SI) CERTIFICATIONS FIREPROOFING PRACTICE TEST (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://sifireproofing.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1

Table of Contents 2

Introduction 3

How to Use This Guide 4

Questions 5

Answers 8

Explanations 10

Next Steps 15

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. **What defines the typical safe working temperature range for applying cementitious fireproofing?**

   A. Any ambient temperature with proper ventilation.

   B. Below the manufacturer's specified range is acceptable.

   C. Within the manufacturer's specified ambient and substrate temperature range.

   D. Only above freezing temperatures.

2. **For high-rise structures at 410 feet, the required SFRM bond strength is at least 430 psf. Which option is correct?**

   A. 420 psf

   B. 430 psf

   C. 440 psf

   D. 450 psf

3. **What surface prep level is typically required for steel to receive spray-applied fireproofing?**

   A. A blast-cleaned surface to roughness level SA 2.5 per ISO 8501-1

   B. Roughened to SA 1.0 per ISO 8501-1

   C. Painted surface

   D. Dusty, oily surface

4. **When patching SFRM, which materials are allowed?**

   A. Cementitious patch

   B. Water-based patch

   C. The same SFRM used on the project

   D. Different patch material

5. **Which of the following documents is not typically required to verify fireproofing compliance?**

   A. Only shop drawings.

   B. Daily logs and weather data.

   C. Shop drawings, material certificates, field reports, test results, daily logs, non-conformance reports, and manufacturer data sheets.

   D. Submittal approvals only.

SAMPLE

6. What is the purpose of protective coverings during fireproofing installation?

A. To hide the installation from clients.

B. To capture moisture.

C. To protect surfaces not being coated and prevent overspray contamination; maintain cleanliness.

D. To speed up curing.

7. Explain the difference between a thermal barrier and fireproofing?

A. Fireproofing provides structural fire resistance; a thermal barrier is a separate interior finish that limits heat transfer; these are distinct compliance concepts.

B. Thermal barrier provides structural fire resistance; fireproofing is for aesthetics.

C. They are interchangeable.

D. Fireproofing and thermal barrier always installed together with no distinctions.

8. What is the difference between cementitious and intumescent fireproofing?

A. Cementitious is a rigid mineral-based insulation material; intumescent coatings are paint-like and expand when heated to form an insulating char

B. Cementitious coatings are flexible paints, and intumescent coatings are rigid blocks

C. Cementitious is a liquid coating; intumescent is a solid

D. Cementitious is decorative; intumescent provides soundproofing

9. The minimum size for a density test sample is 8 cubic inches. Which option matches?

A. 8 cubic inches

B. 6 cubic inches

C. 10 cubic inches

D. 12 cubic inches

10. For metal decking totaling 9,100 square feet, how many SFRM thickness tests are required?

A. 8

B. 9

C. 10

D. 12

SAMPLE

Answers

SAMPLE

1. C
2. B
3. D
4. C
5. C
6. C
7. A
8. A
9. A
10. C

SAMPLE

Explanations

SAMPLE

1. What defines the typical safe working temperature range for applying cementitious fireproofing?

A. Any ambient temperature with proper ventilation.

B. Below the manufacturer's specified range is acceptable.

C. Within the manufacturer's specified ambient and substrate temperature range.

D. Only above freezing temperatures.

Applying cementitious fireproofing must be done within the temperature range specified by the manufacturer for both ambient air and the surface being coated. This window ensures the material hydrates and cures properly, bonds well to the substrate, and dries with a uniform, durable finish. If you go outside these temperatures, curing can be too slow or too fast, moisture may not release correctly, and adhesion or surface quality can suffer, leading to cracking, sagging, or dusting. Ventilation doesn't fix product-specific limits, so even with good air flow, you still need to stay inside the defined range. Being only above freezing isn't enough, because many products require a broader, defined temperature window for both ambient and substrate to achieve proper performance. The safe, effective practice is to apply within the manufacturer's specified ambient and substrate temperature range.

2. For high-rise structures at 410 feet, the required SFRM bond strength is at least 430 psf. Which option is correct?

A. 420 psf

B. 430 psf

C. 440 psf

D. 450 psf

The requirement means the SFRM bond strength must be 430 psf or higher. The option that exactly meets this minimum is 430 psf, so it satisfies the criterion. 420 psf is below the minimum and wouldn't be acceptable. While 440 psf and 450 psf also meet the requirement, 430 psf is the value that matches the stated minimum.

3. What surface prep level is typically required for steel to receive spray-applied fireproofing?

A. A blast-cleaned surface to roughness level SA 2.5 per ISO 8501-1

B. Roughened to SA 1.0 per ISO 8501-1

C. Painted surface

D. Dusty, oily surface

The key idea is that spray-applied fireproofing needs a clean, dry, and highly adherent steel surface. Standards like ISO 8501-1 describe surface cleanliness levels, and for critical bonding of fireproofing, the most reliable prep is blast cleaning to a near-white metal level (SA 2.5). This treatment removes oil, grease, dirt, rust, and loose coatings, leaving a smooth, clean surface that provides good mechanical bonding for the fireproofing material. A roughened level of SA 1.0 is less thorough and may leave contaminants that can weaken adhesion. A painted surface would require removal of the paint to expose bare steel, and a dusty, oily surface would not meet the cleanliness needed for proper bonding. So, blast-cleaned to SA 2.5 is typically the correct prep for reliable spray-applied fireproofing adhesion.

SAMPLE

4. When patching SFRM, which materials are allowed?

A. Cementitious patch

B. Water-based patch

C. The same SFRM used on the project

D. Different patch material

Patch repairs for sprayed fire-resistive materials must use the same SFRM that was originally applied on the project. Matching the material preserves the bond, curing behavior, and thermal properties, which keeps the fire-resistance rating and the system's listing intact. Using a different patch material, such as a cementitious or water-based patch that isn't the same SFRM, can introduce differences in strength, porosity, moisture handling, and thermal expansion. Those differences can lead to poor bonding, cracking, or delamination under heat, potentially reducing the effective fire resistance and voiding the listing. Therefore, the patch should be the same SFRM used on the project unless the manufacturer explicitly approves a different patch for this specific system.

5. Which of the following documents is not typically required to verify fireproofing compliance?

A. Only shop drawings.

B. Daily logs and weather data.

C. Shop drawings, material certificates, field reports, test results, daily logs, non-conformance reports, and manufacturer data sheets.

D. Submittal approvals only.

Verifying fireproofing compliance relies on an auditable trail of evidence that shows what was specified, what was installed, and how it was tested or observed in the field. The best answer reflects the full range of documentation typically used to confirm conformance: shop drawings confirm the intended thickness and placement, material certificates verify product specifications and compliance, field reports document actual installation conditions and progress, test results demonstrate performance against requirements, daily logs capture environmental conditions and work activity, non-conformance reports record deviations and corrective actions, and manufacturer data sheets provide authoritative product information. Together these documents create a thorough record that can be reviewed by inspectors, owners, and authorities to verify that the fireproofing meets the contract and code requirements. Relying on only one type of document, such as submittal approvals alone or daily logs and weather data in isolation, would not provide the complete, traceable evidence needed for full verification.

6. What is the purpose of protective coverings during fireproofing installation?

A. To hide the installation from clients.

B. To capture moisture.

C. To protect surfaces not being coated and prevent overspray contamination; maintain cleanliness.

D. To speed up curing.

Protective coverings serve as a barrier to keep surfaces that should not receive fireproofing clean and free from contamination. They shield adjacent floors, walls, ducts, equipment, and finishes from overspray, drips, splatter, and debris, helping maintain a tidy work area and ensuring that coatings bond properly where intended. Proper use also makes cleanup easier after the work, and helps inspections go smoothly. They should be placed and removed carefully so they don't interfere with curing or leave residues, and they should not trap moisture. So the main purpose is to protect surfaces not being coated and prevent overspray contamination; maintain cleanliness.

SAMPLE

7. Explain the difference between a thermal barrier and fireproofing?

A. Fireproofing provides structural fire resistance; a thermal barrier is a separate interior finish that limits heat transfer; these are distinct compliance concepts.

B. Thermal barrier provides structural fire resistance; fireproofing is for aesthetics.

C. They are interchangeable.

D. Fireproofing and thermal barrier always installed together with no distinctions.

The main idea here is that fire protection for structure and interior heat control are two separate functions with different roles in fire-rated design. Fireproofing is the material applied directly to structural members—like steel beams or columns—to slow heat rise and maintain structural integrity during a fire. It is part of the system that provides the required structural fire resistance rating for the member. A thermal barrier, by contrast, is an interior finish that sits between the fire exposure and the occupied or sensitive space to limit heat transfer. It's typically a standard interior finish (for example, drywall) that protects contents and occupants by reducing how quickly heat and flames can reach them. It does not contribute to the structural fire resistance of the member itself. Because they serve different purposes, they are not interchangeable and are not inherently installed together as a single function. Fireproofing provides structural protection, while a thermal barrier provides interior heat protection. In some assemblies, both appear in a design, but they are specified for distinct requirements and have separate compliance implications.

8. What is the difference between cementitious and intumescent fireproofing?

A. Cementitious is a rigid mineral-based insulation material; intumescent coatings are paint-like and expand when heated to form an insulating char

B. Cementitious coatings are flexible paints, and intumescent coatings are rigid blocks

C. Cementitious is a liquid coating; intumescent is a solid

D. Cementitious is decorative; intumescent provides soundproofing

Understanding how these fireproofing types work helps you see the difference. Cementitious fireproofing is a rigid, mineral-based coating that sets to a solid layer. It protects by its thickness and solid insulation properties, blocking heat transfer through the material itself. Intumescent fireproofing, on the other hand, is applied like a coating similar to paint and remains relatively thin under normal conditions. When exposed to heat, it undergoes a chemical reaction that causes it to swell and form a thick insulating char, creating a protective barrier. That's why the best description is that cementitious is a rigid mineral-based insulation material, while intumescent coatings are paint-like and expand when heated to form an insulating char. Other descriptions—calling cementitious flexible or decorative, or saying intumescent is a rigid block or a liquid/solely for soundproofing—don't match how these systems behave or are applied in fire protection.

SAMPLE

9. The minimum size for a density test sample is 8 cubic inches. Which option matches?

A. 8 cubic inches

B. 6 cubic inches

C. 10 cubic inches

D. 12 cubic inches

The key idea is that a density test needs a specimen large enough to provide a reliable reading. Eight cubic inches is the smallest size that meets the standard, so it represents the minimum required volume. That's why eight cubic inches is the correct match. A smaller sample, like six, wouldn't meet the minimum and could give an inaccurate density due to insufficient material. Larger samples, such as ten or twelve cubic inches, do satisfy the requirement too, but they exceed the minimum rather than match it.

10. For metal decking totaling 9,100 square feet, how many SFRM thickness tests are required?

A. 8

B. 9

C. 10

D. 12

Thickness testing for SFRM is typically done at a rate of one thickness test for every 1,000 square feet of sprayed area, or any portion of that area. This ensures sampling across the whole installation to catch any thin spots. For 9,100 square feet, 9,100 divided by 1,000 equals 9.1. Since you can't do a partial test, you round up to the next whole number, which is 10 tests. The leftover portion (even as small as 100 square feet) requires its own test to verify thickness across the entire area.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://sifireproofing.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE