TEXAS WASTEWATER CLASS B PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR THE FULL VERSION STUDY GUIDE

https://texaswastewaterclassb.examzify.com

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright 1
Table of Contents 2
Introduction 3
How to Use This Guide 4
Questions 5
Answers 8
Explanations 10
Next Steps 16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

SAMPLE

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

SAMPLE

Questions

SAMPLE

1. **Inorganic solids in wastewater treatment typically include which of the following?**

   A. Paper and plastics

   B. Sand, grit, and minerals

   C. Food waste

   D. Oil and grease

2. **What type of solids includes materials that can be suspended or dissolved in wastewater?**

   A. Organic Solids

   B. Inorganic Solids

   C. Settable Solids

   D. Volatile Solids

3. **What is a typical settling time for good quality sludge in an activated sludge plant?**

   A. 5 to 10 minutes

   B. 10 to 15 minutes

   C. 15 to 20 minutes

   D. 20 to 30 minutes

4. **If an activated sludge system displays no aeration, what operational issue should be suspected?**

   A. Excessive sludge wasting

   B. Loss of aeration equipment

   C. Insufficient oxygen supply

   D. Clogged aerators

5. **Which method is preferred for cleaning sewer lines?**

   A. Chemical cleaners

   B. Hydro Jet Cleaner

   C. Manual scraping

   D. Pressure washing

SAMPLE

6. What is referred to when TCEQ authorizes the discharge of untreated wastewater near a receiving stream in extreme cases?

A. Overflow

B. Land application

C. Bypass

D. Retention

7. If an operator notices dead spots in the aeration tank, what issue is likely occurring?

A. High dissolved oxygen

B. Plugged diffusers

C. Low sludge concentration

D. Insufficient aeration volume

8. Which are important control parameters in the activated sludge process?

A. Temperature, pH level, and effluent flow

B. Dissolved oxygen level, aerator solids level, and wasting rate

C. Only the rate of returned sludge

D. Inflow and outflow rates only

9. What is the expected BOD removal percentage typically achieved in the Activated Sludge process?

A. 50 to 60%

B. 70 to 80%

C. 90 to 99%

D. 100%

10. What observations are essential for the final clarifier?

A. Surface scum, sludge blanket, and weir flow

B. Only sludge blanket and rising solids

C. Surface flow and evaporation rates

D. Color and odor of the effluent

SAMPLE

Answers

SAMPLE

1. B
2. B
3. C
4. C
5. B
6. C
7. B
8. B
9. C
10. A

SAMPLE

Explanations

SAMPLE

1. Inorganic solids in wastewater treatment typically include which of the following?

A. Paper and plastics

B. Sand, grit, and minerals

C. Food waste

D. Oil and grease

The correct answer includes sand, grit, and minerals because these materials are characterized as inorganic solids commonly found in wastewater. Inorganic solids are generally defined as materials that do not contain carbon and are not derived from living organisms. Sand and grit arise from soil and dust, which can enter the wastewater system during rainfall or runoff, while mineral solids can come from various sources, including natural minerals that are carried into the system. The other options involve organic materials or are not considered inorganic in the context of wastewater. For example, paper and plastics are primarily organic compounds despite their physical nature as solids, and food waste is composed of organic materials, which means they are not classified as inorganic solids. Oil and grease, likewise, originate from organic substances like fats and oils, making them unsuitable as examples of inorganic solids in wastewater treatment.

2. What type of solids includes materials that can be suspended or dissolved in wastewater?

A. Organic Solids

B. Inorganic Solids

C. Settable Solids

D. Volatile Solids

The correct choice refers to a category of solids that encompasses substances that can either be suspended in the water or dissolved within it. Inorganic solids are typically non-carbon-based materials; they include elements and compounds such as salts and minerals that can be present in wastewater. The characteristic of being suspended or dissolved is crucial for understanding how these solids behave in treatment processes. Organic solids, on the other hand, are primarily carbon-based materials and generally do not include inorganic compounds. Settable solids refer to particles that settle out of suspension under the influence of gravity, which doesn't pertain to the dissolved state. Volatile solids are a subset of organic solids that can be lost through evaporation when heated, suggesting that they are also not representative of all materials that can be dissolved. In summary, inorganic solids are defined by their presence either in a suspended phase or dissolved in the wastewater, making them the appropriate classification for this question.

SAMPLE

3. What is a typical settling time for good quality sludge in an activated sludge plant?

A. 5 to 10 minutes

B. 10 to 15 minutes

C. 15 to 20 minutes

D. 20 to 30 minutes

A typical settling time for good quality sludge in an activated sludge plant is around 15 to 20 minutes. This duration allows for effective sedimentation of the biological solids, enabling the heavier particles to settle to the bottom of the clarifier, forming a sludge layer that can then be removed for further processing or disposal. This timeframe is important because it strikes a balance between allowing enough time for the solids to settle while also maintaining efficiency in the overall wastewater treatment process. Shorter settling times may result in incomplete separation, while longer times can lead to inefficiencies and delays in the treatment cycle. In activated sludge systems, achieving optimal settling times is crucial for maintaining proper system performance, ensuring that the effluent is of high quality, and preventing issues such as bulking or scum formation. Therefore, the choice indicating 15 to 20 minutes reflects a standard practice in the industry.

4. If an activated sludge system displays no aeration, what operational issue should be suspected?

A. Excessive sludge wasting

B. Loss of aeration equipment

C. Insufficient oxygen supply

D. Clogged aerators

The ideal functioning of an activated sludge system relies heavily on the presence of adequate aeration, as this process is essential for maintaining the necessary dissolved oxygen levels that support the metabolic activity of microorganisms. If there is no aeration, it can lead to insufficient oxygen supply, which directly impacts the health and functionality of the biological community in the system. Without sufficient oxygen, microorganisms cannot effectively break down organic matter, ultimately leading to a decline in water quality and treatment efficiency. While there may be other factors to consider, such as clogged aerators or issues with the aeration equipment, the primary and most immediate concern when aeration is absent is the failure to provide enough oxygen to sustain biological processes.

5. Which method is preferred for cleaning sewer lines?

A. Chemical cleaners

B. Hydro Jet Cleaner

C. Manual scraping

D. Pressure washing

The preferred method for cleaning sewer lines is hydro jet cleaning. This technique involves using high-pressure water jets to effectively clear blockages and debris from the pipes. Hydro jetting is particularly advantageous because it not only removes clogs but also cleans the interior of the pipes, which helps to prevent future build-up. The powerful water jets can reach areas that mechanical methods might struggle with, providing a thorough cleaning and maintaining the integrity of the sewer line. Chemical cleaners, while sometimes effective for minor issues, can be harmful to pipes and the environment. Manual scraping requires physical access to the pipes, which can be labor-intensive and may not be practical for all situations. Pressure washing is more suited for exterior surfaces and is not designed specifically for the needs of sewer lines. Hydro jetting stands out as the most comprehensive and effective method for cleaning these systems.

SAMPLE

6. What is referred to when TCEQ authorizes the discharge of untreated wastewater near a receiving stream in extreme cases?

A. Overflow

B. Land application

C. Bypass

D. Retention

The term referred to when TCEQ authorizes the discharge of untreated wastewater near a receiving stream in extreme cases is known as a bypass. A bypass is a situation where the flow of wastewater is redirected, allowing untreated or partially treated wastewater to be released into a water body due to an emergency or unforeseen circumstances, such as excessive rainfall or mechanical failure. This procedure is typically regulated and monitored to minimize environmental impact, as it is not the normal operational process and comes with certain conditions that must be followed. In extreme situations, it may be necessary to resort to this method to prevent backups or overflows that could cause more significant public health and environmental issues. Understanding why the other options do not fit this context further clarifies the correct answer. Overflow usually refers to excess wastewater spilling over containment areas, often due to system overloads and is generally an uncontrolled event. Land application, while a waste management strategy, involves the deliberate and safe distribution of treated wastewater onto land, rather than releasing it directly into water bodies. Retention pertains to the storage of wastewater within a facility for treatment at a later time rather than discharging it untreated.

7. If an operator notices dead spots in the aeration tank, what issue is likely occurring?

A. High dissolved oxygen

B. Plugged diffusers

C. Low sludge concentration

D. Insufficient aeration volume

Identifying dead spots in an aeration tank typically points to issues with the aeration system's ability to distribute air evenly throughout the tank. When diffusers become plugged, they fail to release air effectively into the water, leading to areas with inadequate mixing and aeration—these areas are referred to as dead spots. When diffusers are functioning properly, they facilitate an even distribution of air bubbles, which helps maintain uniform conditions necessary for the aerobic processes to occur. However, if the diffusers are compromised due to clogging, certain portions of the tank may not receive sufficient oxygen, affecting the overall treatment efficiency. Other options might suggest potential concerns within the aeration system, but they do not directly relate to the creation of dead spots in the same manner as plugged diffusers do. Thus, understanding the mechanics of aeration and the importance of diffuser function clearly highlights why recognizing plugged diffusers is crucial when dead spots are observed.

SAMPLE

8. Which are important control parameters in the activated sludge process?

A. Temperature, pH level, and effluent flow

B. Dissolved oxygen level, aerator solids level, and wasting rate

C. Only the rate of returned sludge

D. Inflow and outflow rates only

The choice highlighting dissolved oxygen level, aerator solids level, and wasting rate as important control parameters in the activated sludge process is indeed correct. Dissolved oxygen is crucial because it directly affects the respiration of the microorganisms in the activated sludge, which are essential for breaking down organic matter in wastewater. If the oxygen levels are too low, the bacteria cannot perform their function effectively, leading to incomplete treatment. Aerator solids level refers to the concentration of suspended solids in the aeration tank, which indicates the amount of biomass available for treatment. Maintaining the right concentration is key to ensuring that there are enough microorganisms to efficiently process the incoming waste. The wasting rate, or the amount of sludge that is removed from the system, must be carefully managed to maintain a balance in the system. Over- or under-wasting can disrupt the biological treatment process, as it affects both the solids retention time and the overall health of the microbial community. The other options lack the comprehensive considerations needed for effective control of the activated sludge process. Specifically, simply relying on temperature and pH is not sufficient on its own, nor is focusing only on inflow and outflow rates. The process requires a holistic approach that incorporates several factors, including but not limited to dissolved oxygen

9. What is the expected BOD removal percentage typically achieved in the Activated Sludge process?

A. 50 to 60%

B. 70 to 80%

C. 90 to 99%

D. 100%

In the Activated Sludge Process, a highly effective biological treatment method for wastewater, the typical BOD (Biochemical Oxygen Demand) removal percentage that can be achieved is generally in the range of 90 to 99%. This high level of removal is due to the efficient microbial activity that takes place in the aeration tanks, where microorganisms consume organic matter present in the wastewater. The activated sludge process involves aerating the wastewater to promote the growth of these microorganisms, which convert organic pollutants into biomass and stable end products. After aeration, this mixture is allowed to settle in a clarifier, separating the biomass from the treated water. The significant reduction in BOD is a key indicator of the process's success in eliminating organic pollutants and ensuring that the effluent meets environmental regulations. While lower percentages could be achievable in less optimized systems, the advanced designs and operational control of the Activated Sludge Process typically deliver exceptional performance, resulting in the high removal rates that characterize this method.

SAMPLE

10. What observations are essential for the final clarifier?

A. Surface scum, sludge blanket, and weir flow

B. Only sludge blanket and rising solids

C. Surface flow and evaporation rates

D. Color and odor of the effluent

The final clarifier is a critical component in the wastewater treatment process, and monitoring its performance is essential to ensure efficient operation and treatment. The aspects noted in the chosen response—surface scum, sludge blanket, and weir flow—are fundamental observations for assessing the clarifier's function. Surface scum indicates the presence of floating materials, which can affect the quality of the effluent and may require additional management to maintain treatment efficacy. The sludge blanket is a measure of the settled solids at the bottom of the clarifier. It is important to monitor this layer to prevent excessive accumulation that can lead to poor separation and treatment. Weir flow is crucial too, as it measures the flow of treated effluent over the weirs; ensuring proper flow maintains the hydraulic balance and prevents overflow or bypassing untreated water. In contrast, focusing solely on the sludge blanket and rising solids misses the importance of evaluating surface scum and weir flow, which are both vital for comprehensive clarifier monitoring. Observing only surface flow and evaporation rates does not provide enough information about the solids and treatment efficiency. Lastly, assessing color and odor of the effluent, while relevant to overall treatment quality, does not specifically inform about the functioning of the clarifier itself.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

https://texaswastewaterclassb.examzify.com

We wish you the very best on your exam journey. You've got this!

SAMPLE